

# Installing Detachable Cable Electrodes to Sodium Monitors

Two kits are available for retro-fitting detachable cable electrodes to 8036 Sodium Monitors:

## a) 1048/750 Sodium Electrode Kit

This kit comprises:

- 1 x 1048 836 detachable cable sodium electrode
- 1 x 1048 870 cable assembly.
- 1 x 8036 233 fitting sleeve.

## b) 1431/750 Reference Electrode Kit

This kit comprises:

- 1 x 1436 836 detachable cable reference electrode
- 1 x 1431 870 cable assembly.

### Fitting the Detachable Cable Sodium Electrode – 1048/750

- 1) Open the cover of the junction box and remove the cables of the existing electrodes.
- 2) Thread the 1048 870 cable assembly through the “P” clips on the backplate.
- 3) Remove the existing sodium electrode.
- 4) Fit the sleeve.
- 5) Insert the sodium electrode in the sleeve after removing the black rubber caps from both ends of the electrode.
- 6) Connect the tag contact as shown in the manual.
- 7) Screw the red connector onto the top of the sodium electrode.

### Fitting the Detachable Cable Reference Electrode – 1431/750

- 1) Open the cover of the junction box and remove the cables of the existing electrodes.
- 2) Thread the 1431 870 cable assembly through the “P” clips on the backplate.
- 3) Remove the existing reference electrode.
- 4) Fit the reference electrode in the flow cell after removing the black rubber caps from both ends of the electrode.
- 6) Connect the tag contact as shown in the manual.
- 7) Screw the black connector onto the top of the reference electrode.

### Notes

**When the electrodes next need replacing, it is only necessary to unscrew the cable from the top of the electrode and fit a new one. The cable remains attached to the junction box.**

**These kits need only be ordered once. When you next re-order replacement electrodes order only 1048/836 and/or 1436/836.**

IM/8036-DEK Issue 2



The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

© ABB 2001

Printed in UK (04.01)

**ABB Automation Ltd**  
Stonehouse,  
Gloucestershire. GL10 3TA  
UK  
Tel: +44 (0)1453-826661  
Fax: +44 (0)1453-827856

**ABB Automation Inc.**  
125 E. County Line Road  
Warminster, PA 18974  
USA  
Tel: +1 215-674-6000  
Fax: +1 215-674-7183

**ABB** has Sales & Customer Support expertise  
in over 100 countries worldwide

[www.abb.com](http://www.abb.com)