

Using 8002 Probe to Measure Ammonia in Seawater

1 Ammonia Probe Filling Solution

If this filling solution is to be used in a probe for measurements in sea water, it is recommended that 1.7 g of ammonium chloride and 1 drop (approximately 0.05 ml) of 0.1M silver nitrate are added to the contents of each 50 ml filling solution bottle before first use. Refer to the probe manual, IM/8002 Section 3.9, for further information.

ABB has Sales & Customer Support expertise
in over 100 countries worldwide

www.abb.com

The Company's policy is one of continuous product
improvement and the right is reserved to modify the
information contained herein without notice.

Printed in UK (06.08)

© ABB 2008



ABB Limited

Oldends Lane, Stonehouse
Gloucestershire
GL10 3TA
UK
Tel: +44 (0)1453 826661
Fax: +44 (0)1453 829671

ABB Inc.

125 E. County Line Road
Warminster
PA 18974
USA
Tel:+1 215 674 6000
Fax:+1 215 674 7183