

Pulp Paper & Logistics

Freeness and fibre morphology measurement for quality control

Online instruments that measure the characteristics of fibres in pulp can more frequently provide information than lab testing, enabling quicker corrective action to be taken by operators, leading to better productivity, says Hakan Osterholm*

few decades ago, pulp quality in a paper mill could only be measured in a laboratory, using a number of standard testing methods such as drainability (freeness), per cent of unseparated fibres (Sommerville shive) and size classification by a series of screens (Bauer-McNett).

To evaluate pulp strength, operators once needed to follow a laborious process of making pulp handsheets and performing destructive tests on them. By the time all these tests were complete, the pulp was often already made into paper ready to be shipped. If downward trends in pulp quality were not detected in time, many rolls of paper had to be rejected or downgraded because quality trends were not available in time for a correction to be made.

Today, the story is very different. The evolution of online testing, automated sampling equipment and robotic testers for offline testing of both pulp and paper, combined with data historians, sophisticated control systems and emerging artificial intelligence techniques, have given the industry powerful tools to gain a much tighter control of quality while also enabling faster grade changes.

As a major supplier of laboratory and online measurement equipment – including the L&W Freeness and Fibre online



ABB's global manager for pulp measurements Håkan Österholm

system for fibre morphology measurement in the wet end – ABB has decades of experience in supporting the evolving needs



Figure 1: A fibrillated softwood fibre

July/August 2021

(acquired by ABB in 2011), a second edition of the book will be published later in 2021. The new edition updates developments in this field over the last 15 years, including the use of highresolution cameras and image analysis software that measure fibre properties much more comprehensively than the original lab tests, in a fraction of the time. Here's a preview of some of

of the industry by pioneering

that have helped drive quality

Such expertise is evident in

the 'Fibre Guide' book, which

as well as applications of fibre

analysis within the industry. First

developed by Lorentzen & Wettre

discusses the impacts of different

fibre types and ways of processing

management forward.

many measurement techniques

Freeness measurement

Guide' explores.

the developments that the 'Fibre

The original pulp freeness measurement, as measured by either the Canadian Standard Freeness test (CSF) or the Schopper-Riegler test (SR), is to a great extent a measure of the fibrillation and fines content of pulp, and simulates the drainage rate on the wet end of a paper machine. The CSF test starts with one litre of pulp suspension at a consistency of 0.3 per cent being poured into a drainage chamber. The bottom lid and the air valve on the drainage chamber are opened to start the drainage process. The



Figure 2: Bleached softwood fibres, 50 times magnification

flow of water through the screen at the bottom decreases as a fibre pad builds up in the bottom of the chamber. The total volume in millilitres of water that drains from the chamber is the freeness value of the sample.

In a manually-operated freeness test, variation in how the sample is handled each time a test is made means the precision and reproducibility

are not as high as in automatic tests. Another drawback of manual freeness tests is the time needed to collect samples and determine pulp consistency. It is quite common that only a few measurements per sample point can be carried out in a day, and this low frequency of freeness measurements is not suitable for controlling the process with any precision.



Figure 3: Freeness measurement (manual test in green, automatic test in blue) and Refining specific energy in red at FPC Papeles in Chile



These drawbacks are easily overcome using an online automatic freeness testing system, where the samples are handled the same way every time, both in the preparation stage and in all the tests, resulting in better accuracy and precision. Plus, automatic freeness and fibre analysers can collect samples from multiple locations and process hundreds of measurements per day – giving much more data that can be used for tighter process control.

Freeness measurements are also used to determine whether pulp has been sufficiently developed by refining. The principal objectives of pulp refining are to:

- Increase the flexibility of the cell wall to promote increased contact area
- Fibrillate the external surface of the fibre and generate fines

This further promotes the formation of hydrogen bonds and increases the total surface area available for bonding. When more strength is desired for a certain paper grade, the specific energy of the refining process can be increased by narrowing the gap through which the fibres are forced in the refiner. Because this results in a lower freeness, the freeness measurement is often used as an indicator of the degree of refining.

Online sensors

The initial sensors for online purposes using modern electrooptical and digital processor components (photodiodes and a microprocessor) were developed

CSF x Specific Refining Energy

July/August 2021



around 1975. One of the first was an electro-optical shive analyser, suitable for the optimisation of screen rooms. A few years later, systems for monitoring refining in mechanical pulping that combined measurements of optical fibre length, an optical shive analyser and a freeness measurement were developed. Ways of measuring average fibre length and radius for online purposes were invented in the 1980s.

In the last 10 years, two major improvements have taken place. First, high-resolution cameras have delivered a much finer level of detail, enabling the monitoring of fibre fibrillation (as shown in Figure 1). Second, the reliability of the equipment for online sampling and measurement has been greatly improved. The first online instruments were high-maintenance units, often requiring a few hours per day to keep them running smoothly.

Modern online fibre sampling and measurement devices, however, have been designed to avoid the build-up of dirt, and an automatic cleaning cycle is incorporated to ensure that plugging does not occur. The only maintenance now required is a weekly or bi-weekly check-up and a maintenance service once or twice per year.

Refiner control

Before the fibres reach the paper machine, it is vital that refining generates enough fibrillation and fine material to create proper bonding surfaces between the fibres as they are dried in the process. Too much refining generates additional energy costs (electricity to refiners, drives and vacuum pumps) and slows down the production speed (meaning lost profit). Too little refining



Figure 4: Shape factor of typical pulp fibres

generates lower-strength paper that could lead to web breaks at the paper machine or the converting plant.

The strength may need to be increased by other means such as using chemical additives or virgin kraft as a reinforcing pulp, which are more expensive than the cost of refining. Thus, the use of online freeness to control refining can lead to reductions in production costs, web breaks, culled paper and customer claims.

An example of such use can be found at a paper mill in Chile whose ultimate goal was to control the amount of refining of the incoming pulp to meet strength specifications. Located on the heavily-forested Pacific coast near Concepción, FPC Papeles makes packaging grades of paper from a combination of post-consumer and pre-consumer recovered fibre acquired from 27 cities and five customers. They wanted to improve their ability to adapt their process for the variability of incoming fibres, to both stabilise product quality and reduce costs.

Before acquiring an online pulp freeness sensor, the operators responded to variations in incoming fibre quality by manually modifying the refining load based on lab measurements of pre- and post-refiner freeness taken every two hours.

If the strength of the paper, measured once per reel (about every 45 minutes) was insufficient, the refining energy was increased. If that was not successful, other methods were tried, such as adding chemicals, using more pre-consumer double-lined kraft (DLK) or finally, downgrading it to a lowerstrength product.

Having previously upgraded their refiners to enable automatic modification of their disk gap based on fibre mass flow, FPC now needed a way to determine when to open and close the gaps to provide the required refining load, avoiding the delay between lab measurements of freeness. The long delay between lab freeness measurements was masking fibre variation, making it impossible to respond to changes in a timely fashion.

In early 2018, FPC Papeles installed an online freeness measurement system equipped with two sampling devices. This allowed operators to measure freeness every six to seven minutes at the output of the mill's two refining circuits and more closely monitor the refining process, as shown in Figure 3.

Following a two-month validation period, during which the online and lab readings were regularly compared and correlated, the operators placed their full trust in the new system and began to manually adjust the refiner load based on online freeness readings. In addition to better control, less variability and energy savings, the mill has seen increased production levels and reduced grade change time as a result of the online measurements. The next step would be to close the control loop to automatically run the refiners based on the online measurement by using advanced

process controls. Eduardo Izquierdo, the technical director at FPC Papeles, said: "We are delighted with the online freeness measurement and the support we have received from ABB and MX-Chile, an ABB distributor who helped with installation and support. We look forward to continuing to work with them to achieve higher

levels of process stability, savings and final product quality."

Fibre morphology and paper strength

Freeness is not an absolute measure of the pulp strength. A low freeness value can be produced not only from wellfibrillated fibres, but also from a high concentration of low surface area ray cells with poor bonding potential, or shorter fibres. Thus, the measurement of other fibre properties will help to characterise the pulp better. These include shive content, fibre length, fibre width and shape factor, all of which can be measured with an online instrument. A high shape factor, as illustrated in Figure 4,



Pulp Paper & Logistics



means straight fibres and is well correlated with tensile strength and tensile stiffness.

It is possible to create a virtual strength sensor by combining several fibre measurements from an online fibre sensor, in combination with other process measurements.

This would provide a prediction of online paper strength every few minutes rather than once per reel. Using such a virtual strength sensor to control paper strength would bring additional value to closed-loop control of paper strength.

Better measurements stabilise consistency and quality

With the latest generation

of online instruments, which can characterise the nature of the fibres being used much more thoroughly than manual testing, paper mills can benefit from the improved reliability and higher frequency of online measurements compared to lab testing.

In the near future, the use of online and other virtual measurements for advanced process control strategies will enable mills that embrace new technology to leap ahead of their competition with more consistent quality and a stronger product that costs less to produce.

* Hakan Osterholm is global product manager for pulp measurements at ABB.