













	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
/* BIO2 / Rev B BIO2 */												
	17	E0	EV_NODAT		1	0	1	1 F0171001	Reset	Binary input 1	INS	3701
	17	E1	EV_NODAT		2	0	1	0 F0171001	Activated	Binary input 1	INS	3701
	17	E2	EV_NODAT		4	0	2	1 F0171002	Reset	Binary input 2	INS	3702
	17	E3	EV_NODAT		8	0	2	0 F0171002	Activated	Binary input 2	INS	3702
	17	E4	EV_NODAT		16	0	3	1 F0171003	Reset	Binary input 3	INS	3703
	17	E5	EV_NODAT		32	0	3	0 F0171003	Activated	Binary input 3	INS	3703
	17	E6	EV_NODAT		64	0	4	1 F0171004	Reset	Binary input 4	INS	3704
	17	E7	EV_NODAT		128	0	4	0 F0171004	Activated	Binary input 4	INS	3704
	17	E8	EV_NODAT		256	0	5	1 F0171005	Reset	Binary input 5	INS	3705
	17	E9	EV_NODAT		512	0	5	0 F0171005	Activated	Binary input 5	INS	3705
	17	E10	EV_NODAT		1024	0	6	1 F0171006	Reset	Binary input 6	INS	3706
	17	E11	EV_NODAT		2048	0	6	0 F0171006	Activated	Binary input 6	INS	3706
	17	E12	EV_NODAT		4096	0	7	1 F0171007	Reset	Binary input 7	INS	3707
	17	E13	EV_NODAT		8192	0	7	0 F0171007	Activated	Binary input 7	INS	3707
	17	E14	EV_NODAT		16384	0	8	1 F0171008	Reset	Binary input 8	INS	3708
	17	E15	EV_NODAT		32768	0	8	0 F0171008	Activated	Binary input 8	INS	3708
	17	E16	EV_NODAT		65536	0	9	1 F0171009	Reset	Binary input 9	INS	3709
	17	E17	EV_NODAT		131072	0	9	0 F0171009	Activated	Binary input 9	INS	3709
	17	E18	EV_NODAT		262144	0	10	1 F0171010	Reset	Binary input 10	INS	3710
	17	E19	EV_NODAT		524288	0	10	0 F0171010	Activated	Binary input 10	INS	3710
	17	E20	EV_NODAT		1048576	0	11	1 F017O001	Reset	Binary output 1	INS	3711
	17	E21	EV_NODAT		2097152	0	11	0 F017O001	Activated	Binary output 1	INS	3711
	17	E22	EV_NODAT		4194304	0	12	1 F017O002	Reset	Binary output 2	INS	3712
	17	E23	EV_NODAT		8388608	0	12	0 F017O002	Activated	Binary output 2	INS	3712
	17	E24	EV_NODAT		16777216	0	13	1 F017O003	Reset	Binary output 3	INS	3713
	17	E25	EV_NODAT		33554432	0	13	0 F017O003	Activated	Binary output 3	INS	3713
	17	E26	EV_NODAT		67108864	0	14	1 F017O004	Reset	Binary output 4	INS	3714
	17	E27	EV_NODAT		134217728	0	14	0 F017O004	Activated	Binary output 4	INS	3714
	17	E28	EV_NODAT		268435456	0	15	1 F017O005	Reset	Binary output 5	INS	3715
	17	E29	EV_NODAT		536870912	0	15	0 F017O005	Activated	Binary output 5	INS	3715
	17	E30	EV_NODAT		1073741824	0	16	1 F017O006	Reset	Binary output 6	INS	3716
	17	E31	EV_NODAT		2147483648	0	16	0 F017O006	Activated	Binary output 6	INS	3716
			Default mask=		0							
	17	E32	EV_NODAT		1	0	17	1 F0171021	Stop	Binary input 1 oscillate	INS	3717
	17	E33	EV_NODAT		2	0	17	0 F0171021	Start	Binary input 1 oscillate	INS	3717
	17	E34	EV_NODAT		4	0	18	1 F0171022	Stop	Binary input 2 oscillate	INS	3718
	17	E35	EV_NODAT		8	0	18	0 F0171022	Start	Binary input 2 oscillate	INS	3718
	17	E36	EV_NODAT		16	0	19	1 F0171023	Stop	Binary input 3 oscillate	INS	3719
	17	E37	EV_NODAT		32	0	19	0 F0171023	Start	Binary input 3 oscillate	INS	3719
	17	E38	EV_NODAT		64	0	20	1 F0171024	Stop	Binary input 4 oscillate	INS	3720
	17	E39	EV_NODAT		128	0	20	0 F0171024	Start	Binary input 4 oscillate	INS	3720
	17	E40	EV_NODAT		256	0	21	1 F0171025	Stop	Binary input 5 oscillate	INS	3721
	17	E41	EV_NODAT		512	0	21	0 F0171025	Start	Binary input 5 oscillate	INS	3721
	17	E42	EV_NODAT		1024	0	22	1 F0171026	Stop	Binary input 6 oscillate	INS	3722
	17	E43	EV_NODAT		2048	0	22	0 F0171026	Start	Binary input 6 oscillate	INS	3722
	17	E44	EV_NODAT		4096	0	23	1 F0171027	Stop	Binary input 7 oscillate	INS	3723
	17	E45	EV_NODAT		8192	0	23	0 F0171027	Start	Binary input 7 oscillate	INS	3723
	17	E46	EV_NODAT		16384	0	24	1 F0171028	Stop	Binary input 8 oscillate	INS	3724
	17	E47	EV_NODAT		32768	0	24	0 F0171028	Start	Binary input 8 oscillate	INS	3724
	17	E48	EV_NODAT		65536	0	25	1 F0171029	Stop	Binary input 9 oscillate	INS	3725
	17	E49	EV_NODAT		131072	0	25	0 F0171029	Start	Binary input 9 oscillate	INS	3725
	17	E50	EV_NODAT		262144	0	26	1 F0171030	Stop	Binary input 10 oscillate	INS	3726
	17	E51	EV_NODAT		524288	0	26	0 F0171030	Start	Binary input 10 oscillate	INS	3726
	17	E52	EV_COUNT		1048576	0	27	0 F0171041	Updated	Counter 1	INS	3727
	17	E53	EV_COUNT		2097152	0	28	0 F0171042	Updated	Counter 2	INS	3728
			Default mask=		0							

	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address	
/* LocalMMI027 / Rev C LocalMMI */													
	27	E0	EV_NODAT		1	0	0	0	-	OFF	Backlight	INS	4700
	27	E1	EV_NODAT		2	0	0	0	-	ON	Backlight	INS	4700
	27	E2	EV_NODAT		4	0	1	0	-	-	Password changed	INS	4701
	27	E3	EV_NODAT		8	0	2	0	-	-	Setting done	INS	4702
	27	E4	EV_NODAT		16	0	3	0	-	-	Moving to level 1 (Operator)	INS	4703
	27	E5	EV_NODAT		32	0	4	0	-	-	Moving to level 2 (Technical)	INS	4704
	27	E6	EV_NODAT		64	0	5	0	-	-	Language changed	INS	4705
			Default mask=		0								
/* 100028 / Rev A MMIWAKE */													
	28	E0	EV_NODAT		1	0	99	0	-	-	-	-	4899
	28	E1	EV_NODAT		2	0	0	0	-	Activated	MMI backligh	INS	4800
			Default mask=		0								
/* 100029 / Rev A INDRESET */													
	29	E1	EV_NODAT		2	1	0	0	-	Reset	Indications	INS	4900
	29	E3	EV_NODAT		8	1	1	0	-	Reset	Indications, latched	INS	4901
	29	E5	EV_NODAT		32	1	2	0	-	Reset	Indicat., latched, registered	INS	4902
			Default mask=		10								
/* 100031 / Rev D NOC3Low */													
	31	E0	EV_3BIT_1		1	1	0	0	F031O001	Reset	START signal from 3l> stage	STR	5100
	31	E1	EV_3BIT_1		2	1	0	0	F031O001	Activated	START signal from 3l> stage	STR	5100
	31	E2	EV_3BIT_1		4	1	1	0	F031O002	Reset	TRIP signal from 3l> stage	TRP	5101
	31	E3	EV_3BIT_1		8	1	1	0	F031O002	Activated	TRIP signal from 3l> stage	TRP	5101
	31	E4	EV_3BIT_1		16	1	2	0	F031O003	Reset	CBFP signal from 3l> stage	ALA	5102
	31	E5	EV_3BIT_1		32	1	2	0	F031O003	Activated	CBFP signal from 3l> stage	ALA	5102
	31	E6	EV_NODAT		64	0	3	0	F031I004	Reset	BS1 signal of 3l> stage	BLK	5103
	31	E7	EV_NODAT		128	0	3	0	F031I004	Activated	BS1 signal of 3l> stage	BLK	5103
	31	E8	EV_NODAT		256	0	4	0	F031I005	Reset	BS2 signal of 3l> stage	BLK	5104
	31	E9	EV_NODAT		512	0	4	0	F031I005	Activated	BS2 signal of 3l> stage	BLK	5104
	31	E10	EV_NODAT		1024	0	5	0	-	Off	Test mode of 3l> stage	INS	5105
	31	E11	EV_NODAT		2048	0	5	0	-	On	Test mode of 3l> stage	INS	5105
			Default mask=		63								
/* 100032 / Rev C NOC3High */													
	32	E0	EV_3BIT_1		1	1	0	0	F032O002	Reset	START signal from 3l>> stage	STR	5200
	32	E1	EV_3BIT_1		2	1	0	0	F032O002	Activated	START signal from 3l>> stage	STR	5200
	32	E2	EV_3BIT_1		4	1	1	0	F032O003	Reset	TRIP signal from 3l>> stage	TRP	5201
	32	E3	EV_3BIT_1		8	1	1	0	F032O003	Activated	TRIP signal from 3l>> stage	TRP	5201
	32	E4	EV_3BIT_1		16	1	2	0	F032O004	Reset	CBFP signal from 3l>> stage	ALA	5202
	32	E5	EV_3BIT_1		32	1	2	0	F032O004	Activated	CBFP signal from 3l>> stage	ALA	5202
	32	E6	EV_3BIT_1		64	0	3	0	F032O001	Reset	BSOUT signal from 3l>> stage	BLK	5203
	32	E7	EV_3BIT_1		128	0	3	0	F032O001	Activated	BSOUT signal from 3l>> stage	BLK	5203
	32	E8	EV_NODAT		256	0	4	0	F032I004	Reset	BS1 signal of 3l>> stage	BLK	5204
	32	E9	EV_NODAT		512	0	4	0	F032I004	Activated	BS1 signal of 3l>> stage	BLK	5204
	32	E10	EV_NODAT		1024	0	5	0	F032I005	Reset	BS2 signal of 3l>> stage	BLK	5205
	32	E11	EV_NODAT		2048	0	5	0	F032I005	Activated	BS2 signal of 3l>> stage	BLK	5205
	32	E12	EV_NODAT		4096	0	6	0	-	Off	Test mode of 3l>> stage	INS	5206
	32	E13	EV_NODAT		8192	0	6	0	-	On	Test mode of 3l>> stage	INS	5206
			Default mask=		63								
/* 100033 / Rev C NOC3Inst */													
	33	E0	EV_3BIT_1		1	1	0	0	F033O002	Reset	START signal from 3l>>> stage	STR	5300
	33	E1	EV_3BIT_1		2	1	0	0	F033O002	Activated	START signal from 3l>>> stage	STR	5300
	33	E2	EV_3BIT_1		4	1	1	0	F033O003	Reset	TRIP signal from 3l>>> stage	TRP	5301
	33	E3	EV_3BIT_1		8	1	1	0	F033O003	Activated	TRIP signal from 3l>>> stage	TRP	5301
	33	E4	EV_3BIT_1		16	1	2	0	F033O004	Reset	CBFP signal from 3l>>> stage	ALA	5302
	33	E5	EV_3BIT_1		32	1	2	0	F033O004	Activated	CBFP signal from 3l>>> stage	ALA	5302
	33	E6	EV_3BIT_1		64	0	3	0	F033O001	Reset	BSOUT signal from 3l>>> stage	BLK	5303
	33	E7	EV_3BIT_1		128	0	3	0	F033O001	Activated	BSOUT signal from 3l>>> stage	BLK	5303
	33	E8	EV_NODAT		256	0	4	0	F033I004	Reset	BS1 signal of 3l>>> stage	BLK	5304
	33	E9	EV_NODAT		512	0	4	0	F033I004	Activated	BS1 signal of 3l>>> stage	BLK	5304
	33	E10	EV_NODAT		1024	0	5	0	F033I005	Reset	BS2 signal of 3l>>> stage	BLK	5305
	33	E11	EV_NODAT		2048	0	5	0	F033I005	Activated	BS2 signal of 3l>>> stage	BLK	5305
	33	E12	EV_NODAT		4096	0	6	0	-	Off	Test mode of 3l>>> stage	INS	5306
	33	E13	EV_NODAT		8192	0	6	0	-	On	Test mode of 3l>>> stage	INS	5306
			Default mask=		63								



	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address	
/* 100034 / Rev D Inrush3 */													
	34	E0	EV_NODAT		1	1	0	0	F034O001	Reset	START signal from Inrush3 stage	STR	5400
	34	E1	EV_NODAT		2	1	0	0	F034O001	Activated	START signal from Inrush3 stage	STR	5400
	34	E2	EV_NODAT		4	0	1	0	-	Off	Test mode of Inrush3 stage	INS	5401
	34	E3	EV_NODAT		8	0	1	0	-	On	Test mode of Inrush3 stage	INS	5401
			Default mask=		3								
/* 100035 / Rev F DOC6Low */													
	35	E0	EV_3BIT_1		1	1	0	0	F035O002	Reset	START signal from 3I> -> stage	STR	5500
	35	E1	EV_3BIT_1		2	1	0	0	F035O002	Activated	START signal from 3I> -> stage	STR	5500
	35	E2	EV_3BIT_1		4	1	1	0	F035O003	Reset	TRIP signal from 3I> -> stage	TRP	5501
	35	E3	EV_3BIT_1		8	1	1	0	F035O003	Activated	TRIP signal from 3I> -> stage	TRP	5501
	35	E4	EV_3BIT_1		16	1	2	0	F035O004	Reset	CBFP signal from 3I> -> stage	ALA	5502
	35	E5	EV_3BIT_1		32	1	2	0	F035O004	Activated	CBFP signal from 3I> -> stage	ALA	5502
	35	E6	EV_NODAT		64	0	3	0	F035O001	Reset	DIRECTION signal of 3I> -> stage	ALA	5503
	35	E7	EV_NODAT		128	0	3	0	F035O001	Activated	DIRECTION signal of 3I>-> stage	ALA	5503
	35	E8	EV_NODAT		256	0	4	0	F035I016	Reset	BS1 signal of 3I> -> stage	BLK	5504
	35	E9	EV_NODAT		512	0	4	0	F035I016	Activated	BS1 signal of 3I> -> stage	BLK	5504
	35	E10	EV_NODAT		1024	0	5	0	F035I017	Reset	BS2 signal of 3I> -> stage	BLK	5505
	35	E11	EV_NODAT		2048	0	5	0	F035I017	Activated	BS2 signal of 3I> -> stage	BLK	5505
	35	E12	EV_NODAT		4096	0	6	0	-	Off	Test mode of 3I> -> stage	INS	5506
	35	E13	EV_NODAT		8192	0	6	0	-	On	Test mode of 3I> -> stage	INS	5506
			Default mask=		63								
/* 100036 / Rev F DOC6High */													
	36	E0	EV_3BIT_1		1	1	0	0	F036O003	Reset	START signal from 3I>> -> stage	STR	5600
	36	E1	EV_3BIT_1		2	1	0	0	F036O003	Activated	START signal from 3I>> -> stage	STR	5600
	36	E2	EV_3BIT_1		4	1	1	0	F036O004	Reset	TRIP signal from 3I>> -> stage	TRP	5601
	36	E3	EV_3BIT_1		8	1	1	0	F036O004	Activated	TRIP signal from 3I>> -> stage	TRP	5601
	36	E4	EV_3BIT_1		16	1	2	0	F036O005	Reset	CBFP signal from 3I>> -> stage	ALA	5602
	36	E5	EV_3BIT_1		32	1	2	0	F036O005	Activated	CBFP signal from 3I>> -> stage	ALA	5602
	36	E6	EV_3BIT_1		64	0	3	0	F036O002	Reset	BSOUT signal from 3I>> -> stage	BLK	5603
	36	E7	EV_3BIT_1		128	0	3	0	F036O002	Activated	BSOUT signal from 3I>> -> stage	BLK	5603
	36	E8	EV_NODAT		256	0	4	0	F036O001	Reset	DIRECTION signal of 3I>> -> stage	ALA	5604
	36	E9	EV_NODAT		512	0	4	0	F036O001	Activated	DIRECTION signal of 3I>> -> stage	ALA	5604
	36	E10	EV_NODAT		1024	0	5	0	F036I016	Reset	BS1 signal of 3I>> -> stage	BLK	5605
	36	E11	EV_NODAT		2048	0	5	0	F036I016	Activated	BS1 signal of 3I>> -> stage	BLK	5605
	36	E12	EV_NODAT		4096	0	6	0	F036I017	Reset	BS2 signal of 3I>> -> stage	BLK	5606
	36	E13	EV_NODAT		8192	0	6	0	F036I017	Activated	BS2 signal of 3I>> -> stage	BLK	5606
	36	E14	EV_NODAT		16384	0	7	0	-	Off	Test mode of 3I>> -> stage	INS	5607
	36	E15	EV_NODAT		32768	0	7	0	-	On	Test mode of 3I>> -> stage	INS	5607
			Default mask=		63								
/* 100037 / Rev F DOC6Inst */													
	37	E0	EV_3BIT_1		1	1	0	0	F037O003	Reset	START signal from 3I>>> -> stage	STR	5700
	37	E1	EV_3BIT_1		2	1	0	0	F037O003	Activated	START signal from 3I>>> -> stage	STR	5700
	37	E2	EV_3BIT_1		4	1	1	0	F037O004	Reset	TRIP signal from 3I>>> -> stage	TRP	5701
	37	E3	EV_3BIT_1		8	1	1	0	F037O004	Activated	TRIP signal from 3I>>> -> stage	TRP	5701
	37	E4	EV_3BIT_1		16	1	2	0	F037O005	Reset	CBFP signal from 3I>>> -> stage	ALA	5702
	37	E5	EV_3BIT_1		32	1	2	0	F037O005	Activated	CBFP signal from 3I>>> -> stage	ALA	5702
	37	E6	EV_3BIT_1		64	0	3	0	F037O002	Reset	BSOUT signal from 3I>>> -> stage	BLK	5703
	37	E7	EV_3BIT_1		128	0	3	0	F037O002	Activated	BSOUT signal from 3I>>> -> stage	BLK	5703
	37	E8	EV_NODAT		256	0	4	0	F037O001	Reset	DIRECTION signal of 3I>>> -> stage	ALA	5704
	37	E9	EV_NODAT		512	0	4	0	F037O001	Activated	DIRECTION signal of 3I>>> -> stage	ALA	5704
	37	E10	EV_NODAT		1024	0	5	0	F037I016	Reset	BS1 signal of 3I>>> -> stage	BLK	5705
	37	E11	EV_NODAT		2048	0	5	0	F037I016	Activated	BS1 signal of 3I>>> -> stage	BLK	5705
	37	E12	EV_NODAT		4096	0	6	0	F037I017	Reset	BS2 signal of 3I>>> -> stage	BLK	5706
	37	E13	EV_NODAT		8192	0	6	0	F037I017	Activated	BS2 signal of 3I>>> -> stage	BLK	5706
	37	E14	EV_NODAT		16384	0	7	0	-	Off	Test mode of 3I>>> -> stage	INS	5707
	37	E15	EV_NODAT		32768	0	7	0	-	On	Test mode of 3I>>> -> stage	INS	5707
			Default mask=		63								







	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
/* 100052 / Rev A CUB3Cap */												
	52	E0	EV_3BIT_1		1	1	0	0 F052O001	Reset	START signal from CUB3Cap stage St1	STR	7200
	52	E1	EV_3BIT_1		2	1	0	0 F052O001	Activated	START signal from CUB3Cap stage St1	STR	7200
	52	E2	EV_3BIT_1		4	1	1	0 F052O002	Reset	TRIP signal from CUB3Cap stage St1	TRP	7201
	52	E3	EV_3BIT_1		8	1	1	0 F052O002	Activated	TRIP signal from CUB3Cap stage St1	TRP	7201
	52	E4	EV_3BIT_1		16	1	2	0 F052O003	Reset	CBFP signal from CUB3Cap	ALA	7202
	52	E5	EV_3BIT_1		32	1	2	0 F052O003	Activated	CBFP signal from CUB3Cap	ALA	7202
	52	E6	EV_3BIT_1		64	0	3	0 F052O004	Reset	ST_ALARM signal from CUB3Cap stage St2	STR	7203
	52	E7	EV_3BIT_1		128	0	3	0 F052O004	Activated	ST_ALARM signal from CUB3Cap stage St2	STR	7203
	52	E8	EV_3BIT_1		256	1	4	1 F052O005	Reset	ALARM signal from CUB3Cap stage St2	ALA	7204
	52	E9	EV_3BIT_1		512	1	4	0 F052O005	Activated	ALARM signal from CUB3Cap stage St2	ALA	7204
	52	E10	EV_NODAT		1024	0	5	0 F052I004	Reset	BS1 signal of CUB3Cap	BLK	7205
	52	E11	EV_NODAT		2048	0	5	0 F052I004	Activated	BS1 signal of CUB3Cap	BLK	7205
	52	E12	EV_NODAT		4096	0	6	0 F052I005	Reset	BS2 signal of CUB3Cap	BLK	7206
	52	E13	EV_NODAT		8192	0	6	0 F052I005	Activated	BS2 signal of CUB3Cap	BLK	7206
	52	E14	EV_NODAT		16384	0	7	0 -	Off	Test mode of CUB3Cap	INS	7207
	52	E15	EV_NODAT		32768	0	7	0 -	On	Test mode of CUB3Cap	INS	7207
			Default mask=		831							
/* 100054 / Rev F MotStart */												
	54	E0	EV_NODAT		1	1	0	0 F054O001	Reset	START signal from MotStart	STR	7400
	54	E1	EV_NODAT		2	1	0	0 F054O001	Activated	START signal from MotStart	STR	7400
	54	E2	EV_NODAT		4	1	1	0 F054O002	Reset	TRIP signal from MotStart	TRP	7401
	54	E3	EV_NODAT		8	1	1	0 F054O002	Activated	TRIP signal from MotStart	TRP	7401
	54	E4	EV_NODAT		16	1	2	0 F054O003	Reset	STALL signal from MotStart	STL	7402
	54	E5	EV_NODAT		32	1	2	0 F054O003	Activated	STALL signal from MotStart	STL	7402
	54	E6	EV_NODAT		64	0	3	0 -	Off	Test mode of MotStart	INS	7403
	54	E7	EV_NODAT		128	0	3	0 -	On	Test mode of MotStart	INS	7403
			Default mask=		63							
/* 100062 / Rev E OV3Low */												
	62	E0	EV_3BIT_2		1	1	0	0 F062O001	Reset	START signal from 3U> stage	STR	8200
	62	E1	EV_3BIT_2		2	1	0	0 F062O001	Activated	START signal from 3U> stage	STR	8200
	62	E2	EV_3BIT_2		4	1	1	0 F062O002	Reset	TRIP signal from 3U> stage	TRP	8201
	62	E3	EV_3BIT_2		8	1	1	0 F062O002	Activated	TRIP signal from 3U> stage	TRP	8201
	62	E4	EV_NODAT		16	0	2	0 F062I004	Reset	BS1 signal of 3U> stage	BLK	8202
	62	E5	EV_NODAT		32	0	2	0 F062I004	Activated	BS1 signal of 3U> stage	BLK	8202
	62	E6	EV_NODAT		64	0	3	0 F062I005	Reset	BS2 signal of 3U> stage	BLK	8203
	62	E7	EV_NODAT		128	0	3	0 F062I005	Activated	BS2 signal of 3U> stage	BLK	8203
	62	E8	EV_NODAT		256	0	4	0 -	Off	Test mode of 3U> stage	INS	8204
	62	E9	EV_NODAT		512	0	4	0 -	On	Test mode of 3U> stage	INS	8204
			Default mask=		15							
/* 100063 / Rev D OV3High */												
	63	E0	EV_3BIT_2		1	1	0	0 F063O001	Reset	START signal from 3U>> stage	STR	8300
	63	E1	EV_3BIT_2		2	1	0	0 F063O001	Activated	START signal from 3U>> stage	STR	8300
	63	E2	EV_3BIT_2		4	1	1	0 F063O002	Reset	TRIP signal from 3U>> stage	TRP	8301
	63	E3	EV_3BIT_2		8	1	1	0 F063O002	Activated	TRIP signal from 3U>> stage	TRP	8301
	63	E4	EV_NODAT		16	0	2	0 F063I004	Reset	BS1 signal of 3U>> stage	BLK	8302
	63	E5	EV_NODAT		32	0	2	0 F063I004	Activated	BS1 signal of 3U>> stage	BLK	8302
	63	E6	EV_NODAT		64	0	3	0 F063I005	Reset	BS2 signal of 3U>> stage	BLK	8303
	63	E7	EV_NODAT		128	0	3	0 F063I005	Activated	BS2 signal of 3U>> stage	BLK	8303
	63	E8	EV_NODAT		256	0	4	0 -	Off	Test mode of 3U>> stage	INS	8304
	63	E9	EV_NODAT		512	0	4	0 -	On	Test mode of 3U>> stage	INS	8304
			Default mask=		15							
/* 100064 / Rev D UV3Low */												
	64	E0	EV_3BIT_2		1	1	0	0 F064O001	Reset	START signal from 3U< stage	STR	8400
	64	E1	EV_3BIT_2		2	1	0	0 F064O001	Activated	START signal from 3U< stage	STR	8400
	64	E2	EV_3BIT_2		4	1	1	0 F064O002	Reset	TRIP signal from 3U< stage	TRP	8401
	64	E3	EV_3BIT_2		8	1	1	0 F064O002	Activated	TRIP signal from 3U< stage	TRP	8401
	64	E4	EV_NODAT		16	0	2	0 F064I004	Reset	BS1 signal of 3U< stage	BLK	8402
	64	E5	EV_NODAT		32	0	2	0 F064I004	Activated	BS1 signal of 3U< stage	BLK	8402
	64	E6	EV_NODAT		64	0	3	0 F064I005	Reset	BS2 signal of 3U< stage	BLK	8403
	64	E7	EV_NODAT		128	0	3	0 F064I005	Activated	BS2 signal of 3U< stage	BLK	8403
	64	E8	EV_NODAT		256	0	4	0 -	Off	Test mode of 3U< stage	INS	8404
	64	E9	EV_NODAT		512	0	4	0 -	On	Test mode of 3U< stage	INS	8404
			Default mask=		15							

	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
/* 100065 / Rev D UV3High */												
	65	E0	EV_3BIT_2		1	1	0	0	F065O001	Reset	START signal from 3U<< stage	STR 8500
	65	E1	EV_3BIT_2		2	1	0	0	F065O001	Activated	START signal from 3U<< stage	STR 8500
	65	E2	EV_3BIT_2		4	1	1	0	F065O002	Reset	TRIP signal from 3U<< stage	TRP 8501
	65	E3	EV_3BIT_2		8	1	1	0	F065O002	Activated	TRIP signal from 3U<< stage	TRP 8501
	65	E4	EV_NODAT		16	0	2	0	F065I004	Reset	BS1 signal of 3U<< stage	BLK 8502
	65	E5	EV_NODAT		32	0	2	0	F065I004	Activated	BS1 signal of 3U<< stage	BLK 8502
	65	E6	EV_NODAT		64	0	3	0	F065I005	Reset	BS2 signal of 3U<< stage	BLK 8503
	65	E7	EV_NODAT		128	0	3	0	F065I005	Activated	BS2 signal of 3U<< stage	BLK 8503
	65	E8	EV_NODAT		256	0	4	0	-	Off	Test mode of 3U<< stage	INS 8504
	65	E9	EV_NODAT		512	0	4	0	-	On	Test mode of 3U<< stage	INS 8504
			Default mask=		15							
/* 100070 / Rev H SCVCS1 */												
	70	E0	EV_NODAT		1	1	0	0	F070O001	Reset	SC Due	ALA 9000
	70	E1	EV_NODAT		2	1	0	0	F070O001	Activated	SC Due	ALA 9000
	70	E2	EV_NODAT		4	1	1	0	F070O002	Reset	SC Ok	ALA 9001
	70	E3	EV_NODAT		8	1	1	0	F070O002	Activated	SC Ok	ALA 9001
	70	E4	EV_NODAT		16	1	2	0	F070O003	Reset	Alarm not passed	ALA 9002
	70	E5	EV_NODAT		32	1	2	0	F070O003	Activated	Alarm not passed	ALA 9002
	70	E6	EV_NODAT		64	1	3	0	F070O004	Reset	Alarm Command too long	ALA 9003
	70	E7	EV_NODAT		128	1	3	0	F070O004	Activated	Alarm Command too long	ALA 9003
			Default mask=		127							
/* 100071 / Rev G SCVCS2 */												
	71	E0	EV_NODAT		1	1	0	0	F071O001	Reset	SC Due	ALA 9100
	71	E1	EV_NODAT		2	1	0	0	F071O001	Activated	SC Due	ALA 9100
	71	E2	EV_NODAT		4	1	1	0	F071O002	Reset	SC Ok	ALA 9101
	71	E3	EV_NODAT		8	1	1	0	F071O002	Activated	SC Ok	ALA 9101
	71	E4	EV_NODAT		16	1	2	0	F071O003	Reset	Alarm not passed	ALA 9102
	71	E5	EV_NODAT		32	1	2	0	F071O003	Activated	Alarm not passed	ALA 9102
	71	E6	EV_NODAT		64	1	3	0	F071O004	Reset	Alarm Command too long	ALA 9103
	71	E7	EV_NODAT		128	1	3	0	F071O004	Activated	Alarm Command too long	ALA 9103
			Default mask=		127							
/* 100072 / Rev F Freq1St1 */												
	72	E0	EV_NODAT		1	1	0	0	F072O001	Reset	START1 signal from f>,f< St1	STR 9200
	72	E1	EV_NODAT		2	1	0	0	F072O001	Activated	START1 signal from f>,f< St1	STR 9200
	72	E2	EV_NODAT		4	1	1	0	F072O002	Reset	TRIP1 signal from f>,f< St1	TRP 9201
	72	E3	EV_NODAT		8	1	1	0	F072O002	Activated	TRIP1 signal from f>,f< St1	TRP 9201
	72	E4	EV_NODAT		16	1	2	0	F072O003	Reset	START2 signal from f>,f< St1	STR 9202
	72	E5	EV_NODAT		32	1	2	0	F072O003	Activated	START2 signal from f>,f< St1	STR 9202
	72	E6	EV_NODAT		64	1	3	0	F072O004	Reset	TRIP2 signal from f>,f< St1	TRP 9203
	72	E7	EV_NODAT		128	1	3	0	F072O004	Activated	TRIP2 signal from f>,f< St1	TRP 9203
	72	E8	EV_NODAT		256	0	4	0	F072I004	Reset	BS1 signal of f>,f< St1	BLK 9204
	72	E9	EV_NODAT		512	0	4	0	F072I004	Activated	BS1 signal of f>,f< St1	BLK 9204
	72	E10	EV_NODAT		1024	0	5	0	F072I005	Reset	BS2 signal of f>,f< St1	BLK 9205
	72	E11	EV_NODAT		2048	0	5	0	F072I005	Activated	BS2 signal of f>,f< St1	BLK 9205
	72	E12	EV_NODAT		4096	0	6	0	-	Off	Test mode of f>,f< St1	INS 9206
	72	E13	EV_NODAT		8192	0	6	0	-	On	Test mode of f>,f< St1	INS 9206
			Default mask=		255							
/* 100073 / Rev F Freq1St2 */												
	73	E0	EV_NODAT		1	1	0	0	F073O001	Reset	START1 signal from f>,f< St2	STR 9300
	73	E1	EV_NODAT		2	1	0	0	F073O001	Activated	START1 signal from f>,f< St2	STR 9300
	73	E2	EV_NODAT		4	1	1	0	F073O002	Reset	TRIP1 signal from f>,f< St2	TRP 9301
	73	E3	EV_NODAT		8	1	1	0	F073O002	Activated	TRIP1 signal from f>,f< St2	TRP 9301
	73	E4	EV_NODAT		16	1	2	0	F073O003	Reset	START2 signal from f>,f< St2	STR 9302
	73	E5	EV_NODAT		32	1	2	0	F073O003	Activated	START2 signal from f>,f< St2	STR 9302
	73	E6	EV_NODAT		64	1	3	0	F073O004	Reset	TRIP2 signal from f>,f< St2	TRP 9303
	73	E7	EV_NODAT		128	1	3	0	F073O004	Activated	TRIP2 signal from f>,f< St2	TRP 9303
	73	E8	EV_NODAT		256	0	4	0	F073I004	Reset	BS1 signal of f>,f< St2	BLK 9304
	73	E9	EV_NODAT		512	0	4	0	F073I004	Activated	BS1 signal of f>,f< St2	BLK 9304
	73	E10	EV_NODAT		1024	0	5	0	F073I005	Reset	BS2 signal of f>,f< St2	BLK 9305
	73	E11	EV_NODAT		2048	0	5	0	F073I005	Activated	BS2 signal of f>,f< St2	BLK 9305
	73	E12	EV_NODAT		4096	0	6	0	-	Off	Test mode of f>,f< St2	INS 9306
	73	E13	EV_NODAT		8192	0	6	0	-	On	Test mode of f>,f< St2	INS 9306
			Default mask=		255							











	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
/* 100117 / Rev C CUB1Cap */												
	117	E0	EV_NODAT		1	1	0	0 F117O001	Reset	START signal from CUB1Cap dl1 stage	STR	13700
	117	E1	EV_NODAT		2	1	0	0 F117O001	Activated	START signal from CUB1Cap dl1 stage	STR	13700
	117	E2	EV_NODAT		4	1	1	0 F117O002	Reset	TRIP signal from CUB1Cap dl1 stage	TRP	13701
	117	E3	EV_NODAT		8	1	1	0 F117O002	Activated	TRIP signal from CUB1Cap dl1 stage	TRP	13701
	117	E4	EV_NODAT		16	1	2	0 F117O003	Reset	CBFP signal from CUB1Cap	ALA	13702
	117	E5	EV_NODAT		32	1	2	0 F117O003	Activated	CBFP signal from CUB1Cap	ALA	13702
	117	E6	EV_NODAT		64	0	3	0 F117O004	Reset	ST_ALARM signal from CUB1Cap dl2 stage	STR	13703
	117	E7	EV_NODAT		128	0	3	0 F117O004	Activated	ST_ALARM signal from CUB1Cap dl2 stage	STR	13703
	117	E8	EV_NODAT		256	1	4	1 F117O005	Reset	ALARM signal from CUB1Cap dl2 stage	ALA	13704
	117	E9	EV_NODAT		512	1	4	0 F117O005	Activated	ALARM signal from CUB1Cap dl2 stage	ALA	13704
	117	E10	EV_NODAT		1024	0	5	0 F117I004	Reset	BS1 signal of CUB1Cap	BLK	13705
	117	E11	EV_NODAT		2048	0	5	0 F117I004	Activated	BS1 signal of CUB1Cap	BLK	13705
	117	E12	EV_NODAT		4096	0	6	0 F117I005	Reset	BS2 signal of CUB1Cap	BLK	13706
	117	E13	EV_NODAT		8192	0	6	0 F117I005	Activated	BS2 signal of CUB1Cap	BLK	13706
	117	E14	EV_NODAT		16384	0	7	0 -	Off	Test mode of CUB1Cap	INS	13707
	117	E15	EV_NODAT		32768	0	7	0 -	On	Test mode of CUB1Cap	INS	13707
			Default mask=		831							
/* 100118 / Rev D FuseFail */												
	118	E0	EV_NODAT		1	1	0	0 F118O001	Reset	Fuse failure	ALA	13800
	118	E1	EV_NODAT		2	1	0	0 F118O001	Activated	Fuse failure	ALA	13800
	118	E2	EV_NODAT		4	1	1	1 F118I002	Open	MCB position	POS	13801
	118	E3	EV_NODAT		8	1	1	0 F118I002	Closed	MCB position	POS	13801
	118	E4	EV_NODAT		16	0	2	0 F118I001	Reset	FuseFail blocked	BLK	13802
	118	E5	EV_NODAT		32	0	2	0 F118I001	Activated	FuseFail blocked	BLK	13802
	118	E6	EV_NODAT		64	0	3	0 F118V002	Off	Test mode of FuseFail	INS	13803
	118	E7	EV_NODAT		128	0	3	0 F118V002	On	Test mode of FuseFail	INS	13803
			Default mask=		15							
/* 100120 / Rev B COCB1 */												
	120	E0	EV_2BIT_1		1	1	0	1 F120V001	Open (10)	Breaker 1 position	POS	14000
	120	E1	EV_2BIT_1		2	1	0	0 F120V001	Close (01)	Breaker 1 position	POS	14000
	120	E2	EV_2BIT_1		4	1	0	0 F120V001	Faulty (11)	Breaker 1 position	POS	14000
	120	E3	EV_2BIT_1		8	1	0	0 F120V001	Middle (00)	Breaker 1 position	POS	14000
	120	E4	EV_1BIT		16	1	1	1 F120V031	Enabled	Breaker 1 open command	INS	14001
	120	E5	EV_1BIT		32	1	1	0 F120V031	Disabled	Breaker 1 open command	INS	14001
	120	E6	EV_1BIT		64	1	2	1 F120V030	Enabled	Breaker 1 close command	INS	14002
	120	E7	EV_1BIT		128	1	2	0 F120V030	Disabled	Breaker 1 close command	INS	14002
	120	E8	EV_1BIT		256	0	3	0 F120V034	Inactive	Breaker 1 invalid state	INS	14003
	120	E9	EV_1BIT		512	1	3	0 F120V034	Active	Breaker 1 invalid state	INS	14003
	120	E10	EV_NODAT		1024	1	4	0 -	Completed	Breaker 1 command sequence	INS	14004
	120	E11	EV_NODAT		2048	1	4	0 -	Started	Breaker 1 command sequence	INS	14004
	120	E12	EV_NODAT		4096	0	5	0 -	Deactivated	Breaker 1 open output	INS	14005
	120	E13	EV_NODAT		8192	1	5	0 -	Activated	Breaker 1 open output	INS	14005
	120	E14	EV_NODAT		16384	0	6	0 -	Deactivated	Breaker 1 close output	INS	14006
	120	E15	EV_NODAT		32768	1	6	0 -	Activated	Breaker 1 close output	INS	14006
	120	E16	EV_NODAT		65536	0	7	0 F120O003	Normal	Breaker 1 opening time	INS	14007
	120	E17	EV_NODAT		131072	1	7	0 F120O003	Alarm	Breaker 1 opening time	INS	14007
	120	E18	EV_NODAT		262144	0	8	0 F120O004	Normal	Breaker 1 closing time	INS	14008
	120	E19	EV_NODAT		524288	1	8	0 F120O004	Alarm	Breaker 1 closing time	INS	14008
	120	E20	EV_NODAT		1048576	0	9	0 F120O005	Normal	Breaker 1 inactive time	INS	14009
	120	E21	EV_NODAT		2097152	1	9	0 F120O005	Alarm	Breaker 1 inactive time	INS	14009
	120	E22	EV_NODAT		4194304	0	10	0 F120O006	Normal	Breaker 1 cycle count	INS	14010
	120	E23	EV_NODAT		8388608	1	10	0 F120O006	Alarm	Breaker 1 cycle count	INS	14010
	120	E24	EV_NODAT		16777216	0	11	0 -	Nack	Breaker 1 command status	INS	14011
	120	E25	EV_NODAT		33554432	0	11	0 -	Ack	Breaker 1 command status	INS	14011
	120	E26	EV_1BIT		67108864	0	12	1 F120V035	Inactive	Breaker 1 control blocking	INS	14012
	120	E27	EV_1BIT		134217728	1	12	0 F120V035	Active	Breaker 1 control blocking	INS	14012
	120	E28	EV_NODAT		268435456	0	13	0 -	Unsuccessful	Breaker 1 command status	CMS	14013
			Default mask=		145403647							

















	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
/* 100169 / Rev B MMIALAR8 */												
	169	E0	EV_NODAT		1	0	0	1	F169I001	Inactive	Alarm 8 status	INS 18900
	169	E1	EV_NODAT		2	1	0	0	F169I001	Active	Alarm 8 status	INS 18900
	169	E3	EV_NODAT		8	0	1	0	-	-	Alarm 8 acknowledge	INS 18901
			Default mask=		2							
/* 100181 / Rev C CMCU3 */												
	181	E0	EV_NODAT		1	1	0	1	F181O001	Off	Current input circuit alarm	ALA 20100
	181	E1	EV_NODAT		2	1	0	0	F181O001	On	Current input circuit alarm	ALA 20100
			Default mask=		1							
/* 100182 / Rev D CMVO3 */												
	182	E0	EV_NODAT		1	1	0	1	F182O001	Off	Input voltage circuit alarm	ALA 20200
	182	E1	EV_NODAT		2	1	0	0	F182O001	On	Input voltage circuit alarm	ALA 20200
			Default mask=		1							
/* 100184 / Rev B CMTIME1 */												
	184	E0	EV_NODAT		1	0	0	1	F184O001	Reset	Accumulated time 1 alarm	ALA 20400
	184	E1	EV_NODAT		2	1	0	0	F184O001	Activated	Accumulated time 1 alarm	ALA 20400
	184	E2	EV_NODAT		4	0	1	0	F184I001	Inactive	Accumulated time 1 measurement	INS 20401
	184	E3	EV_NODAT		8	1	1	0	F184I001	Active	Accumulated time 1 measurement	INS 20401
			Default mask=		2							
/* 100185 / Rev B CMTIME2 */												
	185	E0	EV_NODAT		1	0	0	1	F185O001	Reset	Accumulated time 2 alarm	ALA 20500
	185	E1	EV_NODAT		2	1	0	0	F185O001	Activated	Accumulated time 2 alarm	ALA 20500
	185	E2	EV_NODAT		4	0	1	0	F185I001	Inactive	Accumulated time 2 measurement	INS 20501
	185	E3	EV_NODAT		8	1	1	0	F185I001	Active	Accumulated time 2 measurement	INS 20501
			Default mask=		2							
/* 100186 / Rev B CMGAS1 */												
	186	E0	EV_NODAT		1	0	0	1	F186O001	Reset	Low gas density alarm	ALA 20600
	186	E1	EV_NODAT		2	1	0	0	F186O001	Activated	Low gas density alarm	ALA 20600
	186	E2	EV_NODAT		4	0	1	0	F186I001	Inactive	Low gas density warning	ALA 20601
	186	E3	EV_NODAT		8	1	1	0	F186I001	Active	Low gas density warning	ALA 20601
			Default mask=		2							
/* 100187 / Rev B CMBWEAR1 */												
	187	E0	EV_NODAT		1	0	0	1	F187O001	Reset	Breaker 1 electric wear alarm	ALA 20700
	187	E1	EV_NODAT		2	1	0	0	F187O001	Activated	Breaker 1 electric wear alarm	ALA 20700
			Default mask=		0							
/* 100188 / Rev B CMBWEAR2 */												
	188	E0	EV_NODAT		1	0	0	1	F188O001	Reset	Breaker 2 electric wear alarm	ALA 20800
	188	E1	EV_NODAT		2	1	0	0	F188O001	Activated	Breaker 2 electric wear alarm	ALA 20800
			Default mask=		0							
/* 100189 / Rev C CMSCHED */												
	189	E0	EV_NODAT		1	0	0	1	F189O001	Reset	Scheduled maintenance alarm	ALA 20900
	189	E1	EV_NODAT		2	1	0	0	F189O001	Activated	Scheduled maintenance alarm	ALA 20900
			Default mask=		0							
/* 100190 / Rev B CMSPRC1 */												
	190	E0	EV_NODAT		1	0	0	0	-	Inactive	Spring 1 charging motor	INS 21000
	190	E1	EV_NODAT		2	1	0	0	-	Active	Spring 1 charging motor	INS 21000
	190	E2	EV_NODAT		4	0	1	1	F190O002	Reset	Spring 1 max charging alarm	ALA 21001
	190	E3	EV_NODAT		8	1	1	0	F190O002	Activated	Spring 1 max charging alarm	ALA 21001
	190	E4	EV_NODAT		16	0	2	1	F190O003	Reset	Spring 1 min charging alarm	ALA 21002
	190	E5	EV_NODAT		32	1	2	0	F190O003	Activated	Spring 1 min charging alarm	ALA 21002
	190	E7	EV_NODAT		128	1	99	0	-	Activated	Spring 1 charge command	- 21099
	190	E8	EV_NODAT		256	0	3	0	F190I002	Uncharged	Spring 1 charge status	CMS 21003
	190	E9	EV_NODAT		512	1	3	0	F190I002	Charged	Spring 1 charge status	CMS 21003
			Default mask=		170							
/* 100191 / Rev B CMTCS1 */												
	191	E0	EV_NODAT		1	0	0	1	F191O001	Reset	Trip circuit superv. 1 alarm	ALA 21100
	191	E1	EV_NODAT		2	1	0	0	F191O001	Activated	Trip circuit superv. 1 alarm	ALA 21100
	191	E2	EV_NODAT		4	0	1	0	F191I002	Inactive	Trip circuit superv. 1 block	BLK 21101
	191	E3	EV_NODAT		8	1	1	0	F191I002	Active	Trip circuit superv. 1 block	BLK 21101
			Default mask=		2							





	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
		204 E32	EV_FLOAT		1	0	4	1 F204I001	High warning reset	U12	VOL	22404
		204 E33	EV_FLOAT;IQ=HW		2	0	4	0 F204I001	High warning activated	U12	VOL	22404
		204 E34	EV_FLOAT		4	0	5	1 F204I002	High warning reset	U23	VOL	22405
		204 E35	EV_FLOAT;IQ=HW		8	0	5	0 F204I002	High warning activated	U23	VOL	22405
		204 E36	EV_FLOAT		16	0	6	1 F204I003	High warning reset	U31	VOL	22406
		204 E37	EV_FLOAT;IQ=HW		32	0	6	0 F204I003	High warning activated	U31	VOL	22406
		204 E38	EV_FLOAT		64	0	4	0 F204I001	High alarm reset	U12	VOL	22404
		204 E39	EV_FLOAT;IQ=HA		128	0	4	0 F204I001	High alarm activated	U12	VOL	22404
		204 E40	EV_FLOAT		256	0	5	0 F204I002	High alarm reset	U23	VOL	22405
		204 E41	EV_FLOAT;IQ=HA		512	0	5	0 F204I002	High alarm activated	U23	VOL	22405
		204 E42	EV_FLOAT		1024	0	6	0 F204I003	High alarm reset	U31	VOL	22406
		204 E43	EV_FLOAT;IQ=HA		2048	0	6	0 F204I003	High alarm activated	U31	VOL	22406
		204 E44	EV_FLOAT		4096	0	4	0 F204I001	Low warning reset	U12	VOL	22404
		204 E45	EV_FLOAT;IQ=LW		8192	0	4	0 F204I001	Low warning activated	U12	VOL	22404
		204 E46	EV_FLOAT		16384	0	5	0 F204I002	Low warning reset	U23	VOL	22405
		204 E47	EV_FLOAT;IQ=LW		32768	0	5	0 F204I002	Low warning activated	U23	VOL	22405
		204 E48	EV_FLOAT		65536	0	6	0 F204I003	Low warning reset	U31	VOL	22406
		204 E49	EV_FLOAT;IQ=LW		131072	0	6	0 F204I003	Low warning activated	U31	VOL	22406
		204 E50	EV_FLOAT		262144	0	4	0 F204I001	Low alarm reset	U12	VOL	22404
		204 E51	EV_FLOAT;IQ=LA		524288	0	4	0 F204I001	Low alarm activated	U12	VOL	22404
		204 E52	EV_FLOAT		1048576	0	5	0 F204I002	Low alarm reset	U23	VOL	22405
		204 E53	EV_FLOAT;IQ=LA		2097152	0	5	0 F204I002	Low alarm activated	U23	VOL	22405
		204 E54	EV_FLOAT		4194304	0	6	0 F204I003	Low alarm reset	U31	VOL	22406
		204 E55	EV_FLOAT;IQ=LA		8388608	0	6	0 F204I003	Low alarm activated	U31	VOL	22406
		204 E57	EV_FLOAT		33554432	0	4	0 F204I001	Delta	U12	VOL	22404
		204 E59	EV_FLOAT		134217728	0	5	0 F204I002	Delta	U23	VOL	22405
		204 E61	EV_FLOAT		536870912	0	6	0 F204I003	Delta	U31	VOL	22406
			Default mask=		0							
/* 100205 / Rev E MEVO1A */												
		205 E0	EV_FLOAT		1	0	1	1 F205I001	High warning reset	Uo	VOL	22501
		205 E1	EV_FLOAT;IQ=HW		2	0	1	0 F205I001	High warning activated	Uo	VOL	22501
		205 E2	EV_FLOAT		4	0	1	0 F205I001	High alarm reset	Uo	VOL	22501
		205 E3	EV_FLOAT;IQ=HA		8	0	1	0 F205I001	High alarm activated	Uo	VOL	22501
		205 E5	EV_FLOAT		32	0	1	0 F205I001	Delta	Uo	VOL	22501
			Default mask=		0							
/* 100206 / Rev C MEVO3B */												
		206 E0	EV_FLOAT		1	0	1	1 F206I001	High warning reset	UL1	VOL	22601
		206 E1	EV_FLOAT;IQ=HW		2	0	1	0 F206I001	High warning activated	UL1	VOL	22601
		206 E2	EV_FLOAT		4	0	2	1 F206I002	High warning reset	UL2	VOL	22602
		206 E3	EV_FLOAT;IQ=HW		8	0	2	0 F206I002	High warning activated	UL2	VOL	22602
		206 E4	EV_FLOAT		16	0	3	1 F206I003	High warning reset	UL3	VOL	22603
		206 E5	EV_FLOAT;IQ=HW		32	0	3	0 F206I003	High warning activated	UL3	VOL	22603
		206 E6	EV_FLOAT		64	0	1	0 F206I001	High alarm reset	UL1	VOL	22601
		206 E7	EV_FLOAT;IQ=HA		128	0	1	0 F206I001	High alarm activated	UL1	VOL	22601
		206 E8	EV_FLOAT		256	0	2	0 F206I002	High alarm reset	UL2	VOL	22602
		206 E9	EV_FLOAT;IQ=HA		512	0	2	0 F206I002	High alarm activated	UL2	VOL	22602
		206 E10	EV_FLOAT		1024	0	3	0 F206I003	High alarm reset	UL3	VOL	22603
		206 E11	EV_FLOAT;IQ=HA		2048	0	3	0 F206I003	High alarm activated	UL3	VOL	22603
		206 E12	EV_FLOAT		4096	0	1	0 F206I001	Low warning reset	UL1	VOL	22601
		206 E13	EV_FLOAT;IQ=LW		8192	0	1	0 F206I001	Low warning activated	UL1	VOL	22601
		206 E14	EV_FLOAT		16384	0	2	0 F206I002	Low warning reset	UL2	VOL	22602
		206 E15	EV_FLOAT;IQ=LW		32768	0	2	0 F206I002	Low warning activated	UL2	VOL	22602
		206 E16	EV_FLOAT		65536	0	3	0 F206I003	Low warning reset	UL3	VOL	22603
		206 E17	EV_FLOAT;IQ=LW		131072	0	3	0 F206I003	Low warning activated	UL3	VOL	22603
		206 E18	EV_FLOAT		262144	0	1	0 F206I001	Low alarm reset	UL1	VOL	22601
		206 E19	EV_FLOAT;IQ=LA		524288	0	1	0 F206I001	Low alarm activated	UL1	VOL	22601
		206 E20	EV_FLOAT		1048576	0	2	0 F206I002	Low alarm reset	UL2	VOL	22602
		206 E21	EV_FLOAT;IQ=LA		2097152	0	2	0 F206I002	Low alarm activated	UL2	VOL	22602
		206 E22	EV_FLOAT		4194304	0	3	0 F206I003	Low alarm reset	UL3	VOL	22603
		206 E23	EV_FLOAT;IQ=LA		8388608	0	3	0 F206I003	Low alarm activated	UL3	VOL	22603
		206 E25	EV_FLOAT		33554432	0	1	0 F206I001	Delta	UL1	VOL	22601
		206 E27	EV_FLOAT		134217728	0	2	0 F206I002	Delta	UL2	VOL	22602
		206 E29	EV_FLOAT		536870912	0	3	0 F206I003	Delta	UL3	VOL	22603
			Default mask=		0							

	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
		206 E32	EV_FLOAT		1	0	4	1 F206I001	High warning reset	U12	VOL	22604
		206 E33	EV_FLOAT;IQ=HW		2	0	4	0 F206I001	High warning activated	U12	VOL	22604
		206 E34	EV_FLOAT		4	0	5	1 F206I002	High warning reset	U23	VOL	22605
		206 E35	EV_FLOAT;IQ=HW		8	0	5	0 F206I002	High warning activated	U23	VOL	22605
		206 E36	EV_FLOAT		16	0	6	1 F206I003	High warning reset	U31	VOL	22606
		206 E37	EV_FLOAT;IQ=HW		32	0	6	0 F206I003	High warning activated	U31	VOL	22606
		206 E38	EV_FLOAT		64	0	4	0 F206I001	High alarm reset	U12	VOL	22604
		206 E39	EV_FLOAT;IQ=HA		128	0	4	0 F206I001	High alarm activated	U12	VOL	22604
		206 E40	EV_FLOAT		256	0	5	0 F206I002	High alarm reset	U23	VOL	22605
		206 E41	EV_FLOAT;IQ=HA		512	0	5	0 F206I002	High alarm activated	U23	VOL	22605
		206 E42	EV_FLOAT		1024	0	6	0 F206I003	High alarm reset	U31	VOL	22606
		206 E43	EV_FLOAT;IQ=HA		2048	0	6	0 F206I003	High alarm activated	U31	VOL	22606
		206 E44	EV_FLOAT		4096	0	4	0 F206I001	Low warning reset	U12	VOL	22604
		206 E45	EV_FLOAT;IQ=LW		8192	0	4	0 F206I001	Low warning activated	U12	VOL	22604
		206 E46	EV_FLOAT		16384	0	5	0 F206I002	Low warning reset	U23	VOL	22605
		206 E47	EV_FLOAT;IQ=LW		32768	0	5	0 F206I002	Low warning activated	U23	VOL	22605
		206 E48	EV_FLOAT		65536	0	6	0 F206I003	Low warning reset	U31	VOL	22606
		206 E49	EV_FLOAT;IQ=LW		131072	0	6	0 F206I003	Low warning activated	U31	VOL	22606
		206 E50	EV_FLOAT		262144	0	4	0 F206I001	Low alarm reset	U12	VOL	22604
		206 E51	EV_FLOAT;IQ=LA		524288	0	4	0 F206I001	Low alarm activated	U12	VOL	22604
		206 E52	EV_FLOAT		1048576	0	5	0 F206I002	Low alarm reset	U23	VOL	22605
		206 E53	EV_FLOAT;IQ=LA		2097152	0	5	0 F206I002	Low alarm activated	U23	VOL	22605
		206 E54	EV_FLOAT		4194304	0	6	0 F206I003	Low alarm reset	U31	VOL	22606
		206 E55	EV_FLOAT;IQ=LA		8388608	0	6	0 F206I003	Low alarm activated	U31	VOL	22606
		206 E57	EV_FLOAT		33554432	0	4	0 F206I001	Delta	U12	VOL	22604
		206 E59	EV_FLOAT		134217728	0	5	0 F206I002	Delta	U23	VOL	22605
		206 E61	EV_FLOAT		536870912	0	6	0 F206I003	Delta	U31	VOL	22606
			Default mask=		0							
/* 100207 / Rev E MEPE7 */												
		207 E0	EV_FLOAT		1	0	1	1 F207I001	High warning reset	P3	APW	22701
		207 E1	EV_FLOAT;IQ=HW		2	0	1	0 F207I001	High warning activated	P3	APW	22701
		207 E2	EV_FLOAT		4	0	1	0 F207I001	High alarm reset	P3	APW	22701
		207 E3	EV_FLOAT;IQ=HA		8	0	1	0 F207I001	High alarm activated	P3	APW	22701
		207 E4	EV_FLOAT		16	0	2	1 F207I002	High warning reset	Q3	RPW	22702
		207 E5	EV_FLOAT;IQ=HW		32	0	2	0 F207I002	High warning activated	Q3	RPW	22702
		207 E6	EV_FLOAT		64	0	2	0 F207I002	High alarm reset	Q3	RPW	22702
		207 E7	EV_FLOAT;IQ=HA		128	0	2	0 F207I002	High alarm activated	Q3	RPW	22702
		207 E8	EV_FLOAT		256	0	1	0 F207I001	Low warning reset	P3	APW	22701
		207 E9	EV_FLOAT;IQ=LW		512	0	1	0 F207I001	Low warning activated	P3	APW	22701
		207 E10	EV_FLOAT		1024	0	1	0 F207I001	Low alarm reset	P3	APW	22701
		207 E11	EV_FLOAT;IQ=LA		2048	0	1	0 F207I001	Low alarm activated	P3	APW	22701
		207 E12	EV_FLOAT		4096	0	2	0 F207I002	Low warning reset	Q3	RPW	22702
		207 E13	EV_FLOAT;IQ=LW		8192	0	2	0 F207I002	Low warning activated	Q3	RPW	22702
		207 E14	EV_FLOAT		16384	0	2	0 F207I002	Low alarm reset	Q3	RPW	22702
		207 E15	EV_FLOAT;IQ=LA		32768	0	2	0 F207I002	Low alarm activated	Q3	RPW	22702
		207 E17	EV_FLOAT		131072	0	1	0 F207I001	Delta	P3	APW	22701
		207 E19	EV_FLOAT		524288	0	2	0 F207I002	Delta	Q3	RPW	22702
		207 E21	EV_FLOAT		2097152	0	3	0 -	Delta	S3	TPW	22703
		207 E23	EV_FLOAT		8388608	0	4	1 F207I003	Delta	DPF	DPF	22704
		207 E25	EV_FLOAT		33554432	0	5	0 F207V414	Delta	Active energy	RFE	22705
		207 E27	EV_FLOAT		134217728	0	6	0 F207V415	Delta	Active reverse energy	RRE	22706
		207 E29	EV_FLOAT		536870912	0	7	0 F207V416	Delta	Reactive energy	AFE	22707
		207 E31	EV_FLOAT		2147483648	0	8	0 F207V417	Delta	Reactive reverse energy	ARE	22708
			Default mask=		0							
/* 100208 / Rev D MEFR1 */												
		208 E0	EV_FLOAT		1	0	1	1 F208I001	High warning reset	Frequency	FRQ	22801
		208 E1	EV_FLOAT;IQ=HW		2	0	1	0 F208I001	High warning activated	Frequency	FRQ	22801
		208 E2	EV_FLOAT		4	0	1	0 F208I001	High alarm reset	Frequency	FRQ	22801
		208 E3	EV_FLOAT;IQ=HA		8	0	1	0 F208I001	High alarm activated	Frequency	FRQ	22801
		208 E4	EV_FLOAT		16	0	1	0 F208I001	Low warning reset	Frequency	FRQ	22801
		208 E5	EV_FLOAT;IQ=LW		32	0	1	0 F208I001	Low warning activated	Frequency	FRQ	22801
		208 E6	EV_FLOAT		64	0	1	0 F208I001	Low alarm reset	Frequency	FRQ	22801
		208 E7	EV_FLOAT;IQ=LA		128	0	1	0 F208I001	Low alarm activated	Frequency	FRQ	22801
		208 E9	EV_FLOAT		512	0	1	0 F208I001	Delta	Frequency	FRQ	22801
			Default mask=		0							









	Channel	Code	Values	Weighting coefficient	Default	IEC address	GI Table	DB name	Event State	Event Reason	RX	Address
		230	E32	EVENT230	1	0	16	0 -	E32	Customer event	INS	25016
		230	E33	EVENT230	2	0	16	0 -	E33	Customer event	INS	25016
		230	E34	EVENT230	4	0	17	0 -	E34	Customer event	INS	25017
		230	E35	EVENT230	8	0	17	0 -	E35	Customer event	INS	25017
		230	E36	EVENT230	16	0	18	0 -	E36	Customer event	INS	25018
		230	E37	EVENT230	32	0	18	0 -	E37	Customer event	INS	25018
		230	E38	EVENT230	64	0	19	0 -	E38	Customer event	INS	25019
		230	E39	EVENT230	128	0	19	0 -	E39	Customer event	INS	25019
		230	E40	EVENT230	256	0	20	0 -	E40	Customer event	INS	25020
		230	E41	EVENT230	512	0	20	0 -	E41	Customer event	INS	25020
		230	E42	EVENT230	1024	0	21	0 -	E42	Customer event	INS	25021
		230	E43	EVENT230	2048	0	21	0 -	E43	Customer event	INS	25021
		230	E44	EVENT230	4096	0	22	0 -	E44	Customer event	INS	25022
		230	E45	EVENT230	8192	0	22	0 -	E45	Customer event	INS	25022
		230	E46	EVENT230	16384	0	23	0 -	E46	Customer event	INS	25023
		230	E47	EVENT230	32768	0	23	0 -	E47	Customer event	INS	25023
		230	E48	EVENT230	65536	0	24	0 -	E48	Customer event	INS	25024
		230	E49	EVENT230	131072	0	24	0 -	E49	Customer event	INS	25024
		230	E50	EVENT230	262144	0	25	0 -	E50	Customer event	INS	25025
		230	E51	EVENT230	524288	0	25	0 -	E51	Customer event	INS	25025
		230	E52	EVENT230	1048576	0	26	0 -	E52	Customer event	INS	25026
		230	E53	EVENT230	2097152	0	26	0 -	E53	Customer event	INS	25026
		230	E54	EVENT230	4194304	0	27	0 -	E54	Customer event	INS	25027
		230	E55	EVENT230	8388608	0	27	0 -	E55	Customer event	INS	25027
		230	E56	EVENT230	16777216	0	28	0 -	E56	Customer event	INS	25028
		230	E57	EVENT230	33554432	0	28	0 -	E57	Customer event	INS	25028
		230	E58	EVENT230	67108864	0	29	0 -	E58	Customer event	INS	25029
		230	E59	EVENT230	134217728	0	29	0 -	E59	Customer event	INS	25029
		230	E60	EVENT230	268435456	0	30	0 -	E60	Customer event	INS	25030
		230	E61	EVENT230	536870912	0	30	0 -	E61	Customer event	INS	25030
		230	E62	EVENT230	1073741824	0	31	0 -	E62	Customer event	INS	25031
		230	E63	EVENT230	2147483648	0	31	0 -	E63	Customer event	INS	25031
				Default mask=	0							
/* CH231 / Rev B CH231 */												
		231	E0	EV_NODAT	1	1	0	0 -	problem	LON communication	INS	25100
				Default mask=	0							
/* 100512 / Rev E PQCU3H */												
		512	E0	EV_NODAT	1	1	0	0 F512O001	Reset	PQCU3H:Harmonic limit	ALA	53200
		512	E1	EV_NODAT	2	1	0	0 F512O001	Exceeded	PQCU3H:Harmonic limit	ALA	53200
		512	E2	EV_INT16	4	1	1	0 F512O002	Exceeded	PQCU3H:Cumulative limit	ALA	53201
		512	E3	EV_NODAT	8	1	2	0 -	On	PQCU3H:Obs. period near end	OUT	53202
		512	E4	EV_NODAT	16	1	3	0 -	On	PQCU3H:Obs. period ended	OUT	53203
				Default mask=	15							
/* 100513 / Rev E PQVO3H */												
		513	E0	EV_NODAT	1	1	0	0 F513O001	Reset	PQVO3H:Harmonic limit	ALA	53300
		513	E1	EV_NODAT	2	1	0	0 F513O001	Exceeded	PQVO3H:Harmonic limit	ALA	53300
		513	E2	EV_INT16	4	1	1	0 F513O002	Exceeded	PQVO3H:Cumulative limit	ALA	53301
		513	E3	EV_NODAT	8	1	2	0 -	On	PQVO3H:Obs. period near end	OUT	53302
		513	E4	EV_NODAT	16	1	3	0 -	On	PQVO3H:Obs. period ended	OUT	53303
				Default mask=	15							