



INTEGRATOR'S GUIDE

# Entellisys™ 5.6

## Low voltage switchgear





# Table of contents

<b>04</b>	<b>Warranty and general information</b>
<b>05 – 13</b>	<b>Control features</b>
<b>14 – 20</b>	<b>Entellisys status definitions</b>
<b>21 – 25</b>	<b>Modbus® protocol implementation</b>
<b>26 – 81</b>	<b>Modbus memory map</b>
<b>82 – 87</b>	<b>Modbus memory map format codes</b>

# Warranty and general information

## Hazard classifications

The following important highlighted information appears throughout this document to warn of potential hazards or to call attention to information that clarifies a procedure.

Carefully read all instructions and become familiar with the devices before trying to install, operate, service or maintain this equipment.



**DANGER**

**Danger:** Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING**

**Warning:** Indicates a hazardous situation that, if not avoided, could result in death or serious injury.



**CAUTION**

**Caution:** Indicates that if the hazard is not avoided could result in minor or moderate injury.



**NOTICE**

**Notice:** Is used to notify of practices not related to personal injury.

## Trademarks

All third-party trademarks are the property of their respective owners.

## Warranty

This document is based on information available at the time of publication. While efforts have been made to ensure accuracy, the information contained herein does not cover all details or variations in hardware and software, nor does it provide for every possible contingency in connection with installation, operation, and maintenance.

Features may be described herein that are not present in all hardware and software systems.

ABB assumes no obligation of notice to holders of this document with respect to changes subsequently made. ABB makes no representation or warranty, expressed, implied, or statutory, with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein.

No warranties of merchantability or fitness for purpose shall apply. Contact your local sales office if further information is required concerning any aspect of Entellisys 5.6 operation or maintenance.

Entellisys™, EntelliGuard™, EntelliGuard™ E and FlexLogic™ are trademarks of ABB.

Modbus RTU is a registered trademark of AEG Schneider Automation.

## How to contact us

Please have your Entellisys System Summary # and sales order/shop order from the drawings or name plate ready when calling.

The summary number can also be found on the Entellisys HMI on the System Health Screen by clicking on the Job info button.

Warranty (post sales service): 1-888-437-3765  
Technical support and aftermarket parts (non-warranty): 1-888-434-7378

Additional information: [www.abb.com/lowvoltage](http://www.abb.com/lowvoltage)

# Control features

Entellisys CPUs provide Voltage, Current, Power, breaker, discrete I/O status and control for third-party integrators. Allowing integrators to utilize the power of Entellisys for paralleling, load shedding or other power monitoring/control applications. The five main features are:

- IEC61850 (GOOSE I/O): A subset of the IEC 61850 standard and is used to transmit and receive discrete and analog information between devices. In Entellisys, GOOSE is implemented to communicate discrete bits of information only – status or commands – to other IEC 61850 GOOSE compliant devices (See 1VAL107701-MB)
- PLC Inputs: Provides external control inputs into FlexLogic
- Restricted Breaker Control: Limits the ability for Entellisys HMIs or other Modbus devices to issue Open, Close or Trip commands to breakers
- External Control Transfer: Provides the ability for an external supervisory controller to dictate which CPU will run as the master
- System Status: Provides status of all breakers and protective relays

Both CPUA and CPUB are configured to operate as Modbus TCP servers and can service up to 4 devices on port 502 including any Remote HMI workstations. Remote HMI workstations are customer owned computers running the Entellisys Remote HMI Interactive or Viewer software.

**NOTICE**

**NOTICE:** All panel mounted HMI touchscreens are designed to operate on a different port and are not included as one of the port 502 devices.

The Entellisys CPU recognizes one of the three available Modbus tables - the input register table. The Entellisys CPU also recognizes 3 Modbus function codes: 04, 06 and 16. (See page 21).

**Table 1: Modbus function codes**

Function Code	Action	Supported	Table
01	Read Multiple	No	Discrete Coils (read-write)
02	Read Multiple	No	Discrete Inputs (read-only)
03	Read Multiple	No	Output Holding Registers
04	Read Multiple	Yes	Input Registers
05	Write Single	No	Discrete Coils
06	Write Single	Yes	Input Registers
15 (0F)	Write Multiple	No	Discrete Coils
16 (10)	Write Multiple	Yes	Input Registers

**CAUTION**

**CAUTION:** Although the CPU protects critical areas, erroneous write commands may affect the performance of the gear.

**PLC inputs**

PLC inputs provide the ability to manipulate FlexLogic execution. There are 256 PLC inputs, each of which have a corresponding operand that is accessible in FlexLogic. These inputs can be used to drive discrete output, begin a programmed FlexLogic sequence or operate a breaker directly.

**Steps to sending a PLC input to Entellisys**

1. Configure the PLC Inputs in Entellisys: See Configuration on page 7.
2. Program the PLC: The PLC or other third-party Modbus client must be programmed to write to specific bits in the PLC Inputs State registers in the CPU Modus memory map starting at DC00. See PLC Input States (16 items) on page 79. To write to a PLC input:

- a. Determine which byte contains the PLC input to be updated. (See Figure 1-2)
  - b. Read the current register value.
  - c. Apply a bit mask to update only relevant bits.
  - d. Write back to the register.
3. Test: From the third-party Modbus client, write to each PLC input one at a time and verify that the correct PLC input has been toggled. See Status on page 7.
  4. Program FlexLogic: PLC Inputs must now be programmed. See 1VAL107701-MB Entellisys Installation, operations and maintenance manual for more information on FlexLogic programming.
  5. Test FlexLogic: FlexLogic changes must be tested.

#### PLC inputs registers holding state information

Each bit of the “PLC Input States” register represents one PLC input. Bit value 0 indicates the corresponding PLC input is in off state; and bit value is 1 indicating corresponding PLC input is in on state. See Table 2.

Table 2: PLC input states register format

PLC Input States register	PLC Input States bit field	PLC Input X
1	0	1
	1	2
	2	3
	...	...
	15	16
2	0	17
	1	18
	...	...
...		
16	0	241
	1	242
	...	...
	15	256

#### Bit order

All 256 PLC inputs are stored in 16, 2 byte unsigned integer registers. The bit information is stored in the 2-byte register in little-endian format. I.e. PLC input 1 = least significant bit. Table 3 lists several examples to demonstrate how the bits are packed into each register.

Table 3: PLC input examples

PLC Inputs On	Registers	Values	Binary
1 and 3	DC00	5	0000 0000 0000 0101
1, 3 and 16	DC00	32773	1000 0000 0000 0101
1, 3 and 20	DC00, DC00+1	5, 8	0000 0000 0000 0101 / 0000 0000 0000 1000

#### Example:

A third-party Modbus TCP client needs to be programmed to turn on PLC 23 which will, in turn, be programmed in FlexLogic to operate a breaker.

1. Determine which register PLC Input#23 resides: 2nd register, 7th bit. 23-16=7.
2. Read DC01. Returns 32773
3. There are several other inputs that are configured, so a mask must be applied to manipulate just PLC input 23  
Original value: 1000 0000 0000 0101 (32773)  
Apply Mask  
To turn on PLC input 23, use the OR operation: OR 0000 0000 0100 0000 (64)  
To turn off PLC input 23, use the AND operation: AND 1111 1111 1011 1111 (65471)  
Write the result: 1000 0000 0100 0101 (32837)
4. Write 32837 to register DC01

#### Events

If the “Events” parameter for the PLC Input is enabled, an event will be logged in the Events screen when the state has changed. 'x' in the text of event is a placeholder for number from range 1 to 256. Source of the events reports the CPU affected.


“PLC Input x On” - logged when PLC Input transitioned from low to high state.

“PLC Input x Off” - logged when PLC Input transitioned from high to low state.

- 01 PLC Input configuration screen
- 02 PLC Input States register format

**Configuration**

User must enable each PLC Input from the PLC Input screen (Main Menu, User Settings, Control).



— 01

**Function:** Controls whether the input is either enabled or disabled. When input is disabled, FlexLogic always reads its state as low. If input is enabled, FlexLogic reads the state from corresponding Modbus register.


**Events:** When enabled, if there is transition of state, an event corresponding to the direction of the transition will be logged.

**NOTICE**

**NOTICE:** The PLC input states are lost during a CPU power cycle event.

**Status**

To view a snapshot of the PLC input states from the HMI, open the PLC Input State screen (Main Menu, User Settings, Control). Click refresh if update the status.



— 02

**Breaker control**

In addition to PLC inputs, Modbus TCP clients can directly control the breakers by issuing breaker commands.

Because the Entellisys CPU employs only one Modbus table, breaker commands are sent to input registers rather than input coils. To send a command, a “1” must be written to the appropriate register.

Command for all breakers are relayed down to the messenger at the next protection pass, which occurs every 1/2 cycle.

**NOTICE**

**NOTICE:** The third-party modbus client must send the write command to both CPUs to ensure the command reaches the Messenger.

The breaker command registers for all 30 breakers begin at address 4CD6 and repeating for each of up to 30 breakers. See Table 54: Modbus memory map for details and memory locations.

**Table 4: Available breaker commands**

Register offset from 4CD6	Command
0	Open Breaker 1
1	Close Breaker 1
2	Trip Breaker 1
3	Clear Energy on Breaker 1
5	Breaker 1 Remote Lockout Enabled
6	Breaker 1 Remote Lockout Reset

**Modbus security**

For added security, a “Command Password” can be configured in the HMI. If set, the breaker command registers, as with all Entellisys command registers, will require the password to be sent first before the command. See Modbus Security on page 18 for more details on implementation. See 1VAL107701-MB Entellisys Installation, operations, and maintenance manual for configuration details.

### Restricted breaker control

In systems with certain supervisory control schemes, such as a paralleling gear application, it may be necessary to deny breaker control from the user or from other Modbus TCP clients.

Using the Restricted Breaker Control feature, a code can be added for open, close and trip operations for selected breakers. Each function (open/close/trip) can be configured independently for a selected breaker. When Restricted Breaker Control is enabled for a particular breaker, normal command registers are disabled and the CPU will expect the pre-configured code to be written to a different register for the respective breaker for open, close or trip commands.

### NOTICE

**NOTICE:** Restricted breaker control does NOT interfere with protective relays or FlexLogic and their ability to operate the breaker.

**Enabling restricted breaker control:** See Operation on page 9

### Events:

Following events are issued when a restricted breaker receives either a open, close or trip command.

- Breaker Open/Close/Trip Command Restricted Control Received: CPU acknowledged that the “SRC X Open/Close/Trip Breaker By Restricted Control” register received the correct command code
- Breaker Open/Close/Trip Cmd Restricted Cntrl Incorrect Code: CPU reported that the “SRC X Open/Close/Trip Breaker By Restricted Control” register received the incorrect command code
- Breaker Open/Close/Trip Cmd Restricted Control Not Enabled: CPU reported that the “SRC X Open/Close/Trip Breaker By Restricted Control” register received a command but the Restricted Breaker Control is disabled
- Breaker Open/Close/Trip Command Restricted Control Enabled: CPU acknowledged that the normal Open/Close/Trip command was rejected because the associated command was restricted for the breaker (See Setup on page 8).

### Restricted operation: (Restricted command enabled)

For restricted operations, the SRC X Node Command Registers in Table 54 are ignored and the CPU will only send a open, close and trip command to a messenger if the value written to SRC X Restricted Breaker Control Registers in Table 54 match the code entered for the command in question in the “Restricted Breaker Control” setting screen (See Setup in Figure 03).

### Setup

Navigate to the “Restricted Breaker Control” tab from the Main Menu, Maintenance screen - administrative login is required.

Breaker Name	Restricted Open	Restricted Close	Restricted Trip
Breaker 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Breaker 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 11	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 12	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 13	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 14	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 16	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 17	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Breaker 18	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

### Open / Close and trip code text boxes

Enter the code that is required to operate the associated breaker(s) in restricted mode. The default value for the Open/Close/Trip code is “2.” Allowable values are from 2 to 65535.

### Breaker operation matrix

Check the operations per breaker which require restricted control.

### NOTICE

**NOTICE:** Restricting operations will prevent the HMI from sending said actions to the respective breaker(s).


### CPU external control transfer

Entellisis is designed with redundant CPUs - both CPUs run protection functions simultaneously, however, the CPU control redundancy scheme utilizes primary/hot backup redundancy approach. By default, CPU A is the primary and CPU B is the backup.

The primary runs as the active CPU and the backup runs as the inactive CPU. The active CPU has contact outputs and circuit breaker control commands actuated, and the inactive CPU has contact outputs and circuit breaker control commands blocked. Only one CPU can be active at any given time. Modbus register FlexLogic Active, address 9588, holds 1 when the CPU is active and holds 0 when the CPU is inactive.

Internally Entellisys, depending on the system state, will determine which CPU should be running as the active CPU and, if necessary, automatically hand off control to optimize the performance of the gear.

In an application with a supervisory control structure, the third-party Modbus TCP supervisory client will communicate to both CPUs but in the event that it cannot communicate to one of the CPUs, it will need to force the remaining CPU to operate as and continue to operate as the active CPU.



Contact ABB for additional information on a specific redundant network application.

To effectively employ the CPU External Control Transfer into a supervisory control schema, the supervisory controller must continuously monitor the state of the communication and issue commands based on the Application guidelines (page 10).

**CAUTION**

**CAUTION:** Redundant I/O must be used if contact inputs or outputs are being used in a FlexLogic control application.

**Events:**

- **CPU external control transfer command received:** CPU received a “CPU External Control Transfer” command
- **CPU control transfer return to auto command rcvd:** “CPU Return To Auto Control Transfer” command
- **CPUx assumes control logic by external command:** CPU has executed the “CPU External Control Transfer” command and assumed active control
- **CPUx relinquishes control logic by external cmd:** CPU relinquishes control after the client issues “CPU Return To Auto Control Transfer” command or other CPU requests this CPU to relinquish control

**Function enable**

The CPU External Control Transfer function can only be enabled by the factory. When disabled, the associated modbus command registers and FlexLogic elements remain low and ignore all write operations.

**Operation**

The only interface the user has for this function is through Modbus TCP.

**Command Registers**

- **CPU external control transfer** - Writing a “1” to this register will force the CPU to become the active CPU and begin executing FlexLogic. This process will take up to 150ms (180ms for 50Hz system)
- **CPU return to auto control transfer** - Writing a “1” to this register will return the CPU back to normal operation. Return to automatic control transfer process will take up to 250ms (300ms for 50Hz system)

### Status registers

- **CPU external control transfer mode enable:** Indicates that the function is enabled and ready
- **Main task heart beat:** This is a new register to indicate that the main task is running. Every time the main task is executed (every half cycle), this register value is incremented by one, from 1 to 65535. When the register overflows, it will reset to 1. If the main task is not running, this register is not incremented but a client can still read the register value. If the main task was never started, this register will remain zero
- **Active flexlogic control:** Indicates the active CPU
- **Flexlogic redundancy mode:** Indicates the CPU control transfer mode. There are two modes: CPU Auto Control Transfer Mode (“0”) and CPU External Control Transfer Mode (“1”)

### Details:

- When a CPU receives an External Control Transfer command, it will request the other CPU to relinquish control. Once the other CPU relinquishes control, the commanded CPU will assume control and set the Active FlexLogic Control state high
- Any External Control Transfer command requires a complementary Return to Auto Command to resume normal operation
- If both CPUs have received an External Control Transfer command, normal operation will only resume after both CPUs have received the Return to Auto command

### NOTICE

**NOTICE:** All protection relays will continue operating on both CPUs in a fully redundant fashion independent of the External Control feature.

### Application

The third-party supervisory control application must be programmed to monitor the health of the communication and determine the active CPU.

#### 1. Verify that “External Control Transfer is enabled:

Read the CPU External Control Transfer Enabled register (95A4). Ensure that this feature is enabled before proceeding.

2. **Determine communication status:** Continuously read the Main Task Heart Beat register (02FF) from both CPUA and CPUB. If the “Main Task Heart Beat” is incrementing, the CPU is online and running. If the “Main Task Heart Beat” is not incrementing, then the Entellisys firmware is not running.

3. **Determine the active CPU:** If the CPU is online and running, read the FlexLogic Active register (9588) from both CPUs. The active CPU will return a “1.”
4. **Determine the “External control transfer mode”:** Read the Flexlogic Redundancy Mode register (959D) to determine the mode.
5. **Command case:** There are four conditions that require the client to force a CPU to become the active CPU.
  - a. If only CPU A is online and its FlexLogic is not active, then the client will command CPU A to take control. After the system returns to normal, the client must command CPU A to Return to Auto Control Transfer.
  - b. If only CPU B is online and its FlexLogic is not active, then the client will command CPU B to take control. After the system returns normal, the client must command CPU B to Return to Auto Control Transfer.
  - c. If both CPU A and CPU B are online and neither are active, then the client will command either CPU A or CPU B to take control. This condition is only caused by a configuration error and must be corrected by a ABB field service engineer. After the system has been restored to normal, the client must command the active CPU to Return to Auto Control Transfer.
  - d. If both CPU A and CPU B are on-line AND if the Flexlogic Redundancy Mode register on either CPU A or CPU B is greater than 0 then return to Auto by sending each CPU a Return to Auto Control Transfer command.

### FlexLogic

New protection elements have been added to FlexLogic to report the status of the Control Transfer function.

- **CPU control active CPU A:** High when CPU A is the active CPU either by Entellisys or an external device
- **CPU control active CPU B:** High when CPU B is the active CPU either by Entellisys or an external device
- **CPU external control transfer:** High when the active CPU is determined by an external device through “External Control Transfer.”

- I/O health OK:** This new FlexLogic protection element was added to enable the customer to use the state of the Discrete I/O subsystem (PMC or Remote I/O) to determine actions to take in the FlexLogic program. If it is a PMC system, I/O health OK is False if the number of detected PMC cards does not match the number of configured PMC cards. It is True otherwise. If it is a Remote I/O system, I/O Health OK is False if: The number of detected Remote I/O modules does not match the number of configured Remote I/O modules, There is a communication error with any of the Remote I/O stations, There is a functional error with any of the bus couplers/I/O modules Otherwise, I/O Health OK is True

**Example:**

Update VOs to display the Active CPU and indicate the External Control Transfer mode.

- Reserve 3 spare VOs and add the FlexLogic code shown in Figure 5.
- Add indicators to the HMI control screen and map them to their associated VOs.

Flex Logic Entry	Type	Symbol	Instance
Flex Entry 1	Protection Element	CPU CONTROL ACTIVE CPU A	NONE
Flex Entry 2	Write Virtual Output(Assign)	CPU A Control Active (VO 1)	NONE
Flex Entry 3	Protection Element	CPU CONTROL ACTIVE CPU B	NONE
Flex Entry 4	Write Virtual Output(Assign)	CPU B Control Active (VO 2)	NONE
Flex Entry 5	Protection Element	CPU EXTERNAL CONTROL TR	NONE
Flex Entry 6	Write Virtual Output(Assign)	CPU External Control Transf	NONE
Flex Entry 7	End of List		
Flex Entry 8	End of List		
Flex Entry 9	End of List		

**Real time indication**

The current active CPU and the External Control Transfer Mode status are displayed at the bottom of the FlexLogic Editor widow.

**Modbus security**

If Modbus security has been configured (See Page 50 in 1VAL107701-MB document), then Modbus clients must write the pre-configured password to either the Command Password Entry or Setting Password Entry registers before sending commands or updating settings on each CPU. The configured passwords are encrypted and stored on the CPU.

**Operation**

COMMAND and SETTING passwords each have a 30-minute timer. Each timer starts when you enter the particular password, and is restarted whenever you “use” it.

For example, writing a setting restarts the SETTING password timer and writing a command register or forcing a coil restarts the COMMAND password timer. The value read at memory location 02A8 can be used to confirm whether a COMMAND password is enabled or disabled (0 for Disabled). The value read at memory location 02A9 can be used to confirm whether a SETTING password is enabled or disabled.

COMMAND or SETTING password security access is restricted to the particular port or particular TCP/IP connection on which the entry was made. Passwords must be entered when accessing the relay through other ports or connections, and the passwords must be reentered after disconnecting and reconnecting on TCP/IP.

**Implementation**

To write a breaker 1 open command to a CPU with a command password preset to “1234” the following must be coded at the Modbus TCP client:

- Enter command mode: Write “1234” to memory location 02A4 (Command Password Entry).
- Read memory location 02A8 (Command Password Status) to verify the password was accepted.
- Write “1” to location 4CD6 (SRC x Open Breaker in Table 54).
- Exit command mode: Write “0” to memory location 02A4 (Command Password Entry). Similarly, the Setting Password Entry register in Table 54 is set up at memory location 02A6. To gain SETTING level security access, the SETTING password must be entered at memory location 02A6. The entered SETTING password must match the current SETTING password setting to change settings.


—  
06  
Alarm state transition diagram

—  
07  
Entellisys Pickup Alarm and Status Timing Diagram. The alarm bits stay high only while the breaker is opening and is clearing the fault. As soon as the fault is cleared, the relay will drop out. The acknowledge bit will persist.

**Interfacing to the alarm handler**

The Source Vectors for Alarms on page 61 is a set of registers beginning at 0428 provides the means to interface to each CUP's Alarm Handler functionality. Each pair of 32-bit values represent the current state (read only) and the acknowledge setting (read/write) for each alarm type. Each value represents the states for all of the circuit breakers in the system as denoted in Format Code F722, one bit for each. A 1 in the bit field position for a given circuit breaker in the state register indicates that the alarm condition is currently active, while a 0 indicates the condition is not currently active.

When a condition passes from inactive to active, the corresponding ACK bit in the next register will be set to 1. At this point an external program may acknowledge the alarm by writing a 0 to that bit location. It is important for the external program to first read the ACK register and mask the new value such that the states represented by the other bits remain intact. The following state table describes how the HMI interfaces with the CPU to update its indicators.




—  
06

**Example of long time / short time pickup alarm status in third-party supervisory systems**

In Entellisys there are many alarms including LT and ST pickup. An alarm will be active for as long as the condition exists. The Acknowledge will persist until the user interacts with the HMI. (See Figure 07)

In the case of trip alarms such as ST or LT Trip Status the alarm bit will only be active for the period of time between trip and dropout. Often only a few milliseconds in duration while the breaker is opening. During that time, however, it will set both the Alarm and its associated Acknowledge bit high.




—  
07

**Implementation**

The alarm registers are listed in Table 54. They are defined as data format code F722 is defined as 2 registers containing breaker status for breaker 1 – 30. (See Section Modbus memory map format codes)

In Figure 08, the bits of the two registers are arranged left to right. In the example below, breaker 1 (right most bit) and 30 (3rd from the left) tripped on ST, thus the **ST Ack and ST Trip Alarm** registers will be updated to reflect the bit pattern below.


For example, the **LT Over current Trip Alarm State** is two registers long. The first, register x0464, contains information on breakers 17-30 and the second, register x0465, contains information on breakers 1-16.



—  
08

The **ST Trip Alarm State** registers will only reflect the Trip condition while the breaker is opening. During that time, the ST Trip Alarm state (x0468 and x0469) will read 8192 and 1 as will and ST Ack registers.

After the fault has cleared and the Relays have dropped out, the ST Trip Alarm registers will clear and the Acknowledge will persist.



—  
09

**PLC implementation**

The alarm status is updated and cleared quickly (within 50ms), so a Modbus client will not be able to detect the trip alarm with any reliability. Therefore, for most relays, third-party Modbus clients should read the Acknowledge registers.

When an event has occurred and the Modbus client has consumed the information, the Modbus client could then take a some action that would ensure that the Acknowledgment bit is cleared before the breaker is re-closed. The most straight forward of which would be for the client to clear through a write command.

# Entellisys status definitions

## System status

Modbus TCP clients have access to states of FlexLogic operands, protection elements, breaker control, status, contact inputs/outputs, and virtual inputs/outputs through the Modbus TCP interface.

After each protection pass, all the information regarding each operand's state is updated in corresponding Modbus register. The following sections give a complete list of registers holding state information of each operand.

### NOTICE

**NOTICE:** The third-party modbus client must determine which CPU is running as the “active CPU” (Modbus register: “FlexLogic Active”) and FlexLogic health status (Modbus register: “FlexLogic Status Message”).

## Breaker status

Each breaker has 13 different states shown in Table 5. Each one of them corresponds to a different bit in the data item.

Table 5: Breaker control status bit field

Bit	Value
0	Breaker Opened
1	Breaker Closed
2	Breaker Locked Out
3	Closing Spring Charged
4	Active Disconnect Connected
5	Active Disconnect Disconnected
6	Secondary Disconnect Connected
7	Breaker Ready
8	Breaker Available
9	Breaker Open Failed
10	Breaker Close Failed
11	Breaker Fault
12	Reserved

Table 6: Breaker status offsets

Breaker number	Register offset	Bit offset	Notes
Breaker 1	0	0	
Breaker 2	0	13	Spans over two registers
Breaker 3	1	10	Spans over two registers
Breaker 4	2	7	Spans over two registers
-	-	-	-
Breaker 30	24	6	Spans over two registers

## CPU FlexLogic status

The following information is provided to determine the CPU's role and the state of the external control transfer feature.

The Active CPU Status uses one register. See System Operand States (1 item) in Table 54 for memory location.

Table 7: Active CPU status bit field

Bit	Value	Notes
0	CPU A	CPU A is active
1	CPU B	CPU B is active
2	CPU External Control Transfer	0=Active CPU determined by Entellisys 1=Active CPU determined by an external device

## IOC operand states

Each breaker has 2 different states shown in Table 8. Each one of them corresponds to a different bit in the data item.

Table 8: IOC status bit field

Bit	Value
0	Trip Operated
1	Trip Dropout

The breaker states for all 30 breakers span across 4 consecutive modbus registers as shown in Table 9. See IOC Operand States (4 items) in Table 54 for memory locations.

—  
**Table 9: IOC status offsets**

Breaker number	Register offset	Bit offset
Breaker 1	0	0
Breaker 2	0	2
Breaker 3	0	4
Breaker 4	0	6
Breaker 5	0	8
Breaker 6	0	10
Breaker 7	0	12
Breaker 8	0	14
Breaker 9	1	0
-	-	-
Breaker 30	3	12

**ST overcurrent operand states**

Each breaker has 3 different states shown in Table 10. Each one of them corresponds to a different bit in the data item.

—  
**Table 10: ST Overcurrent status bit field**

Bit	Value
0	Trip Pickup
1	Trip Operated
2	Trip Dropout

The breaker states for all 30 breakers span across 6 consecutive modbus registers as shown in Table 11. See ST Overcurrent Operand States (6 items) in Table 54 for memory locations.

—  
**Table 11: Breaker status offsets**

Breaker number	Register offset	Bit offset	Notes
Breaker 1	0	0	
Breaker 2	0	3	
Breaker 3	0	6	
Breaker 4	0	9	
Breaker 5	0	12	
Breaker 6	0	15	Spans over two registers
Breaker 7	1	2	
-	-	-	
Breaker 30	5	10	

**LT overcurrent operand states**

Each breaker has 3 different states shown in Table 12. Each one of them corresponds to a different bit in the data item.

—  
**Table 12: LT Overcurrent status bit field**

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout

The breaker states for all 30 breakers span across 6 consecutive modbus registers as shown in Table 13. See PLC Interface (Read/Write Settings) in Table 54 for memory locations.

—  
**Table 13: Breaker status offsets**

Breaker number	Register offset	Bit offset	Notes
Breaker 1	0	0	
Breaker 2	0	3	
Breaker 3	0	6	
Breaker 4	0	9	
Breaker 5	0	12	
Breaker 6	0	15	Spans over two registers
Breaker 7	1	2	
-	-	-	
Breaker 30	5	10	

**High current and high current transient operand states**

Each breaker has 3 different states shown in Table 14. Each one of them corresponds to a different bit in the data item.

—  
**Table 14: High current status bit field**

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout

The breaker states for all 30 breakers span across 6 consecutive modbus registers as shown in Table 15. See High Current Operand States (6 items) and High Current Transient Operand States (6 items) in Table 54 for memory locations.

Table 15: High current status offsets

Breaker number	Register offset	Bit offset	Notes
Breaker 1	0	0	
Breaker 2	0	3	
Breaker 3	0	6	
Breaker 4	0	9	
Breaker 5	0	12	
Breaker 6	0	15	Spans over two registers
Breaker 7	1	2	
-	-	-	
Breaker 30	5	10	

#### High current flex relay operand states

There are 16 Flex Relays and each have 3 different states shown in Table 16. Each one of them corresponds to a different bit in the data item.

Table 16: High current status bit field

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout

The relay states for all 16 relays span across 3 consecutive modbus registers as shown in Table 17. See High Current Flex Relay Operand States (3 items) in Table 54 for memory locations.

Table 17: High current flex relay status offsets

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	3	
Relay 3	0	6	
Relay 4	0	9	
Relay 5	0	12	
Relay 6	0	15	Spans over two registers
Relay 7	1	2	
-	-	-	
Relay 30	5	10	

#### Ground fault operand states

Each breaker has 5 different states shown in Table 18. Each one of them corresponds to a different bit in the data item.

Table 18: Ground fault status bit field

Bit	Value
0	Trip Pickup
1	Trip Operated
2	Trip Dropout
3	Alarm Pickup
4	Alarm Operated
5	Alarm Dropout

The breaker states for all 30 breakers span across 12 consecutive modbus registers as shown in Table 19. See Ground Fault Operand States (12 items) in Table 54 for memory locations.

Table 19: Ground fault status offsets

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 30	11	4	

#### Over (and under) frequency operand states

Each breaker has 6 different states shown in Table 20. Each one of them corresponds to a different bit in the data item.

Table 20: Over frequency status bit field

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout
3	Trip Pickup
4	Trip Operated
5	Trip Dropout

The breaker states for all 30 breakers span across 12 consecutive modbus registers as shown in Table 21. See Over Frequency Operand States (12 items) and Under Frequency Operand States (12 items) in Table 54 for memory locations.

**Table 21: Over frequency status offsets**

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 30	11	4	

**Over (and under) voltage operand states**

Each breaker has 6 different states shown in Table 22. Each one of them corresponds to a different bit in the data item.

**Table 22: Over voltage status bit field**

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout
3	Trip Pickup
4	Trip Operated
5	Trip Dropout

The breaker states for all 30 breakers span across 12 consecutive modbus registers as shown in Table 23. See Over Voltage Operand States (12 items) and Under Voltage Operand States (12 items) in Table 54 for memory locations.

**Table 23: Over voltage status offsets**

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 30	11	4	

**Under voltage flex relay operand states**

There are 16 Over Voltage and 16 Under Voltage Flex Relays. Each relay has 6 different states shown in Table 24. Each one of them corresponds to a different bit in the data item.

**Table 24: Over voltage status bit field**

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout
3	Trip Pickup
4	Trip Operated
5	Trip Dropout

The relay states for all 16 relays span across 6 consecutive modbus registers as shown in Table 25. See Under Voltage Relay Flex Operand States (6 items) in Table 54 for memory locations.

**Table 25: Over Frequency status offsets**

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 16	5	10	

**Phase loss operand states**

Each breaker has 6 different states shown in Table 26. Each one of them corresponds to a different bit in the data item.

**Table 26: Phase loss status bit field**

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout
3	Trip Pickup
4	Trip Operated
5	Trip Dropout

The breaker states for all 30 breakers span across 12 consecutive modbus registers as shown in Table 27. See Phase Loss Operand States (12 items) in Table 54 for memory locations.

**Table 27: Phase loss status offsets**

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 16	10	14	

### Power reversal operand states

Each breaker has 6 different states shown in Table 28. Each one of them corresponds to a different bit in the data item.

Table 28: Power reversal status bit field

Bit	Value
0	Alarm Pickup
1	Alarm Operated
2	Alarm Dropout
3	Trip Pickup
4	Trip Operated
5	Trip Dropout

The breaker states for all 30 breakers span across 12 consecutive modbus registers as shown in Table 29. See Power Reversal Operand States (12 items) in Table 54 for memory locations.

Table 29: Power reversal status offsets

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 16	10	14	

### Over (and under) demand metering alarm operand states

There are 16 demand alarms. Each alarm relay has 6 different states shown in Table 30. Each one of them corresponds to a different bit in the data item.

Table 30: Demand metering status bit field

Bit	Value
0	Under-Demand Alarm Pickup
1	Under-Demand Alarm Operated
2	Under Demand Alarm Dropout
3	Over-Demand Alarm Pickup
4	Over-Demand Alarm Operated
5	Over-Demand Alarm Dropout

The Alarm states for all 16 alarms span across 6 consecutive modbus registers as shown in Table 31. See Over Demand Alarm Flex Operand States (3 items) and Under Demand Alarm Flex Operand States (3 items) in Table 54 for memory locations.

Table 31: Power reversal status offsets

Breaker number	Register offset	Bit offset	Notes
Relay 1	0	0	
Relay 2	0	6	
Relay 3	0	12	Spans over two registers
Relay 4	1	2	
-	-	-	
Relay 16	5	10	

### Multipoint Flexlogic operand states 2

#### Bus differential operand states

Each zone has 6 different states shown in Table 32. Each one of them corresponds to a different bit in the data item.

Table 32: Bus differential status bit field

Bit	Value
0	Trip Dropout
1	Alarm Dropout
2	Trip Pickup
3	Alarm Pickup
4	Trip Operated
5	Alarm Operated
6	Backup Trip Operated

The zone states for all 4 relay instances span across 2 consecutive modbus registers as shown in Table 33. See Bus Differential Operand States (2 items) in Table 54 for memory locations.

Table 33: Bus differential status offsets

Breaker number	Register offset	Bit offset	Notes
Zone 1	0	0	
Zone 2	0	7	
Zone 3	0	14	This zone's information spans over two registers
Zone 4	1	5	
	1	12	Bits from 12 thru 15 are not used and will always be set to 0

### MSGF Overcurrent Operand States

Each zone has 7 different states shown in Table 34. Each one of them corresponds to a different bit in the data item.

**Table 34: MSGF overcurrent status bit field**

Bit	Value
0	Trip Dropout
1	Alarm Dropout
2	Trip Pickup
3	Alarm Pickup
4	Trip Operated
5	Alarm Operated
6	Backup Trip Operated

The zone states for all 4 instances span across 2 consecutive modbus registers as shown in Table 35. See MSGF Overcurrent Operand States (2 items) in Table 54 for memory locations.

**Table 35: MSGF overcurrent status offsets**

Breaker number	Register offset	Bit offset	Notes
Zone 1	0	0	
Zone 2	0	7	
Zone 3	0	14	This zone's information spans over two registers
Zone 4	1	5	
	1	12	Bits from 12 thru 15 are not used and will always be set to 0

**HRGF detection operand states**

Each breaker has 3 different states shown in Table 36. Each one of them corresponds to a different bit in the data item.

**Table 36: HRGF detection status bit field**

Bit	Value
0	Alarm Dropout
1	Alarm Pickup
2	Alarm Operated

The breaker states for all 30 breakers span across 6 consecutive modbus registers as shown in Table 37. See HRGF Detection Operand States (6 items) in Table 54 for memory locations.

**Table 37: HRGF detection status offsets**

Breaker number	Register offset	Bit offset	Notes
Breaker 1	0	0	
Breaker 2	0	3	
Breaker 3	0	6	
Breaker 4	0	9	
-	-	-	-

**Hrgf location operand states**

Each zone has 2 different states shown in Table 38. Each one of them corresponds to a different bit in the data item.

**Table 38: HRGF location status bit field**

Bit	Value
0	Locator in On State
1	Locator in Off State

The zone states for all 4 location function instances are contained in a single modbus register as shown in Table 39. See HRGF Location Operand States in Table 54 for memory locations.

**Table 39: HRGF location status offsets**

Breaker number	Register offset	Bit offset	Notes
Zone 1	0	0	
Zone 2	0	2	
Zone 3	0	4	
Zone 4	0	6	
	0	8	Bits from 8 thru 15 are not used and will always be set to 0

**Reduced energy let - thru operand states**

This relay has 1 state shown in Table 40.

**Table 40: RELT multipoint operand states**

Bit	Value
0	Multipoint Reduced Let-Thru Mode On

The relay state uses one modbus register as shown in Table 41. See Reduced Let Thru Operand States (4 item) in Table 54 for memory locations.

Table 41: RELT status offsets

Breaker number	Register offset	Bit offset
Breaker 1 Single Point RELT	0	0
Breaker 2 Single Point RELT	0	1
Breaker 3 Single Point RELT	0	2
Breaker 4 Single Point RELT	0	3
Breaker 5 Single Point RELT	0	4
Breaker 6 Single Point RELT	0	5
Breaker 7 Single Point RELT	0	6
Breaker 8 Single Point RELT	0	7
Breaker 9 Single Point RELT	0	8
Breaker 10 Single Point RELT	0	9
Breaker 11 Single Point RELT	0	10
Breaker 12 Single Point RELT	0	11
Breaker 13 Single Point RELT	0	12
Breaker 14 Single Point RELT	0	13
Breaker 15 Single Point RELT	0	14
Breaker 16 Single Point RELT	0	15
Breaker 17 Single Point RELT	1	0
Breaker 18 Single Point RELT	1	1
Breaker 19 Single Point RELT	1	2
Breaker 20 Single Point RELT	1	3
Breaker 21 Single Point RELT	1	4
Breaker 22 Single Point RELT	1	5
Breaker 23 Single Point RELT	1	6
Breaker 24 Single Point RELT	1	7
Breaker 25 Single Point RELT	1	8
Breaker 26 Single Point RELT	1	9
Breaker 27 Single Point RELT	1	10
Breaker 28 Single Point RELT	1	11
Breaker 29 Single Point RELT	1	12
Breaker 30 Single Point RELT	1	13
Multipoint RELT	1	14
System Wide RELT	1	15

#### Summation msgf zone operand states

Each zone has 7 different states shown in Table 42. Each one of them corresponds to a different bit in the data item.

Table 42: Summation MSGF zone status bit field

Bit	Value
0	Trip Dropout
1	Alarm Dropout
2	Trip Pickup
3	Alarm Pickup
4	Trip Operated
5	Alarm Operated
6	Trip Restrained

The zone states for both zones reside in a single modbus register as shown in Table 43. See PLC Interface (Read/Write Settings) in Table 54 for memory locations.

Table 43: Summation MSGF zone status offsets

Breaker Number	Register Offset	Bit Offset
Zone 1	0	0
Zone 2	0	8

#### Synch check operand states

Each relay has 10 different states shown in Table 44. Each one of them corresponds to a different bit in the data item.

Table 44: Synch check status bit field

Bit	Value
0	Dead Source Operated
1	Dead Source Dropout
2	Synch Operated
3	Synch Dropout
4	Close Operated
5	Close Dropout
6	V1 Above Minimum
7	V2 Above Minimum
8	V1 Below Maximum
9	V2 Below Maximum

The relay states for all 12 relays span across 8 consecutive modbus registers as shown in Table 45. See Synch Check Operand States (8 items) in Table 54 for memory locations.

Table 45: Synch Check status offsets

Breaker Number	Register Offset	Bit Offset	Notes
Relay 1	0	0	
Relay 2	0	10	Spans over two registers
Relay 3	1	4	
Relay 4	1	14	Spans over two registers
Relay 5	2	8	Spans over two registers
Relay 6	3	2	
Relay 7	3	12	
Relay 8	4	6	
Relay 9	5	0	
Relay 10	5	10	
Relay 11	6	4	
Relay 12	6	14	
	7	8	Bits from 8 thru 15 are not used and will always be set to 0

# Modbus® protocol implementation

## Introduction

The CPU supports a number of communications protocols to allow connection to the HMI computer, as well as other equipment which includes personal computers, RTUs, SCADA masters, and programmable logic controllers. The Modicon Modbus® RTU protocol is the most basic protocol supported. Modbus is available via ethernet as specified by the Modbus/TCP specification.

Note that:

- The CPU always acts as a slave device, meaning that it never initiates communications; it only listens and responds to requests issued by a master computer
- For Modbus, a subset of the Remote Terminal Unit (RTU) protocol format is supported that allows extensive monitoring, programming, and control functions using read and write register commands
- The CPU will support a maximum of 8 concurrent Modbus sessions. Four sessions are reserved for use by HMI computers. A remote device that attempts to connect when all sessions are in use will receive a response message indicating the number of maximum connections has been exceeded. If a remote device does not make a request within 30 seconds, the session will be timed out and made available to the next device that establishes a session

## Physical layer

The Modbus RTU protocol is hardware-independent so that the physical layer can be any of a variety of standard hardware configurations. The CPU includes a faceplate (front panel) 100BaseT Ethernet port. Data flow is auto-configuring full or half-duplex. Each data byte is transmitted in an asynchronous format consisting of 1 start bit, 8 data bits, 1 stop bit, and possibly 1 parity bit. This produces a 10 or 11 bit data frame.

The master device in any system must know the address of the slave device with which it is to communicate. In the case of ModbusTCP communications, the CPU will not act on a request from a master if the address in the request does not match the CPU's slave address. A single setting selects the slave address used for ModbusTCP. The default slave address for a CPU is 1.

## Data link layer

Communications takes place in packets, which are groups of asynchronously framed byte data. The master transmits a packet to the slave and the slave responds with a packet. The end of a packet is marked by 'dead-time' on the communications line. The following describes general format for both transmit and receive packets. For exact details on packet formatting, see the subsequent sections describing each function code.

—  
**Table 46: Modbus packet format**

Description	Size
Slave address	1 byte
Function code	1 byte
Data	N bytes
CRC	2 bytes
Dead time	3.5 bytes transmission time

## Slave address

This is the address of the slave device that is intended to receive the packet sent by the master and perform the desired action. Only the addressed slave will respond to a packet that starts with its address. Note that since Modbus/TCP also relies on a correct IP address to receive the packet, and each CPU responds as a single device, it is generally not necessary to change the Modbus address of the device.

### Function code

This is one of the supported function codes of the unit which tells the slave what action to perform. See Supported function codes in the Modbus® protocol implementation section for complete details. An exception response from the slave is indicated by setting the high order bit of the function code in the response packet. See Exception responses for further details.

### Data

This will be a variable number of bytes depending on the function code. This may include actual values, settings, or addresses sent by the master to the slave or by the slave to the master.

### CRC

This is a two byte error checking code. The RTU version of Modbus includes a 16-bit cyclic redundancy check (CRC-16) with every packet which is an industry standard method used for error detection. If a Modbus slave device receives a packet in which an error is indicated by the CRC, the slave device will not act upon or respond to the packet thus preventing any erroneous operations. See CRC-16 Algorithm for a description of how to calculate the CRC.

### CRC-16 algorithm

The CRC-16 algorithm essentially treats the entire data stream (data bits only; start, stop and parity ignored) as one continuous binary number. This number is first shifted left 16 bits and then divided by a characteristic polynomial (1100000000000101B). The 16-bit remainder of the division is appended to the end of the packet, most significant byte first. The resulting packet including CRC, when divided by the same polynomial at the receiver, will give a zero remainder if no transmission errors have occurred. This algorithm requires the characteristic polynomial to be reverse bit ordered. The most significant bit of the characteristic polynomial is dropped, since it does not affect the value of the remainder.

Table 47: CRC-26 algorithm

Symbols	
-->	data transfer
A	16-bit working register
Alow	Ahigh
Ahigh	high order byte of A
CRC	16-bit CRC-16 result
i,j	loop counters
(+)	logical EXCLUSIVE-OR operator
N	total number of data bytes
Di	i-th data byte (i = 0 to N-1)
G	16-bit characteristic polynomial = 1010000000000001 (binary) with MSbit dropped and bit order reversed
shr (x)	right shift operator (th LSbit of x is shifted into a carry flag, a '0' is shifted into the MSbit of x, all other bits are shifted right one location)

### Algorithm:

1. FFFF (hex) --> A
2. 0 --> i
3. 0 --> j
4. Di (+) Alow --> Alow
5. j + 1 --> j
6. shr (A)
7. Is there a carry? No: go to 8 Yes: G (+) A --> A and continue.
8. Is j = 8? No: go to 5 Yes: continue
9. i + 1 --> i
10. Is i = N? No: go to 3 Yes: continue
11. A --> CRC

### Supported function codes

Modbus officially defines function codes from 1 to 127 though only a small subset is generally needed. The CPU supports some of these functions, as summarized in the following table. Subsequent sections describe each function code in detail.

### Function code 03H/04H – read actual values or settings

This function code allows the master to read one or more consecutive data registers (actual values or settings) from a relay. Data registers are always 16 bit (two byte) values transmitted with high order byte first. The maximum number of registers that can be read in a single packet is 125. (Refer to the Modbus memory map section) Since some PLC implementations of Modbus only support one of function codes 03h and 04h, the CPU interpretation allows either function code to be used for reading one or more consecutive data registers. The data starting address will determine the type of data being read.

Function codes 03h and 04h are therefore identical. The following table shows the format of the master and slave packets. The example shows a master device requesting 3 register values starting at address 4050h from slave device 11h (17 decimal); the slave device responds with the values 40, 300, and 0 from registers 4050h, 4051h, and 4052h, respectively.

Table 48: Format of master and slave packets

Function code		Modbus definition	CPU definition
HEX	DEC		
03	3	Read Holding Registers	Read Actual Values or Settings
04	4	Read Holding Registers	Read Actual Values or Settings
05	5	Force Single Coil	Execute Operation
06	6	Preset Single Register	Store Single Setting
10	16	Preset Multiple Registers	Store Multiple Settings

Table 49: Master and slave device packet transmission example

Master transmission	
Packet format	Example (HEX)
Slave address	11
Function code	04
Data starting ADDR - hi	40
Data starting ADDR - lo	50
Number of registers - hi	00
Number of registers - lo	03
CRC - lo A7 DATA #2 - lo	A7
CRC - lo A7 DATA #2 - hi	4A
Slave response	
Slave address	11
Function code	04
Byte count	06
Data #1 hi	00
Data #1 lo	28
Data #2 hi	01
Data #2 lo	2C
Data #3 hi	00
Data #3 lo	00
CRC - lo	0D
CRC - hi	60

**Function code 05H – execute operation**

This function code allows the master to perform various operations in the CPU. The following table shows the format of the master and slave packets. The example shows a master device requesting the slave device 11H (17 dec) to perform a reset. The hi and lo CODE VALUE bytes always have the values 'FF' and '00' respectively and are a remnant of the original Modbus definition of this function code.

Table 50: Master and slave device packet transmission example

Master transmission	
Packet format	Example (HEX)
Slave address	11
Function code	05
Operation code - hi	00
Operation code - lo	01
Code value - hi	FF
Code value - lo	00
CRC - lo	DF
CRC - hi	6A
Slave response	
Slave address	11
Function code	05
Operation code - hi	00
Operation code - lo	01
Code value - hi	FF
Code value - lo	00
CRC - lo	DF
CRC - hi	6A

**Function code 06H – store single setting**

This function code allows the master to modify the contents of a single setting register in a CPU. Setting registers are always 16-bit (two byte) values transmitted high-order byte first. The following table shows the format of the master and slave packets. The example shows a master device storing the value 200 at memory map address 4051h to slave device 11h (17 dec).

—  
**Table 51: Master and slave device packet transmission example**

<b>Master transmission</b>	
<b>Packet format</b>	<b>Example (HEX)</b>
Slave address	11
Function code	06
Data starting ADDR - hi	40
Data starting ADDR - lo	51
Data - hi	00
Data - lo	C8
CRC - lo	CE
CRC - hi	DD
<b>Slave response</b>	
Slave address	11
Function code	05
Data starting ADDR - hi	40
Data starting ADDR - lo	51
Data - hi	00
Data - lo	C8
CRC - lo	CE
CRC - hi	DD

#### Function code 10H – store multiple settings

This function code allows the master to modify the contents of a one or more consecutive setting registers in a CPU. Setting registers are 16-bit (two byte) values transmitted high-order byte first. The maximum number of setting registers that can be stored in a single packet is 60. The following table shows the format of the master and slave packets. The example shows a master device storing the value 200 at memory map address 4051h, and the value 1 at memory map address 4052h to slave device 11h (17 dec).

—  
**Table 52: Master and slave device packet transmission example**

<b>Master transmission</b>	
<b>Packet format</b>	<b>Example (HEX)</b>
Slave address	11
Function code	10
Data starting ADDR - hi	40
Data starting ADDR - lo	51
Number of settings - hi	00
Number of settings - lo	02
Byte count	04
Data #1 - hi	00
Data #1 - lo	C8
Data #2 - hi	00
Data #2 - lo	01
CRC - lo	12
CRC - hi	62

—  
**Table 52: Master and slave device packet transmission example (continued)**

<b>Slave response</b>	
<b>Packet format</b>	<b>Example (HEX)</b>
Slave address	11
Function code	10
Data starting ADDR - hi	40
Data starting ADDR - lo	51
Number of settings - hi	00
Number of settings - lo	02
CRC - lo	07
CRC - hi	64

#### Exception responses

Programming or operation errors usually happen because of illegal data in a packet. These errors result in an exception response from the slave. The slave detecting one of these errors sends a response packet to the master with the high order bit of the function code set to 1. The following table shows the format of the master and slave packets. The example shows a master device sending the unsupported function code 39h to slave device 11.

—  
**Table 53: Master and slave device packet transmission example**

<b>Master transmission</b>	
<b>Packet format</b>	<b>Example (HEX)</b>
Slave address	11
Function code	39
CRC - low order byte	CD
CRC - high order byte	F2
<b>Slave response</b>	
Slave address	11
Function code	B9
Error code	01
CRC - low order byte	93
CRC - high order byte	95

## File transfers

### Obtaining CPU files using Modbus protocol

The CPU has a generic file transfer facility, meaning that you use the same method to obtain all of the different types of files from the unit. The Modbus registers that implement file transfer are found in the “Modbus File Transfer (Read/Write)” and “Modbus File Transfer (Read Only)” modules, starting at address 030Eh in the Modbus Memory Map. To read a file from the CPU, use the following steps:

1. Write the filename to the “Name of file to read” register using a write multiple registers command. If the name is shorter than 80 characters, you may write only enough registers to include all the text of the filename. Filenames are not case sensitive.
2. Repeatedly read all the registers in “Modbus File Transfer (Read Only)” using a read multiple registers command. It is not necessary to read the entire data block, since the CPU will remember which was the last register read. The “position” register is initially zero and thereafter indicates how many bytes (2 times the number of registers) you have read so far. The “size of...” register indicates the number of bytes of data remaining to read, to a maximum of 244.
3. Keep reading until the “size of...” register is smaller than the number of bytes you are transferring. This condition indicates end of file. Discard any bytes you have read beyond the indicated block size.
4. If you need to re-try a block, read only the “size of...” and “block of data”, without reading the position. The file pointer is only incremented when you read the position register, so the same data block will be returned as was read in the previous operation.

On the next read, check to see if the position is where you expect it to be, and discard the previous block if it is not (this condition would indicate that the CPU did not process your original read request). The CPU retains connection-specific file transfer information, so files may be read simultaneously on multiple Modbus connections.

- a. Obtaining files from the CPU using other protocols
  - All the files available via Modbus may also be retrieved using the standard file transfer mechanisms in other protocols (for example, TFTP).
- b. Reading event recorder files
  - To read the entire event recorder contents in ASCII format (the only available format), use the following filename:
    - EVT.TXT
- c. Reading fault report files
  - The file name for fault report data is faultReport#####.txt. The ##### refers to the fault report record number. This number is identical to the event record number associated with the fault report. A request for a non-existent fault report file will yield file with no data below the header.
- d. Reading waveform capture files
  - Waveform records comply with COMTRADE 1999 format (IEEE Std C37.111-1999). The file names as required by the standard for waveform capture data are wfc#####.dat and wfc#####.cfg. The ##### refers to the waveform record number. Note that this number is not the same as the event number cited in the case of the fault report above. If an event has a waveform capture associated with it, the waveform number will be shown in the WF Number field as indicated in the header of the event log.

# Modbus memory map

## NOTICE

**NOTICE:** A multiplier factor may be necessary in cases where an integer value is returned but the Range and/or Step imply a greater precision. In these cases, it is necessary to divide the returned value by 10 for a step of “0.1” or “0.5”; by 100 for a step of “.01”; and so on. Similarly, it is necessary to multiply by these factors prior to writing a settings value. This note does not apply to any step value greater than 1 (a step of “10” does not require a multiplier, for example). This note also does not apply to values returned in floating point format. See the format codes at the end of the map for more information.

## NOTICE

**NOTICE:** Discrete I/O output state registers (Contact Output x State - register range from 70BF to 713E and Contact Output States - register range from DC38 to DC3F) contain correct information only when FlexLogic Active register (9588) contains value 1 (yes).

—  
Table 54: Modbus memory map

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Product Information (Read Only)</b>						
0000	FBW Product Type	0 to 65535	---	1	F716	0
0001	CPU Serial Number	---	---	---	F203	"0"
0009	Ethernet MAC Address	---	---	---	F072	0
000C	DAQ Ethernet MAC Address	---	---	---	F072	0
000F	CCPU Hardware Version	0 to 65535	---	1	F001	100
0010	CCPU Firmware Version	0 to 65535	---	1	F001	100
0011	CCPU Firmware Boot Code Version	0 to 65535	---	1	F001	100
0012	Build Date	---	---	0	F200	"0"
0026	Synchronizer Board Status	0 to 1	---	1	F102	0
0027	Synchronizer Board Frequency Setting	50 to 60	Hz	10	F001	60
0028	Last Energy Clear Date	0 to 4294967295	---	1	F050	0
002A	Last CCPU Commissioned Date	0 to 4294967295	---	1	F050	0
002C	Expected Node Protocol Version	0 to 65535	---	1	F001	0
002D	Summary Number	---	---	---	F209	"0"
0033	Line up	0 to 99	---	1	F001	1
0034	System Frequency Detected	0 to 65535	Hz	1	F001	0
0035	CCPU Modbus Map Version	0 to 65535	---	1	F001	560
0036	Reserved	0 to 1	---	1	F126	0 (No)

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Installation (Read/Write)</b>						
0080	CCPU ID	0 to 1	---	1	F17	0
0081	CCPU Commissioned	0 to 1	---	1	F102	0
0082	CCPU Name	---	---	---	F200	"UNNAMED"
0096	System Frequency	50 to 60	Hz	10	F001	60
0097	Phase Rotation	0 to 1	---	1	F106	0
<b>Clock (Read/Write)</b>						
00E0	Current Time	0 to 4294967295	---	1	F050	0
00E2	Date Time Changed	0 to 4294967295	---	1	F050	0
<b>Communications (Read/Write)</b>						
00EC	IP Address	0 to 4294967295	---	1	F003	3232235876
00EE	IP Subnet Mask	0 to 4294963200	---	1	F003	4294967040
00F0	Gateway IP Address	0 to 4294967295	---	1	F003	0
00F2	Reserved (5 items)	1 to 254	---	1	F001	1
<b>Event Recorder (Read Only)</b>						
0150	Events Since Last Clear	0 to 4294967295	---	1	F003	0
0152	Number of Available Events	0 to 4294967295	---	1	F003	0
0154	Event Recorder Last Cleared Date	0 to 4294967295	---	1	F050	0
<b>Modbus File Transfer (Read/Write)</b>						
0156	Name of file to read	---	---	---	F204	None
<b>Modbus File Transfer (Read Only)</b>						
017E	"Character position of current block within file"	0 to 4294967295	---	1	F003	0
0180	Size of currently-available data block	0 to 65535	---	1	F001	0
0181	Block of data from requested file (122 items)	0 to 65535	---	1	F001	0
<b>Modbus File Transfer Area 2 (Read/Write)</b>						
01FB	Modbus File Transfer 2 Filename	---	---	---	F204	None
<b>Modbus File Transfer Area 2 (Read Only)</b>						
0223	"Character position of current block within file"	0 to 4294967295	---	1	F003	0
0225	Size of currently-available data block	0 to 65535	---	1	F001	0
0226	Block of data from requested file (122 items)	0 to 65535	---	1	F001	0
<b>Passwords (Read/Write Command)</b>						
02A0	Reserved (4 items)	0 to 4294967295	---	1	F003	0
02A4	Modbus Command Password Entry	0 to 4294967295	---	1	F003	0
02A6	Modbus Setting Password Entry	0 to 4294967295	---	1	F003	0
<b>Passwords (Read Only)</b>						
02A8	Modbus Command Password Status	0 to 1	---	1	F102	0 (Disabled)
02A9	Modbus Setting Password Status	0 to 1	---	1	F102	0 (Disabled)
02AA	Reserved (128 items)					
<b>Communication Status (Read Only)</b>						
02FF	Main Task Heart Beat	0 to 65535	---	1	F001	0
<b>Zone Manager</b>						
032A	Current Topology State	0 to 255	---	1	F001	0
032B	Current Zone1 Topology	0 to 255	---	1	F001	1
032C	Current Zone2 Topology	0 to 255	---	1	F001	1
032D	Current Zone3 Topology	0 to 255	---	1	F001	1
032E	Current Zone4 Topology	0 to 255	---	1	F001	1
032F	Current Zone1 Topology PT Throwover	0 to 255	---	1	F001	1
0330	Current Zone2 Topology PT Throwover	0 to 255	---	1	F001	1
0331	Current Zone3 Topology PT Throwover	0 to 255	---	1	F001	1
0332	Current Zone4 Topology PT Throwover	0 to 255	---	1	F001	1

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Event Recorder (Read/Write Command)</b>						
0346	Event Recorder Clear Command	---	---	---	F126	0
<b>Energy Commands (Read/Write)</b>						
0347	Energy Clear Command	---	---	---	F126	0
<b>Fault Report Commands (Read/Write)</b>						
0348	Fault Trigger Command	---	---	---	F126	0
<b>Demand</b>						
0349	Demand Subinterval Length	1 to 60	Minutes	1	F001	1
034A	Demand Subintervals Per Interval	1 to 15	---	1	F001	1
034B	Demand Reset All Command	0 to 1	---	1	F126	0
034C	Number Of Demand Resets All	0 to 4294963200	---	1	F003	0
034E	Last Demand Reset All DateTime	0 to 4294967295	---	1	F050	0
0350	Demand Log Clear All Command	0 to 1	---	1	F126	0
0351	Demand Log Last Cleared All Date	0 to 4294967295	---	1	F050	0
<b>Waveform Capture</b>						
035D	Number WF Records Available	0 to 65535	---	1	F001	0
035E	Waveform Clear Command	---	---	---	F126	0
035F	Waveform Last Clear Date	0 to 4294967295	---	1	F050	0
0361	Waveform Trigger Command	---	---	---	F126	0
0362	Waveform Trigger Mode	0 to 1	---	1	F118	0
0363	Waveform Trigger Position	0 to 119	Half Cycles	1	F001	60
0364	Waveforms Since Last Clear	0 to 4294967295	---	1	F003	0
0366	WFC Buffers Free	0 to 65535	---	1	F001	0
0367	WFC Buffers Stored	0 to 65535	---	1	F001	0
0368	Waveform Trigger Thru FlexLogic	0 to 65535	---	1	F300	0
<b>Preventive Maintenance</b>						
0370	Load Life Rating 800A	0 to 65535	A	1	F001	2800
0371	Load Life Rating 1600A	0 to 65535	A	1	F001	1200
0372	Load Life Rating 2000A	0 to 65535	A	1	F001	1000
0373	Load Life Rating 3200A	0 to 65535	A	1	F001	600
0374	Load Life Rating 4000A	0 to 65535	A	1	F001	500
0375	Load Life Rating 5000A	0 to 65535	A	1	F001	400
0376	Mechanical_Life_Rating_800A	0 to 65535	A	1	F001	12500
0377	Mechanical_Life_Rating_1600A	0 to 65535	A	1	F001	4000
0378	Mechanical_Life_Rating_2000A	0 to 65535	A	1	F001	4000
0379	Mechanical_Life_Rating_3200A	0 to 65535	A	1	F001	1500
037A	Mechanical_Life_Rating_4000A	0 to 65535	A	1	F001	1500
037B	Mechanical_Life_Rating_5000A	0 to 65535	A	1	F001	1500
037C	Load Life Max Current 800A	1 to 50	---	1	F001	15
037D	Load Life Max Current 1600A	1 to 50	---	1	F001	15
037E	Load Life Max Current 2000A	1 to 50	---	1	F001	15
037F	Load Life Max Current 3200A	1 to 50	---	1	F001	13
0380	Load Life Max Current 4000A	1 to 50	---	1	F001	9
0381	Load Life Max Current 5000A	1 to 50	---	1	F001	7
<b>Hardware Information (Read Only)</b>						
03A0	Flash Lifetime	1 to 10	---	1	F001	1
<b>Source Status Vectors (Read Only)</b>						
040A	Expected Nodes X State	0 to 4294967295	---	1	F722	0
040C	Source Node Identifier LED X State	0 to 4294967295	---	1	F722	0
040E	Node Setting Changed X State	0 to 4294967295	---	1	F722	0
0410	Nodes Communicating X State	0 to 4294967295	---	1	F722	0

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Status Vectors (Read Only) (Continued)</b>						
412	Nodes Commissioned X State	0 to 4294967295	---	1	F722	0
0414	Duplicate Nodes X State	0 to 4294967295	---	1	F722	0
0416	Node Internal Diagnostics X State	0 to 4294967295	---	1	F722	0
0418	Node System Diagnostics X State	0 to 4294967295	---	1	F722	0
041A	Node Hardware Diagnostics X State	0 to 4294967295	---	1	F722	0
041C	Node Reflected CCPU Diagnostics X State	0 to 4294967295	---	1	F722	0
041E	Breaker Contact Position X State	0 to 4294967295	---	1	F722	0
0420	Breaker Primary Connection X State	0 to 4294967295	---	1	F722	0
0422	Breaker Lockout X State	0 to 4294967295	---	1	F722	0
0424	Summations Suspended X State	0 to 4294967295	---	1	F722	0
0426	Breaker Tripped X State	0 to 4294967295	---	1	F722	0
<b>"Source Vectors For Alarms (Ack Are R/W)"</b>						
0428	Undervoltage Trip Alarm State	0 to 4294967295	---	1	F722	0
042A	Undervoltage Trip Alarm Ack	0 to 4294967295	---	1	F722	0
042C	Undervoltage Alarm State	0 to 4294967295	---	1	F722	0
042E	Undervoltage Alarm Ack	0 to 4294967295	---	1	F722	0
0430	Overvoltage Trip Alarm State	0 to 4294967295	---	1	F722	0
0432	Overvoltage Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0434	Overvoltage Alarm State	0 to 4294967295	---	1	F722	0
0436	Overvoltage Alarm Ack	0 to 4294967295	---	1	F722	0
0438	Phase Loss Trip Alarm State	0 to 4294967295	---	1	F722	0
043A	Phase Loss Trip Alarm Ack	0 to 4294967295	---	1	F722	0
043C	Phase Loss Alarm State	0 to 4294967295	---	1	F722	0
043E	Phase Loss Alarm Ack	0 to 4294967295	---	1	F722	0
0440	Reverse Power Trip Alarm State	0 to 4294967295	---	1	F722	0
0442	Reverse Power Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0444	Reverse Power Alarm State	0 to 4294967295	---	1	F722	0
0446	Reverse Power Alarm Ack	0 to 4294967295	---	1	F722	0
0448	High Current Alarm State	0 to 4294967295	---	1	F722	0
044A	High Current Alarm Ack	0 to 4294967295	---	1	F722	0
044C	Underfrequency Trip Alarm State	0 to 4294967295	---	1	F722	0
044E	Underfrequency Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0450	Underfrequency Alarm State	0 to 4294967295	---	1	F722	0
0452	Underfrequency Alarm Ack	0 to 4294967295	---	1	F722	0
0454	Overfrequency Trip Alarm State	0 to 4294967295	---	1	F722	0
0456	Overfrequency Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0458	Overfrequency Alarm State	0 to 4294967295	---	1	F722	0
045A	Overfrequency Alarm Ack	0 to 4294967295	---	1	F722	0
045C	High Resistance Ground Fault Alarm State	0 to 4294967295	---	1	F722	0
045E	High Resistance Ground Fault Alarm Ack	0 to 4294967295	---	1	F722	0
0460	Breaker Open Failed Alarm State	0 to 4294967295	---	1	F722	0
0462	Breaker Open Failed Alarm Ack	0 to 4294967295	---	1	F722	0
0464	Long Time Overcurrent Trip Alarm State	0 to 4294967295	---	1	F722	0
0466	Long Time Overcurrent Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0468	Short Time Overcurrent Trip Alarm State	0 to 4294967295	---	1	F722	0
046A	Short Time Overcurrent Trip Alarm Ack	0 to 4294967295	---	1	F722	0
046C	Ground Fault Trip Alarm State	0 to 4294967295	---	1	F722	0
046E	Ground Fault Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0470	Ground Fault Alarm State	0 to 4294967295	---	1	F722	0
0472	Ground Fault Alarm Ack	0 to 4294967295	---	1	F722	0

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>"Source Vectors For Alarms (Ack Are R/W)" (Continued)</b>						
0474	Analog IOC Trip Alarm State	0 to 4294967295	---	1	F722	0
0476	Analog IOC Trip Alarm Ack	0 to 4294967295	---	1	F722	0
0478	IOC Trip Alarm State	0 to 4294967295	---	1	F722	0
047A	IOC Trip Alarm Ack	0 to 4294967295	---	1	F722	0
047C	Node Control Power Lost State	0 to 4294967295	---	1	F722	0
047E	Node Control Power Lost Ack	0 to 4294967295	---	1	F722	0
0480	Node Communication Lost State	0 to 4294967295	---	1	F722	0
0482	Node Communication Lost Ack	0 to 4294967295	---	1	F722	0
0484	Breaker Load Life 50 State	0 to 4294967295	---	1	F722	0
0486	Breaker Load Life 50 Ack	0 to 4294967295	---	1	F722	0
0488	Breaker Load Life 75 State	0 to 4294967295	---	1	F722	0
048A	Breaker Load Life 75 Ack	0 to 4294967295	---	1	F722	0
048C	Breaker Load Life 90 State	0 to 4294967295	---	1	F722	0
048E	Breaker Load Life 90 Ack	0 to 4294967295	---	1	F722	0
0490	Breaker Accum Service Alarm State	0 to 4294967295	---	1	F722	0
0492	Breaker Accum Service Alarm Ack	0 to 4294967295	---	1	F722	0
0494	Breaker Mechanical Life 12 5 State	0 to 4294967295	---	1	F722	0
0496	Breaker Mechanical Life 12 5 Ack	0 to 4294967295	---	1	F722	0
0498	Breaker Mechanical Life 25 State	0 to 4294967295	---	1	F722	0
049A	Breaker Mechanical Life 25 Ack	0 to 4294967295	---	1	F722	0
049C	Breaker Mechanical Life 37 5 State	0 to 4294967295	---	1	F722	0
049E	Breaker Mechanical Life 37 5 Ack	0 to 4294967295	---	1	F722	0
04A0	Breaker Mechanical Life 50 State	0 to 4294967295	---	1	F722	0
04A2	Breaker Mechanical Life 50 Ack	0 to 4294967295	---	1	F722	0
04A4	Breaker Mechanical Life 62 5 State	0 to 4294967295	---	1	F722	0
04A6	Breaker Mechanical Life 62 5 Ack	0 to 4294967295	---	1	F722	0
04A8	Breaker Mechanical Life 75 State	0 to 4294967295	---	1	F722	0
04AA	Breaker Mechanical Life 75 Ack	0 to 4294967295	---	1	F722	0
04AC	Breaker Mechanical Life 87 5 State	0 to 4294967295	---	1	F722	0
04AE	Breaker Mechanical Life 87 5 Ack	0 to 4294967295	---	1	F722	0
04B0	Breaker Mechanical Life 100 State	0 to 4294967295	---	1	F722	0
04B2	Breaker Mechanical Life 100 Ack	0 to 4294967295	---	1	F722	0
04B4	Bus Differential Trip Alarm State	0 to 4294967295	---	1	F722	0
04B6	Bus Differential Trip Alarm Ack	0 to 4294967295	---	1	F722	0
04B8	Bus Differential Alarm State	0 to 4294967295	---	1	F722	0
04BA	Bus Differential Alarm Ack	0 to 4294967295	---	1	F722	0
04BC	Multi Source Ground Fault Trip Alarm State	0 to 4294967295	---	1	F722	0
04BE	Multi Source Ground Fault Trip Alarm Ack	0 to 4294967295	---	1	F722	0
04C0	Multi Source Ground Fault Alarm State	0 to 4294967295	---	1	F722	0
04C2	Multi Source Ground Fault Alarm Ack	0 to 4294967295	---	1	F722	0
04C4	Hardware Synch Card Lost State	0 to 4294967295	---	1	F722	0
04C6	Hardware Synch Card Lost Ack	0 to 4294967295	---	1	F722	0
04CA	Compartment ID Button Missing Alarm State	0 to 4294967295	---	1	F722	0
04CE	Compartment ID Button Missing Alarm Ack	0 to 4294967295	---	1	F722	0
04D0	Control Alarm State	0 to 4294967295	---	1	F722	0
04D2	Control Alarm Ack	0 to 4294967295	---	1	F722	0
04D4	Redundant CPU Node Comm Loss State	0 to 4294967295	---	1	F722	0
04D6	Redundant CPU Node Comm Loss Ack	0 to 4294967295	---	1	F722	0
04D8	Redundant CPU Hardware Synch Loss State	0 to 4294967295	---	1	F722	0

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>"Source Vectors For Alarms (Ack Are R/W)" (Continued)</b>						
04DA	Redundant CPU Hardware Synch Loss Ack	0 to 4294967295	---	1	F722	0
04DC	Discrete IO Misconfigured State	0 to 4294967295	---	1	F722	0
04DE	Discrete IO Misconfigured Ack	0 to 4294967295	---	1	F722	0
04E0	Reserved (8 items)	0 to 4294967295	---	1	F722	0
04E8	HRGF Location Alarm State	0 to 4294967295	---	1	F722	0
04EA	HRGF Location Alarm Ack	0 to 4294967295	---	1	F722	0
04EC	High Current Flex Relay Alarm State	0 to 4294967295	---	1	F722	0
04EE	High Current Flex Relay Alarm Ack	0 to 4294967295	---	1	F722	0
04F0	Undervoltage Flex Relay Trip Alarm State	0 to 4294967295	---	1	F722	0
04F2	Undervoltage Flex Relay Trip Alarm Ack	0 to 4294967295	---	1	F722	0
04F4	Undervoltage Flex Relay Alarm State	0 to 4294967295	---	1	F722	0
04F6	Undervoltage Flex Relay Alarm Ack	0 to 4294967295	---	1	F722	0
04F8	Reserved (8 items)	0 to 4294967295	---	1	F722	0
0500	Over Demand Flex Alarm State	0 to 4294967295	---	1	F722	0
0502	Over Demand Flex Alarm Ack	0 to 4294967295	---	1	F722	0
0504	Under Demand Flex Alarm State	0 to 4294967295	---	1	F722	0
0506	Under Demand Flex Alarm Ack	0 to 4294967295	---	1	F722	0
0508	SRC X Node Ground CT Connected	0 to 4294967295	---	1	F722	0
050A	High Current Trigger Alarm State	0 to 4294967295	---	1	F722	0
050C	High Current Trigger Alarm Ack	0 to 4294967295	---	1	F722	0
050E	Reduced Let Thru Over x Hours Alarm State	0 to 4294967295	---	1	F722	0
0510	Reduced Let Thru Over x Hours Alarm Ack	0 to 4294967295	---	1	F722	0
0512	HRGF Location Contactor Operating Alarm State	0 to 4294967295	---	1	F722	0
0514	HRGF Location Contactor Operating Alarm Ack	0 to 4294967295	---	1	F722	0
0516	HRGF Location Trip Alarm State	0 to 4294967295	---	1	F722	0
0518	HRGF Location Trip Alarm Ack	0 to 4294967295	---	1	F722	0
051A	Flux Shifter Alarm State	0 to 4294967295	---	1	F722	0
051C	Flux Shifter Alarm Ack	0 to 4294967295	---	1	F722	0
051E	Shunt Trip Failure Alarm State	0 to 4294967295	---	1	F722	0
0520	Shunt Trip Failure Alarm Ack	0 to 4294967295	---	1	F722	0
0522	Remote IO Subsystem Malfunction State	0 to 4294967295		1	F722	0
0524	Remote IO Subsystem Malfunction Ack	0 to 4294967295		1	F722	0
<b>Source Voltage (Read Only) (30 Modules)</b>						
0542	Phase AG Voltage RMS	0 to 999999	V	0,001	F060	0
0544	Phase BG Voltage RMS	0 to 999999	V	0,001	F060	0
0546	Phase CG Voltage RMS	0 to 999999	V	0,001	F060	0
0548	Phase AB Voltage RMS	0 to 999999	V	0,001	F060	0
054A	Phase BC Voltage RMS	0 to 999999	V	0,001	F060	0
054C	Phase CA Voltage RMS	0 to 999999	V	0,001	F060	0
054E	SRC X Voltage Reserved (30 items)	---	---	0	F001	0
056C	...Repeated for module number 2					
0596	...Repeated for module number 3					
05C0	...Repeated for module number 4					
05EA	...Repeated for module number 5					
0614	...Repeated for module number 6					
063E	...Repeated for module number 7					
0668	...Repeated for module number 8					
0692	...Repeated for module number 9					
06BC	...Repeated for module number 10					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Voltage (Read Only) (30 Modules) (Continued)</b>						
06E6	...Repeated for module number 11					
0710	...Repeated for module number 12					
073A	...Repeated for module number 13					
0764	...Repeated for module number 14					
078E	...Repeated for module number 15					
07B8	...Repeated for module number 16					
07E2	...Repeated for module number 17					
080C	...Repeated for module number 18					
0836	...Repeated for module number 19					
0860	...Repeated for module number 20					
088A	...Repeated for module number 21					
08B4	...Repeated for module number 22					
08DE	...Repeated for module number 23					
0908	...Repeated for module number 24					
0932	...Repeated for module number 25					
095C	...Repeated for module number 26					
0986	...Repeated for module number 27					
09B0	...Repeated for module number 28					
09DA	...Repeated for module number 29					
0A04	...Repeated for module number 30					
<b>FBW Current (Read Only) (30 Modules)</b>						
0A2E	Phase A Current RMS	0 to 999999	A	0,001	F060	0
0A30	Phase B Current RMS	0 to 999999	A	0,001	F060	0
0A32	Phase C Current RMS	0 to 999999	A	0,001	F060	0
0A34	Neutral Current RMS	0 to 999999	A	0,001	F060	0
0A36	Ground Current RMS	0 to 999999	A	0,001	F060	0
0A38	...Repeated for module number 2					
0A42	...Repeated for module number 3					
0A4C	...Repeated for module number 4					
0A56	...Repeated for module number 5					
0A60	...Repeated for module number 6					
0A6A	...Repeated for module number 7					
0A74	...Repeated for module number 8					
0A7E	...Repeated for module number 9					
0A88	...Repeated for module number 10					
0A92	...Repeated for module number 11					
0A9C	...Repeated for module number 12					
0AA6	...Repeated for module number 13					
0AB0	...Repeated for module number 14					
0ABA	...Repeated for module number 15					
0AC4	...Repeated for module number 16					
0ACE	...Repeated for module number 17					
0AD8	...Repeated for module number 18					
0AE2	...Repeated for module number 19					
0AEC	...Repeated for module number 20					
0AF6	...Repeated for module number 21					
0B00	...Repeated for module number 22					
0B0A	...Repeated for module number 23					
0B14	...Repeated for module number 24					
0B1E	...Repeated for module number 25					

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>FBW Current (Read Only) (30 Modules) (Continued)</b>						
0B28	...Repeated for module number 26					
0B32	...Repeated for module number 27					
0B3C	...Repeated for module number 28					
0B46	...Repeated for module number 29					
0B50	...Repeated for module number 30					
<b>Reduced Let Thru Command</b>						
0B5A	Remote Multipoint Reduced Let Thru Enable	0 to 1	---	1	F126	0
0B5B	Remote Multipoint Reduced Let Thru Reset	0 to 1	---	1	F126	0
0B5C	Remote Multipoint Reduced Let Thru Factory Rst All	0 to 1	---	1	F126	0
0B5D	Remote System Reduced Let Thru Enable	0 to 1	---	1	F126	0
0B5E	Remote System Reduced Let Thru Reset	0 to 1	---	1	F126	0
0B5F	Remote System Reduced Let Thru Factory Rst All	0 to 1	---	1	F126	0
0B60	Reserved (11 Items)					
<b>Reduced Let Thru Setting (Read/Write)</b>						
0B6B	FlexLogic Multipoint Reduced Let Thru Trigger	0 to 65535	---	1	F300	0
0B6C	FlexLogic System Reduced Let Thru Trigger	0 to 65535	---	1	F300	0
0B6D	Reduced Let Thru Alarm Reactivation Time	1 to 24	Hrs	1	F001	24
0B6E	Reserved (6 Items)					
<b>Reduced Let Thru Status (Read Only)</b>						
0B74	Reduced Let Thru Status	0 to 4294967295	---	1	F739	0
0B76	FlexLogic Multipoint Reduced Let Thru State	0 to 1	---	1	F108	0
0B77	FlexLogic System Reduced Let Thru State	0 to 1	---	1	F108	0
0B78	Remote Reduced Let Thru Command Feedback	0 to 4294967295	---	1	F739	0
0B7A	Remote Multipoint Reduced Let Thru Enable Count	0 to 8	---	1	F001	0
0B7B	Remote System Reduced Let Thru Enable Count	0 to 8	---	1	F001	0
0B7C	Reserved (7 Items)					
<b>Source Reduced Let Thru Command (30 Modules)</b>						
0B84	SRC X Remote Reduced Let Thru Enable Load	0 to 1	---	1	F126	0
0B85	SRC X Remote Reduced Let Thru Reset Load	0 to 1	---	1	F126	0
0B86	SRC X Remote Reduced Let Thru Factory Rst All	0 to 1	---	1	F126	0
0B87	Reserved (9 Items)	0 to 1	---	1	F126	0
0B90	...Repeated for Node 2					
0B9C	...Repeated for Node 3					
0BA8	...Repeated for Node 4					
0BB4	...Repeated for Node 5					
0BC0	...Repeated for Node 6					
0BCC	...Repeated for Node 7					
0BD8	...Repeated for Node 8					
0BE4	...Repeated for Node 9					
0BF0	...Repeated for Node 10					
0BFC	...Repeated for Node 11					
0C08	...Repeated for Node 12					
0C14	...Repeated for Node 13					
0C20	...Repeated for Node 14					
0C2C	...Repeated for Node 15					
0C38	...Repeated for Node 16					
0C44	...Repeated for Node 17					
0C50	...Repeated for Node 18					
0C5C	...Repeated for Node 19					
0C68	...Repeated for Node 20					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Reduced Let Thru Command (30 Modules) (Continued)</b>						
0C74	...Repeated for Node 21					
0C80	...Repeated for Node 22					
0C8C	...Repeated for Node 23					
0C98	...Repeated for Node 24					
0CA4	...Repeated for Node 25					
0CB0	...Repeated for Node 26					
0CBC	...Repeated for Node 27					
0CC8	...Repeated for Node 28					
0CD4	...Repeated for Node 29					
0CE0	...Repeated for Node 30					
<b>Source Reduced Let Thru Setting (30 Modules)</b>						
0CEC	SRC X Reduced Let Thru Association	0 to 1073741823	---	1	F722	0
0CEE	SRC X Reduced Let Thru Setting Reserved					
0CF1	...Repeated for Node 2					
0CF6	...Repeated for Node 3					
0CFB	...Repeated for Node 4					
0D00	...Repeated for Node 5					
0D05	...Repeated for Node 6					
0D0A	...Repeated for Node 7					
0D0F	...Repeated for Node 8					
0D14	...Repeated for Node 9					
0D19	...Repeated for Node 10					
0D1E	...Repeated for Node 11					
0D23	...Repeated for Node 12					
0D28	...Repeated for Node 13					
0D2D	...Repeated for Node 14					
0D32	...Repeated for Node 15					
0D37	...Repeated for Node 16					
0D3C	...Repeated for Node 17					
0D41	...Repeated for Node 18					
0D46	...Repeated for Node 19					
0D4B	...Repeated for Node 20					
0D50	...Repeated for Node 21					
0D55	...Repeated for Node 22					
0D5A	...Repeated for Node 23					
0D5F	...Repeated for Node 24					
0D64	...Repeated for Node 25					
0D69	...Repeated for Node 26					
0D6E	...Repeated for Node 27					
0D73	...Repeated for Node 28					
0D78	...Repeated for Node 29					
0D7D	...Repeated for Node 30					
<b>Source Reduced Let Thru Status (Read Only) (30 Modules)</b>						
0D82	SRC X FlexLogic Reduced Let Thru State	0 to 1	---	1	F108	0
0D83	SRC X Remote Reduced Let Thru Enable Load Count	0 to 8	---	1	F001	0
0D84	Reserved (8 items)					
0D8C	...Repeated for Node 2					
0D96	...Repeated for Node 3					
0DA0	...Repeated for Node 4					
0DAA	...Repeated for Node 5					

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Reduced Let Thru Status (Read Only) (30 Modules) (Continued)</b>						
0DB4	...Repeated for Node 6					
0DBE	...Repeated for Node 7					
0DC8	...Repeated for Node 8					
0DD2	...Repeated for Node 9					
0DDC	...Repeated for Node 10					
0DE6	...Repeated for Node 11					
0DF0	...Repeated for Node 12					
0DFA	...Repeated for Node 13					
0E04	...Repeated for Node 14					
0E0E	...Repeated for Node 15					
0E18	...Repeated for Node 16					
0E22	...Repeated for Node 17					
0E2C	...Repeated for Node 18					
0E36	...Repeated for Node 19					
0E40	...Repeated for Node 20					
0E4A	...Repeated for Node 21					
0E54	...Repeated for Node 22					
0E5E	...Repeated for Node 23					
0E68	...Repeated for Node 24					
0E72	...Repeated for Node 25					
0E7C	...Repeated for Node 26					
0E86	...Repeated for Node 27					
0E90	...Repeated for Node 28					
0E9A	...Repeated for Node 29					
0EA4	...Repeated for Node 30					
<b>Source Power (Read Only) (30 Modules)</b>						
0EAE	Three Phase Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EB0	Phase A Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EB2	Phase B Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EAE	Three Phase Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EB0	Phase A Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EB2	Phase B Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EB4	Phase C Real Power	-1000000000000 to 1000000000000	W	0,001	F060	0
0EB6	Three Phase Reactive Power	-1000000000000 to 1000000000000	var	0,001	F060	0
0EB8	Phase A Reactive Power	-1000000000000 to 1000000000000	var	0,001	F060	0
0EBA	Phase B Reactive Power	-1000000000000 to 1000000000000	var	0,001	F060	0
0EBC	Phase C Reactive Power	-1000000000000 to 1000000000000	var	0,001	F060	0
0EBE	Three Phase Apparent Power	-1000000000000 to 1000000000000	VA	0,001	F060	0
0EC0	Phase A Apparent Power	-1000000000000 to 1000000000000	VA	0,001	F060	0
0EC2	Phase B Apparent Power	-1000000000000 to 1000000000000	VA	0,001	F060	0

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Power (Read Only) (30 Modules) (Continued)</b>						
0EC4	Phase C Apparent Power	-1000000000000 to 1000000000000	VA	0,001	F060	0
0EC6	Three Phase Power Factor	-999 to 1000	---	1	F013	0
0EC7	Phase A Power Factor	-999 to 1000	---	1	F013	0
0EC8	Phase B Power Factor	-999 to 1000	---	1	F013	0
0EC9	Phase C Power Factor	-999 to 1000	---	1	F013	0
0ECA	SRC X Power Reserved (10 items)					
0ED4	...Repeated for module number 2					
0EFA	...Repeated for module number 3					
0F20	...Repeated for module number 4					
0F46	...Repeated for module number 5					
0F6C	...Repeated for module number 6					
0F92	...Repeated for module number 7					
0FB8	...Repeated for module number 8					
0FDE	...Repeated for module number 9					
1004	...Repeated for module number 10					
102A	...Repeated for module number 11					
1050	...Repeated for module number 12					
1076	...Repeated for module number 13					
109C	...Repeated for module number 14					
10C2	...Repeated for module number 15					
10E8	...Repeated for module number 16					
110E	...Repeated for module number 17					
1134	...Repeated for module number 18					
115A	...Repeated for module number 19					
1180	...Repeated for module number 20					
11A6	...Repeated for module number 21					
11CC	...Repeated for module number 22					
11F2	...Repeated for module number 23					
1218	...Repeated for module number 24					
123E	...Repeated for module number 25					
1264	...Repeated for module number 26					
128A	...Repeated for module number 27					
12B0	...Repeated for module number 28					
12D6	...Repeated for module number 29					
12FC	...Repeated for module number 30					
<b>Source Energy (Read Only) (30 Modules)</b>						
1322	Positive Watthour	0 to 1000000000000	Wh	0,001	F060	0
1324	Phase A Positive Watthour	0 to 1000000000000	Wh	0,001	F060	0
1326	Phase B Positive Watthour	0 to 1000000000000	Wh	0,001	F060	0
1328	Phase C Positive Watthour	0 to 1000000000000	Wh	0,001	F060	0
132A	Negative Watthour	0 to 1000000000000	Wh	0,001	F060	0
132C	Phase A Negative Watthour	0 to 1000000000000	Wh	0,001	F060	0
132E	Phase B Negative Watthour	0 to 1000000000000	Wh	0,001	F060	0
1330	Phase C Negative Watthour	0 to 1000000000000	Wh	0,001	F060	0
1332	Positive Varhour	0 to 1000000000000	varh	0,001	F060	0
1334	Phase A Positive Varhour	0 to 1000000000000	varh	0,001	F060	0
1336	Phase B Positive Varhour	0 to 1000000000000	varh	0,001	F060	0
1338	Phase C Positive Varhour	0 to 1000000000000	varh	0,001	F060	0
133A	Negative Varhour	0 to 1000000000000	varh	0,001	F060	0

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Energy (Read Only) (30 Modules) (Continued)</b>						
133C	Phase A Negative Varhour	0 to 1000000000000	varh	0,001	F060	0
133E	Phase B Negative Varhour	0 to 1000000000000	varh	0,001	F060	0
1340	Phase C Negative Varhour	0 to 1000000000000	varh	0,001	F060	0
1342	Vahour	0 to 1000000000000	vah	0,001	F060	0
1344	Phase A Vahour	0 to 1000000000000	vah	0,001	F060	0
1346	Phase B Vahour	0 to 1000000000000	vah	0,001	F060	0
1348	Phase C Vahour	0 to 1000000000000	vah	0,001	F060	0
134A	SRC X Energy Reserved (10 items)					
1354	...Repeated for module number 2					
1386	...Repeated for module number 3					
13B8	...Repeated for module number 4					
13EA	...Repeated for module number 5					
141C	...Repeated for module number 6					
144E	...Repeated for module number 7					
1480	...Repeated for module number 8					
14B2	...Repeated for module number 9					
14E4	...Repeated for module number 10					
1516	...Repeated for module number 11					
1548	...Repeated for module number 12					
157A	...Repeated for module number 13					
15AC	...Repeated for module number 14					
15DE	...Repeated for module number 15					
1610	...Repeated for module number 16					
1642	...Repeated for module number 17					
1674	...Repeated for module number 18					
16A6	...Repeated for module number 19					
16D8	...Repeated for module number 20					
170A	...Repeated for module number 21					
173C	...Repeated for module number 22					
176E	...Repeated for module number 23					
17A0	...Repeated for module number 24					
17D2	...Repeated for module number 25					
1804	...Repeated for module number 26					
1836	...Repeated for module number 27					
1868	...Repeated for module number 28					
189A	...Repeated for module number 29					
18CC	...Repeated for module number 30					
<b>Source Harmonic Analysis (Read only) (30 Modules)</b>						
18FE	SRC X Phase A Voltage THD	0 to 1000	dB	1	F001	0
18FF	SRC X Phase B Voltage THD	0 to 1000	dB	1	F001	0
1900	SRC X Phase C Voltage THD	0 to 1000	dB	1	F001	0
1901	SRC X Phase A Current THD	0 to 1000	dB	1	F001	0
1902	SRC X Phase B Current THD	0 to 1000	dB	1	F001	0
1903	SRC X Phase C Current THD	0 to 1000	dB	1	F001	0
1904	SRC X Phase N Current THD	0 to 1000	dB	1	F001	0
1905	SRC X Phase A K Factor	0 to 65535	---	1	F001	10
1906	SRC X Phase B K Factor	0 to 65535	---	1	F001	10
1907	SRC X Phase C K Factor	0 to 65535	---	1	F001	10
1908	SRC X Phase N K Factor	0 to 65535	---	1	F001	10
1909	SRC X Harmonic Analysis Reserved (10 items)					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Harmonic Analysis (Read only) (30 Modules) (Continued)</b>						
1913	...Repeated for module number 2					
1928	...Repeated for module number 3					
193D	...Repeated for module number 4					
1952	...Repeated for module number 5					
1967	...Repeated for module number 6					
197C	...Repeated for module number 7					
1991	...Repeated for module number 8					
19A6	...Repeated for module number 9					
19BB	...Repeated for module number 10					
19D0	...Repeated for module number 11					
19E5	...Repeated for module number 12					
19FA	...Repeated for module number 13					
1A0F	...Repeated for module number 14					
1A24	...Repeated for module number 15					
1A39	...Repeated for module number 16					
1A4E	...Repeated for module number 17					
1A63	...Repeated for module number 18					
1A78	...Repeated for module number 19					
1A8D	...Repeated for module number 20					
1AA2	...Repeated for module number 21					
1AB7	...Repeated for module number 22					
1ACC	...Repeated for module number 23					
1AE1	...Repeated for module number 24					
1AF6	...Repeated for module number 25					
1B0B	...Repeated for module number 26					
1B20	...Repeated for module number 27					
1B35	...Repeated for module number 28					
1B4A	...Repeated for module number 29					
1B5F	...Repeated for module number 30					
<b>Source Demand Peaks (Read Only) (30 Modules)</b>						
1B74	SRC X Maximum kW	-1000000000000 to 1000000000000	W	0,001	F060	0
1B76	SRC X Maximum kW DateTime	0 to 4294967295	---	1	F050	0
1B78	SRC X Maximum kvar	-1000000000000 to 1000000000000	var	0,001	F060	0
1B7A	SRC X Maximum kvar DateTime	0 to 4294967295	---	1	F050	0
1B7C	SRC X Maximum kVA	-1000000000000 to 1000000000000	VA	0,001	F060	0
1B7E	SRC X Maximum kVA DateTime	0 to 4294967295	---	1	F050	0
1B80	SRC X Source Demand Peaks Reserved (8 items)					
1B88	...Repeated for module number 2					
1B9C	...Repeated for module number 3					
1BB0	...Repeated for module number 4					
1BC4	...Repeated for module number 5					
1BD8	...Repeated for module number 6					
1BEC	...Repeated for module number 7					
1C00	...Repeated for module number 8					
1C14	...Repeated for module number 9					
1C28	...Repeated for module number 10					
1C3C	...Repeated for module number 11					

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Demand Peaks (Read Only) (30 Modules) (Continued)</b>						
1C50	...Repeated for module number 12					
1C64	...Repeated for module number 13					
1C78	...Repeated for module number 14					
1C8C	...Repeated for module number 15					
1CA0	...Repeated for module number 16					
1CB4	...Repeated for module number 17					
1CC8	...Repeated for module number 18					
1CDC	...Repeated for module number 19					
1CF0	...Repeated for module number 20					
1D04	...Repeated for module number 21					
1D18	...Repeated for module number 22					
1D2C	...Repeated for module number 23					
1D40	...Repeated for module number 24					
1D54	...Repeated for module number 25					
1D68	...Repeated for module number 26					
1D7C	...Repeated for module number 27					
1D90	...Repeated for module number 28					
1DA4	...Repeated for module number 29					
1DB8	...Repeated for module number 30					
<b>SRCx Node Metering Min Max Values (Read Only) (30 Modules)</b>						
1DCC	SRC X Three Phase Power Factor Min	-999 to 1000	---	1	F013	0
1DCD	SRC X Three Phase Power Factor Min Date	0 to 4294967295	---	1	F050	0
1DCF	SRC X Phase A Power Factor Min	-999 to 1000	---	1	F013	0
1DD0	SRC X Phase A Power Factor Min Date	0 to 4294967295	---	1	F050	0
1DD2	SRC X Phase B Power Factor Min	-999 to 1000	---	1	F013	0
1DD3	SRC X Phase B Power Factor Min Date	0 to 4294967295	---	1	F050	0
1DD5	SRC X Phase C Power Factor Min	-999 to 1000	---	1	F013	0
1DD6	SRC X Phase C Power Factor Min Date	0 to 4294967295	---	1	F050	0
1DD8	SRC X Three Phase Power Factor Max	-999 to 1000	---	1	F013	0
1DD9	SRC X Three Phase Power Factor Max Date	0 to 4294967295	---	1	F050	0
1ddb	SRC X Phase A Power Factor Max	-999 to 1000	---	1	F013	0
1DDC	SRC X Phase A Power Factor Max Date	0 to 4294967295	---	1	F050	0
1DDE	SRC X Phase B Power Factor Max	-999 to 1000	---	1	F013	0
1DDF	SRC X Phase B Power Factor Max Date	0 to 4294967295	---	1	F050	0
1DE1	SRC X Phase C Power Factor Max	-999 to 1000	---	1	F013	0
1DE2	SRC X Phase C Power Factor Max Date	0 to 4294967295	---	1	F050	0
1DE4	SRC X Last Clear Energy Date	0 to 4294967295	---	1	F050	0
1DE6	SRC X Last Commissioned Date	0 to 4294967295	---	1	F050	0
1DE8	SRC X Power Peak Reserved (47 items)					
1E17	...Repeated for module number 2					
1E62	...Repeated for module number 3					
1EAD	...Repeated for module number 4					
1EF8	...Repeated for module number 5					
1F43	...Repeated for module number 6					
1F8E	...Repeated for module number 7					
1FD9	...Repeated for module number 8					
2024	...Repeated for module number 9					
206F	...Repeated for module number 10					
20BA	...Repeated for module number 11					
2105	...Repeated for module number 12					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>SRCx Node Metering Min Max Values (Read Only) (30 Modules) (continued)</b>						
2150	...Repeated for module number 13					
219B	...Repeated for module number 14					
21E6	...Repeated for module number 15					
2231	...Repeated for module number 16					
227C	...Repeated for module number 17					
22C7	...Repeated for module number 18					
2312	...Repeated for module number 19					
235D	...Repeated for module number 20					
23A8	...Repeated for module number 21					
23F3	...Repeated for module number 22					
243E	...Repeated for module number 23					
2489	...Repeated for module number 24					
24D4	...Repeated for module number 25					
251F	...Repeated for module number 26					
256A	...Repeated for module number 27					
25B5	...Repeated for module number 28					
2600	...Repeated for module number 29					
264B	...Repeated for module number 30					
<b>Setting Enable (Read/Write)</b>						
2696	GF Tripping Priority Enable	0 to 1	---	1	F102	0
<b>Source Demand (30 Modules)</b>						
26A2	SRC X Previous Interval kW	-1000000000000 to 1000000000000	W	0,001	F060	0
26A4	SRC X Previous Interval kvar	-1000000000000 to 1000000000000	var	0,001	F060	0
26A6	SRC X Previous Interval kVA	-1000000000000 to 1000000000000	VA	0,001	F060	0
26A8	SRC X Last Reset DateTime	0 to 4294967295	---	1	F050	0
26AA	SRC X Number Of Demand Resets	0 to 4294967295	---	1	F003	0
26AC	SRC X Demand Reset	0 to 1	---	1	F126	0
26AD	SRC X Demand Log Clear Command	0 to 1	---	1	F126	0
26AE	SRC X Demand Log Last Cleared Date	0 to 4294967295	---	1	F050	0
26B0	SRC X Demand Log Records Since Last Clear	0 to 4294967295	---	1	F003	0
26B2	SRC X Demand Log Interval Records Available	0 to 4294967295	---	1	F003	0
26B4	SRC X Demand Reserved (20 items)					
26C8	...Repeated for module number 2					
26EE	...Repeated for module number 3					
2714	...Repeated for module number 4					
273A	...Repeated for module number 5					
2760	...Repeated for module number 6					
2786	...Repeated for module number 7					
27AC	...Repeated for module number 8					
27D2	...Repeated for module number 9					
27F8	...Repeated for module number 10					
281E	...Repeated for module number 11					
2844	...Repeated for module number 12					
286A	...Repeated for module number 13					
2890	...Repeated for module number 14					
28B6	...Repeated for module number 15					
28DC	...Repeated for module number 16					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Demand (30 Modules) (continued)</b>						
2902	...Repeated for module number 17					
2928	...Repeated for module number 18					
294E	...Repeated for module number 19					
2974	...Repeated for module number 20					
299A	...Repeated for module number 21					
29C0	...Repeated for module number 22					
29E6	...Repeated for module number 23					
2A0C	...Repeated for module number 24					
2A32	...Repeated for module number 25					
2A58	...Repeated for module number 26					
2A7E	...Repeated for module number 27					
2AA4	...Repeated for module number 28					
2ACA	...Repeated for module number 29					
2AF0	...Repeated for module number 30					
<b>SRCx As Reported At Node Status (Read Only) (30 Modules)</b>						
2B16	SRC X Node ID	0 to 29	---	1	F001	0
2B17	SRC X Node MAC Address	---	---	---	F072	{0}
2B1A	SRC X Frame Rating	0 to 65535	---	1	F001	0
2B1B	SRC X CT Rating	0 to 65535	---	1	F001	0
2B1C	SRC X Breaker Type	0 to 65535	---	1	F715	0
2B1D	SRC X NodeProt Protection Config	0 to 65535	---	1	F705	0
2B1E	SRC X Node Firmware Version	0 to 65535	---	1	F001	0
2B1F	SRC X Hardware Version	0 to 255	---	1	F001	0
2B20	SRC X Message Protocol Version	0 to 65535	---	1	F001	0
2B21	SRC X Product Type	0 to 65535	---	1	F716	0
2B22	SRC X NodeProt Rating Switch	0 to 65535	---	1	F001	0
2B23	SRC X NodeProt LT Setting	0 to 65535	---	1	F001	0
2B24	SRC X NodeProt IOC Threshold Setting	0 to 65535	---	1	F001	0
2B25	SRC X NodeProt Ground Fault Setting	0 to 65535	---	1	F001	0
2B26	SRC X NodeProt Short Time Setting	0 to 65535	---	1	F001	0
2B27	SRC X Node Internal Diagnostics	0 to 65535	---	1	F701	0
2B28	SRC X Node System Diagnostics 1	0 to 65535	---	1	F702	0
2B29	SRC X Node System Diagnostics 2	0 to 65535	---	1	F703	0
2B2A	SRC X Node Hardware Diagnostics	0 to 65535	---	1	F704	0
2B2B	SRC X Node Physical Status	0 to 65535	---	1	F708	0
2B2C	SRC X Node Logic and Trip Status	0 to 65535	---	1	F709	0
2B2D	SRC X Node Last Trip Sequence Number	0 to 4294967295	---	1	F003	0
2B2F	SRC X Reflected CCPU Diagnostics	0 to 65535	---	1	F706	0
2B30	SRC X Reflected CCPU 0 Command	0 to 65535	---	1	F707	0
2B31	SRC X Reflected CCPU 1 Command	0 to 65535	---	1	F707	0
2B32	SRC X Fan Status	0 to 1	---	1	F108	0
2B33	SRC X CT Rating Node Report	0 to 65535	---	1	F001	0
2B34	SRC X Node Serial Number	---	---	---	F205	0
2B3A	SRC X Phase A Frequency	0 to 65535	Hz	1	F001	0
2B3B	SRC X Phase B Frequency	0 to 65535	Hz	1	F001	0
2B3C	SRC X Phase C Frequency	0 to 65535	Hz	1	F001	0
2B3D	SRC X Topology	0 to 15	---	1	F001	1
2B3E	SRC X ST ZSI Current Restrained Time	0 to 65535	mS	1	F001	0

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>SRCx As Reported At Node Status (Read Only) (30 Modules) (Continued)</b>						
2B3F	SRC X NodeProt Adjustable Selective IOC Setting	0 to 48	Half Cycle	1	F001	0
2B40	Reserved (2 items)					
2B66	...Repeated for module number 2					
2BB6	...Repeated for module number 3					
2C06	...Repeated for module number 4					
2C56	...Repeated for module number 5					
2CA6	...Repeated for module number 6					
2CF6	...Repeated for module number 7					
2D46	...Repeated for module number 8					
2D96	...Repeated for module number 9					
2DE6	...Repeated for module number 10					
2E36	...Repeated for module number 11					
2E86	...Repeated for module number 12					
2ED6	...Repeated for module number 13					
2F26	...Repeated for module number 14					
2F76	...Repeated for module number 15					
2FC6	...Repeated for module number 16					
3016	...Repeated for module number 17					
3066	...Repeated for module number 18					
30B6	...Repeated for module number 19					
3106	...Repeated for module number 20					
3156	...Repeated for module number 21					
31A6	...Repeated for module number 22					
31F6	...Repeated for module number 23					
3246	...Repeated for module number 24					
3296	...Repeated for module number 25					
32E6	...Repeated for module number 26					
3336	...Repeated for module number 27					
3386	...Repeated for module number 28					
33D6	...Repeated for module number 29					
3426	...Repeated for module number 30					
<b>SRCx Node Counters (Read/Write) - Write a 0 to these to reset them</b>						
3476	Reserved (840 items)	0 to 65535	---	1	F001	0
<b>Source Settings (Read/Write) (30 Modules)</b>						
37BE	SRC X Node Commissioned	0 to 1	---	1	F102	0
37BF	SRC X PT Source Node Identifier	0 to 29	---	1	F001	0
37C0	SRC X Breaker Connection	0 to 1	---	1	F712	0
37C1	Source Settings Reserved (17 items)					
37D2	SRC X PT Rating	0 to 7	---	1	F719	0
37D3	SRC X UV Trip Enable	0 to 1	---	1	F102	0
37D4	SRC X UV Trip Curve Type	0 to 1	---	1	F726	1
37D5	SRC X UV Trip Pickup Setting	10 to 95	%	1	F001	50
37D6	SRC X UV Trip Time Delay	5 to 6000	S	5	F001	300
37D7	SRC X UV Trip Phase Requirement	1 to 3	---	1	F001	1
37D8	SRC X UV Trip Block Volt Enable	0 to 1	---	1	F102	0
37D9	SRC X UV Trip Block Volt Setting	5 to 75	%	1	F001	5
37DA	SRC X UV Trip or Open Setting	0 to 1	---	1	F727	1
37DB	SRC X UV Alarm Enable	0 to 1	---	1	F102	0

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Settings (Read/Write) (30 Modules) (Continued)</b>						
37DC	SRC X UV Alarm Curve Type	0 to 1	---	1	F726	1
37DD	SRC X UV Alarm Pickup Setting	10 to 95	%	1	F001	50
37DE	SRC X UV Alarm Time Delay	5 to 6000	S	5	F001	150
37DF	SRC X UV Alarm Phase Requirement	1 to 3	---	1	F001	1
37E0	SRC X UV Alarm Block Volt Enable	0 to 1	---	1	F102	0
37E1	SRC X UV Alarm Block Volt Setting	5 to 75	%	1	F001	5
37E2	SRC X OV Trip Enable	0 to 1	---	1	F102	0
37E3	SRC X OV Trip Pickup Setting	105 to 125	%	1	F001	120
37E4	SRC X OV Trip Time Delay	5 to 6000	S	5	F001	300
37E5	SRC X OV Trip Phase Requirement	1 to 3	---	1	F001	1
37E6	SRC X OV Trip or Open Setting	0 to 1	---	1	F727	1
37E7	SRC X OV Alarm Enable	0 to 1	---	1	F102	0
37E8	SRC X OV Alarm Pickup Threshold	105 to 125	%	1	F001	120
37E9	SRC X OV Alarm Time Delay	5 to 6000	S	5	F001	150
37EA	SRC X OV Alarm Phase Requirement	1 to 3	---	1	F001	1
37EB	Source Settings Reserved 2 (7 items)					
37F2	SRC X PL Trip Enable	0 to 1	---	1	F102	0
37F3	SRC X PL Trip Pickup Setting	8 to 50	%V	1	F001	8
37F4	SRC X PL Trip Time Delay	5 to 6000	S	5	F001	300
37F5	SRC X PL Trip Block Volt Enable	0 to 1	---	1	F102	0
37F6	SRC X PL Trip or Open Setting	0 to 1	---	1	F727	1
37F7	SRC X PL Alarm Enable	0 to 1	---	1	F102	0
37F8	SRC X PL Alarm Pickup Setting	8 to 50	%V	1	F001	8
37F9	SRC X PL Alarm Time Delay	5 to 6000	S	5	F001	150
37FA	SRC X PL Alarm Block Volt Enable	0 to 1	---	1	F102	0
37FB	SRC X PL Trip Blocking Voltage Setting	5 to 5	%	1	F001	5
37FC	SRC X PL Alarm Blocking Voltage Setting	5 to 5	%	1	F001	5
37FD	Source Settings Reserved 3 (3 items)					
3800	SRC X Rev Power Trip Enable	0 to 1	---	1	F102	0
3801	SRC X Rev Power Trip Pickup Setting	10 to 990	S	10	F001	990
3802	SRC X Rev Power Trip Time Delay	5 to 6000	S	5	F001	300
3803	SRC X Rev Power Alarm Enable	0 to 1	---	1	F102	0
3804	SRC X Rev Power Alarm Pickup Setting	10 to 990	kW	10	F001	990
3805	SRC X Rev Power Alarm Time Delay	5 to 6000	S	5	F001	150
3806	SRC X Rev Power Trip or Open	0 to 1	---	1	F727	1
3807	Source Settings Reserved 4 (4 items)					
380B	SRC X High Curr Alarm Enable	0 to 1	---	1	F102	0
380C	SRC X High Curr Alarm Pickup Setting	50 to 200	%LT Pickup	5	F001	200
380D	SRC X High Curr Alarm Time Delay	1 to 15	S	1	F001	15
380E	Source Settings Reserved 5 (5 items)					
3813	SRC X Total Breaker Operations	0 to 65535	---	1	F001	0
3814	SRC X Total Breaker No Load Operations	0 to 65535	---	1	F001	0
3815	SRC X Total Breaker Load Operations	0 to 65535	---	1	F001	0
3816	SRC X Total Breaker Fault Operations	0 to 65535	---	1	F001	0
3817	SRC X Breaker Percent Load Life	0 to 65535	%	1	F001	0
3818	SRC X Breaker Percent Mechanical Life	0 to 65535	%	1	F001	0
3819	SRC X Time Date Last Breaker Operation	0 to 4294967295	---	1	F050	0
381B	SRC X Time Date Initial Energization	0 to 4294967295	---	1	F050	0

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Settings (Read/Write) (30 Modules) (Continued)</b>						
381D	SRC X Breaker Service Hours	0 to 4294967295	Hrs	1	F003	0
381F	Source Settings Reserved 6 (5 items)					
3824	SRC X UF Trip Enable	0 to 1	---	1	F102	0
3825	SRC X UF Trip Pickup Setting	450 to 600	Hz	1	F001	450
3826	SRC X UF Trip Time Delay	1 to 6000	S	1	F001	300
3827	SRC X UF Trip Blocking Voltage Enable	0 to 1	---	1	F102	0
3828	SRC X UF Trip or Open setting	0 to 1	---	1	F727	1
3829	SRC X UF Alarm Enable	0 to 1	---	1	F102	0
382A	SRC X UF Alarm Pickup Setting	450 to 600	Hz	1	F001	450
382B	SRC X UF Alarm Time Delay	1 to 6000	S	1	F001	150
382C	SRC X UF Alarm Blocking Voltage Enable	0 to 1	---	1	F102	0
382D	SRC X OF Trip Enable	0 to 1	---	1	F102	0
382E	SRC X OF Trip Pickup Setting	500 to 700	Hz	1	F001	500
382F	SRC X OF Trip Time Delay	1 to 6000	S	1	F001	300
3830	SRC X OF Trip Blocking Voltage Enable	0 to 1	---	1	F102	0
3831	SRC X OF Trip or Open setting	0 to 1	Hz	1	F727	1
3832	SRC X OF Alarm Enable	0 to 1	---	1	F102	0
3833	SRC X OF Alarm Pickup Setting	500 to 700	Hz	1	F001	500
3834	SRC X OF Alarm Time Delay	1 to 6000	S	1	F001	150
3835	SRC X OF Alarm Blocking Voltage Enable	0 to 1	---	1	F102	0
3836	SRC X HRGF Enable	0 to 1	---	1	F102	0
3837	SRC X HRGF Pickup	1 to 100	A	1	F001	20
3838	SRC X HRGF Delay	5 to 50	S	1	F001	5
3839	SRC X HRGF Ground Resistance	5 to 500	Ohm	1	F001	5
383A	SRC X HRGF CT Rating	10 to 10	A	1	F001	10
383B	SRC X Reverse Current Protection Switch	0 to 1	---	1	F102	0
383C	SRC X Reverse Current Pickup Setting	15 to 90	---	5	F001	50
383D	SRC X Reverse Current I2T Curve	0 to 1	---	1	F102	0
383E	SRC X Reverse Current Delay Band Setting	0 to 6	---	1	F713	2
383F	SRC X Reverse Current Alarm Protection Switch	0 to 1	---	1	F102	0
3840	SRC X Reverse Current Alarm Pickup Setting	15 to 90	---	5	F001	50
3841	SRC X Reverse Current Alarm I2T Curve	0 to 1	---	1	F102	0
3842	SRC X Reverse Current Alarm Delay Band Setting	0 to 6	---	1	F713	2
3843	SRC X High Curr Trigger Alarm Enable	0 to 1	---	1	F102	0
3844	SRC X High Curr Trigger Alarm Pickup Setting	1 to 90	%LT Pickup	1	F001	20
3845	SRC X High Curr Trigger Alarm Delay Setting	1 to 120	S	1	F001	12
3846	SRC X High Curr Trigger Alarm WFC Enable	0 to 1	---	1	F102	0
3847	SRC X High Curr Trigger Alarm Max WF	0 to 30	---	1	F001	15
3848	SRC X High Curr Trigger Alarm WF Triggered	0 to 30	---	1	F001	0
3849	SRC X High Curr Trigger Alarm WF Count Reset	0 to 1	---	1	F126	0
384A	SRC X Settings Reserved (40 items)					
3872	...Repeated for module number 2					
3926	...Repeated for module number 3					
39DA	...Repeated for module number 4					
3A8E	...Repeated for module number 5					
3B42	...Repeated for module number 6					
3BF6	...Repeated for module number 7					
3CAA	...Repeated for module number 8					

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Settings (Read/Write) (30 Modules) (Continued)</b>						
3D5E	...Repeated for module number 9					
3E12	...Repeated for module number 10					
3EC6	...Repeated for module number 11					
3F7A	...Repeated for module number 12					
402E	...Repeated for module number 13					
40E2	...Repeated for module number 14					
4196	...Repeated for module number 15					
424A	...Repeated for module number 16					
42FE	...Repeated for module number 17					
43B2	...Repeated for module number 18					
4466	...Repeated for module number 19					
451A	...Repeated for module number 20					
45CE	...Repeated for module number 21					
4682	...Repeated for module number 22					
4736	...Repeated for module number 23					
47EA	...Repeated for module number 24					
489E	...Repeated for module number 25					
4952	...Repeated for module number 26					
4A06	...Repeated for module number 27					
4ABA	...Repeated for module number 28					
4B6E	...Repeated for module number 29					
4C22	...Repeated for module number 30					
3838	SRC X HRGF Delay	5 to 50	S	1	F001	5
3839	SRC X HRGF Ground Resistance	5 to 500	Ohm	1	F001	5
383A	SRC X HRGF CT Rating	10 to 10	A	1	F001	10
383B	SRC X Reverse Current Protection Switch	0 to 1	---	1	F102	0
383C	SRC X Reverse Current Pickup Setting	15 to 90	---	5	F001	50
383D	SRC X Reverse Current I2T Curve	0 to 1	---	1	F102	0
383E	SRC X Reverse Current Delay Band Setting	0 to 6	---	1	F713	2
<b>SRC X Node Command Registers (Read / Write) (30 Modules)</b>						
4CD6	SRC X Open Breaker	0 to 1	---	1	F126	0
4CD7	SRC X Close Breaker	0 to 1	---	1	F126	0
4CD8	SRC X Trip Breaker	0 to 1	---	1	F126	0
4CD9	SRC X Clear Energy	0 to 1	---	1	F126	0
4CDA	SRC X Delete Node	0 to 1	---	1	F126	0
4CDB	SRC X Remote Lockout Enable	0 to 1	---	1	F126	0
4CDC	SRC X Remote Lockout Reset	0 to 1	---	1	F126	0
4CDD	SRC X Machine Output Energize	0 to 1	---	1	F126	0
4CDE	SRC X Machine Output De-energize	0 to 1	---	1	F126	0
4CDF	SRC X Command Reserved					
4CF4	...Repeated for module number 2					
4D12	...Repeated for module number 3					
4D30	...Repeated for module number 4					
4D4E	...Repeated for module number 5					
4D6C	...Repeated for module number 6					
4D8A	...Repeated for module number 7					
4DA8	...Repeated for module number 8					
4DC6	...Repeated for module number 9					
4DE4	...Repeated for module number 10					
4E02	...Repeated for module number 11					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>SRC X Node Command Registers (Read / Write) (30 Modules) (Continued)</b>						
4E20	...Repeated for module number 12					
4E3E	...Repeated for module number 13					
4E5C	...Repeated for module number 14					
4E7A	...Repeated for module number 15					
4E98	...Repeated for module number 16					
4EB6	...Repeated for module number 17					
4ED4	...Repeated for module number 18					
4EF2	...Repeated for module number 19					
4F10	...Repeated for module number 20					
4F2E	...Repeated for module number 21					
4F4C	...Repeated for module number 22					
4F6A	...Repeated for module number 23					
4F88	...Repeated for module number 24					
4FA6	...Repeated for module number 25					
4FC4	...Repeated for module number 26					
4FE2	...Repeated for module number 27					
5000	...Repeated for module number 28					
501E	...Repeated for module number 29					
503C	...Repeated for module number 30					
<b>SynchCheck Settings (Read/Write) (12 Modules)</b>						
505A	Synch Check Enable	0 to 1	---	1	F102	0 (Disabled)
505B	Synch Check V1 Source	0 to 29	---	1	F001	0
505C	Synch Check V2 Source	0 to 29	---	1	F001	0
505D	Synch Check Max Volt Diff	0 to 900	V	5	F001	0
505E	Synch Check Max Phase Diff	0 to 60	Deg	1	F001	0
505F	Synch Check Max Freq Diff	0 to 20	Hz	1	F001	0
5060	Synch Check Dead Max V1	5 to 50	%	1	F001	5
5061	Synch Check Live Min V1	50 to 100	%	1	F001	50
5062	Synch Check Dead Max V2	5 to 50	%	1	F001	5
5063	Synch Check Live Min V2	50 to 100	%	1	F001	50
5064	Reserved (4 items)	5 to 50	---	1	F001	5
5068	Synch Check Dead Source Select	0 to 5	---	1	F176	0 (None selected)
5069	SynchCheck Status	0 to 65535	---	1	F001	0
506A	Synch Check Reserved (14 items)					
5078	...Repeated for module number 2					
5096	...Repeated for module number 3					
50B4	...Repeated for module number 4					
50D2	...Repeated for module number 5					
50F0	...Repeated for module number 6					
510E	...Repeated for module number 7					
512C	...Repeated for module number 8					
514A	...Repeated for module number 9					
5168	...Repeated for module number 10					
5186	...Repeated for module number 11					
51A4	...Repeated for module number 12					
<b>ZSI Option Settings (Read/Write)</b>						
51C2	ZSI Option	0 to 2	---	1	F732	0

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>ZSI Zone Enables (Read/Write Setting) (4 Modules)</b>						
51C4	ZSI Zone X Enabled	0 to 1	---	1	F126	0
51C5	ZSI Zone Enable Reserved (4 items)					
51C9	...Repeated for Zone 2					
51CE	...Repeated for Zone 3					
51D3	...Repeated for Zone 4					
<b>Simple Network Time Protocol (SNTP) (Read/Write)</b>						
51DD	SNTP Server IP Address	0 to 4294967295	---	1	F003	0
51DF	SNTP Server Time Zone Bias	-46800 to 43200	---	900	F004	0
<b>Redundant Trip Coil Enable (Read/Write)</b>						
51E2	Redundant Trip Coil Enable	0 to 1	---	1	F102	0
<b>ZSI ST Tier Settings (Read/Write Setting) (30 Modules)</b>						
5200	SRC X ST ZSI Zone 1 Tier Settings (16 items)	0 to 3	---	1	F733	0
5210	SRC X ST ZSI Zone 2 Tier Settings (16 items)	0 to 3	---	1	F733	0
5220	SRC X ST ZSI Zone 3 Tier Settings (16 items)	0 to 3	---	1	F733	0
5230	SRC X ST ZSI Zone 4 Tier Settings (16 items)	0 to 3	---	1	F733	0
5240	SRC X ST External ZSI Restrained Time Setting	0 to 7		1	F740	0
5250	...Repeated for module number 2					
52A0	...Repeated for module number 3					
52F0	...Repeated for module number 4					
5340	...Repeated for module number 5					
5390	...Repeated for module number 6					
53E0	...Repeated for module number 7					
5430	...Repeated for module number 8					
5480	...Repeated for module number 9					
54D0	...Repeated for module number 10					
5520	...Repeated for module number 11					
5570	...Repeated for module number 12					
55C0	...Repeated for module number 13					
5610	...Repeated for module number 14					
5660	...Repeated for module number 15					
56B0	...Repeated for module number 16					
5700	...Repeated for module number 17					
5750	...Repeated for module number 18					
57A0	...Repeated for module number 19					
57F0	...Repeated for module number 20					
5840	...Repeated for module number 21					
5890	...Repeated for module number 22					
58E0	...Repeated for module number 23					
5930	...Repeated for module number 24					
5980	...Repeated for module number 25					
59D0	...Repeated for module number 26					
5A20	...Repeated for module number 27					
5A70	...Repeated for module number 28					
5AC0	...Repeated for module number 29					
5B10	...Repeated for module number 30					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>ZSI GF Tier Settings (Read/Write Setting) (30 Modules)</b>						
5B60	SRC X GF ZSI Zone 1 Tier Settings (16 items)	0 to 3	---	1	F733	0
5B70	SRC X GF ZSI Zone 2 Tier Settings (16 items)	0 to 3	---	1	F733	0
5B80	SRC X GF ZSI Zone 3 Tier Settings (16 items)	0 to 3	---	1	F733	0
5B90	SRC X GF ZSI Zone 4 Tier Settings (16 items)	0 to 3	---	1	F733	0
5BA0	SRC X GF ZSI Tier Settings Reserved (16 items)					
5BB0	...Repeated for module number 2					
5C00	...Repeated for module number 3					
5C50	...Repeated for module number 4					
5CA0	...Repeated for module number 5					
5CF0	...Repeated for module number 6					
5D40	...Repeated for module number 7					
5D90	...Repeated for module number 8					
5DE0	...Repeated for module number 9					
5E30	...Repeated for module number 10					
5E80	...Repeated for module number 11					
5ED0	...Repeated for module number 12					
5F20	...Repeated for module number 13					
5F70	...Repeated for module number 14					
5FC0	...Repeated for module number 15					
6010	...Repeated for module number 16					
6060	...Repeated for module number 17					
60B0	...Repeated for module number 18					
6100	...Repeated for module number 19					
6150	...Repeated for module number 20					
61A0	...Repeated for module number 21					
61F0	...Repeated for module number 22					
6240	...Repeated for module number 23					
6290	...Repeated for module number 24					
62E0	...Repeated for module number 25					
6330	...Repeated for module number 26					
6380	...Repeated for module number 27					
63D0	...Repeated for module number 28					
6420	...Repeated for module number 29					
6470	...Repeated for module number 30					
<b>ZSI MSGF Zone GRP X Tier Settings (Read/Write Setting) (4 Modules)</b>						
64C0	MSGF ZSI Zone 1 GRP X Tier Settings (16 items)	0 to 3	---	1	F733	0
64D0	MSGF ZSI Zone 2 GRP X Tier Settings (16 items)	0 to 3	---	1	F733	0
64E0	MSGF ZSI Zone 3 GRP X Tier Settings (16 items)	0 to 3	---	1	F733	0
64F0	MSGF ZSI Zone 4 GRP X Tier Settings (16 items)	0 to 3	---	1	F733	0
6500	MSGF ZSI Reserved (16 items)					
6510	...Repeated for Zone 2					
6560	...Repeated for Zone 3					
65B0	...Repeated for Zone 4					
<b>Zone X MSGF Settings (Read/Write Setting) (4 Modules)</b>						
6600	Zone X MSGF Trip Pickup Setting (16 items)	30 to 1200	A	10	F001	1200
6610	Zone X MSGF Alarm Pickup Setting (16 items)	30 to 1200	A	10	F001	1200

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Zone X MSGF Settings (Read/Write Setting) (4 Modules) (Continued)</b>						
6620	Zone X MSGF Trip Delay Band Setting (16 items)	0 to 6	---	1	F735	2
6630	Zone X MSGF Alarm Delay Band Setting (16 items)	0 to 6	---	1	F735	2
6640	Zone X MSGF Trip I2T Curve (16 items)	0 to 1	---	1	F102	0
6650	Zone X MSGF Alarm I2T Curve (16 items)	0 to 1	---	1	F102	0
6660	Zone X MSGF Trip Enabled (16 items)	0 to 1	---	1	F102	0
6670	Zone X MSGF Alarm Enabled (16 items)	0 to 1	---	1	F102	0
6680	Zone X MSGF Backup Enabled (16 items)	0 to 1	---	1	F102	0
6690	Zone X MSGF Backup Time Delta Enabled (16 items)	0 to 1	---	1	F102	0
66A0	Zone X MSGF Trip or Open	0 to 1	---	1	F727	0
66A1	Zone X MSGF Reserved (16 items)					
66B1	...Repeated for Zone 2					
6762	...Repeated for Zone 3					
6813	...Repeated for Zone 4					
<b>Zone X BD Settings (Read/Write Setting) (4 Modules)</b>						
68C4	Zone X BD Trip Pickup Setting (16 items)	100 to 22000	A	100	F001	1200
68D4	Zone X BD Alarm Pickup Setting (16 items)	100 to 22000	A	100	F001	1200
68E4	Zone X BD Trip Pickup Setting2 (16 items)	100 to 22000	A	100	F001	1200
68F4	Zone X BD Alarm Pickup Setting2 (16 items)	100 to 22000	A	100	F001	1200
6904	Zone X BD Trip Delay Band Setting (16 items)	0 to 6		1	F735	2
6914	Zone X BD Alarm Delay Band Setting (16 items)	0 to 6	---	1	F735	2
6924	Zone X BD Trip Delay Band Setting2 (16 items)	0 to 6		1	F735	2
6934	Zone X BD Alarm Delay Band Setting2 (16 items)	0 to 6	---	1	F735	2
6944	Zone X BD Trip Enabled (16 items)	0 to 1	---	1	F102	0
6954	Zone X BD Alarm Enabled (16 items)	0 to 1	---	1	F102	0
6964	Zone X BD Backup Enabled (16 items)	0 to 1	---	1	F102	0
6974	Zone X BD Backup Time Delta Enabled (16 items)	0 to 1	---	1	F102	0
6984	Zone X BD Trip or Open	0 to 1	---	1	F727	0
6985	Zone X BD Reserved (16 items)					
6995	...Repeated for Zone 2					
6A66	...Repeated for Zone 3					
6B37	...Repeated for Zone 4					
<b>Zone X Summation Settings (Read/Write Setting) (2 Modules)</b>						
6C08	Zone X Summation MSGF Trip Delay Band Setting (16 items)	0 to 6	---	1	F735	2
6C18	Zone X Summation MSGF Alarm Delay Band Setting (16 items)	0 to 6	---	1	F735	2
6C28	Zone X Summation MSGF Trip I2T Curve (16 items)	0 to 1	---	1	F102	0
6C38	Zone X Summation MSGF Alarm I2T Curve (16 items)	0 to 1	---	1	F102	0
6C48	Zone X Summation MSGF Trip Enabled (16 items)	0 to 1	---	1	F102	0
6C58	Zone X Summation MSGF Alarm Enabled (16 items)	0 to 1	A	1	F102	0
6C68	Zone X Summation MSGF Trip Pickup Setting (16 items)	30 to 1200	A	10	F001	1200

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Zone X Summation Settings (Read/Write Setting) (2 Modules) (Continued)</b>						
6C78	Zone X Summation MSGF Alarm Pickup Setting (16 items)	30 to 1200	A	10	F001	1200
6C88	Zone X Summation MSGF Trip or Open	0 to 1	---	1	F727	0
6C89	Zone X Summation Reserved (16 items)					
6CA9	...Repeated for Zone 2					
<b>Options (Read Only)</b>						
6D4A	Reserved (242 items)	---	---	---	F077	"0"
6E3C	Option String Authentication Status	0 to 2	---	1	F738	0 (invalid)
6E3D	Option String Timestamp	0 to 4294967295	---	1	F050	0
6E3F	Option Bit Vectors	0 to 65535	---	1	F728	0
6E40	Option Expanded Metering Count	0 to 30	---	1	F001	0
6E41	Option Expanded Metering Node x State Enable	0 to 4294967295	---	1	F722	0
6E43	Option Demand Metering Count	0 to 30	---	1	F001	0
6E44	Option Demand Metering Node x State Enable	0 to 4294967295	---	1	F722	0
6E46	Option Advanced Metering Count	0 to 30	---	1	F001	0
6E47	Option Advanced Metering Node x State Enable	0 to 4294967295	---	1	F722	0
6E49	Option Voltage Relay Count	0 to 30	---	1	F001	0
6E4A	Option Voltage Relay Node x State Enable	0 to 4294967295	---	1	F722	0
6E4C	Option High Current Relay Count	0 to 30	---	1	F001	0
6E4D	Option High Current Relay Node x State Enable	0 to 4294967295	---	1	F722	0
6E4F	Option Freq and Rev Pwr Relay Count	0 to 30	---	1	F001	0
6E50	Option Freq Rev Pwr Relay Node x State Enable	0 to 4294967295	---	1	F722	0
6E52	Reserved (3 items)	---	---	---	---	---
6E55	Option HRGF Location Count	0 to 4	---	1	F001	0
6E56	Option HRGF Location Zone x State Enable	0 to 15	---	1	F722	0
<b>Self Test Targets (Read Only)</b>						
6E64	Reserved (4 items)	0 to 4294967295		1	F143	0
<b>Function X HRGF Location Settings (Read/Write Settings) (4 Modules)</b>						
6E80	Zone X HRGF Location Auto Mode Enabled	0 to 1	---	1	F102	1
6E81	Zone X HRGF Location Main Breaker	0 to 30	---	1	F001	30
6E82	Zone X HRGF Location ReAlarm Delay	0 to 99	Hrs	1	F001	8
6E83	Zone X HRGF Location Alarm ReCheck Delay	0 to 99	S	1	F001	2
6E84	Zone X HRGF Location Trip Delay	0 to 999	Hrs	1	F001	0
6E85	Zone X HRGF Location Trip Enabled	0 to 1	---	1	F102	0
6E86	Zone X HRGF Location Settings Reserved (4 items)					
6E8A	...Repeated for Zone 2					
6E94	...Repeated for Zone 3					
6E9E	...Repeated for Zone 4					
<b>Function X HRGF Location (Read/Write Settings)</b>						
6EA8	Zone X HRGF Location Manual Mode Start	0 to 1	---	1	F102	0
6EA9	Zone X HRGF Location Contactor Frequency	50 to 200	Hz	25	F001	100
6EAA	Zone X HRGF Location Contactor Duty Cycle	0 to 100	%	1	F001	50
6EAB	Zone X HRGF Location Manual Function To Start	0 to 4	---	1	F001	0
6EAC	Zone X HRGF Location Manual Availability	0 to 15	---	1	F500	0
6EAD	Zone X HRGF Location Test Contactor Pulsing	0 to 4	---	1	F001	0
6EAE	Zone X HRGF Location Subinterval	20 to 60	S	5	F001	20

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Contact Input Configuration (Read/Write Setting) (2 Modules)</b>						
7003	Board 1 I/O Direction High	0 to 4294967295	---	1	F737	0
7005	Board 1 I/O Direction Low	0 to 4294967295	---	1	F736	0
7007	Board 2 I/O Direction High	0 to 4294967295	---	1	F737	0
7009	Board 2 I/O Direction Low	0 to 4294967295	---	1	F736	0
<b>Discrete I/O Configuration (Read Only)</b>						
702A	Boards Detected	0 to 16	---	1	F001	0
702B	Boards Used	0 to 16	---	1	F001	0
702C	Total I/O Points Available	0 to 65535	---	1	F001	0
702D	Contact Input Count	0 to 128	---	1	F001	0
702E	Contact Output Count	0 to 128	---	1	F001	0
702F	Boards Expected	0 to 16	---	1	F001	0
7030	Remote IO Stations Detected	0 to 4		1	F001	0
7031	Discrete IO Type	0 to 2		1	F008	0
7032	Configured Discrete IO Type	0 to 2		1	F001	0
<b>Expanded Digital I/O states (Read Only) (128 Modules)</b>						
703F	Contact Input x State (128 items)	1 to 128	---	1	F108	0 (Off)
70BF	Contact Output x State (128 items)	1 to 128	---	1	F108	0 (Off)
<b>Contact Inputs (Read/Write setting) (128 Modules)</b>						
713F	Contact Input x Name	---	---	---	F200	"Cont Input x".
7153	Contact Input x Events	0 to 1	---	1	F102	1 (Enabled)
7154	Contact Input x Debounce Time	0 to 4		1	F734	0
7155	Contact Input x Reserved (4 items)					
7159	...Repeated for module number 2					
7173	...Repeated for module number 3					
718D	...Repeated for module number 4					
71A7	...Repeated for module number 5					
71C1	...Repeated for module number 6					
71DB	...Repeated for module number 7					
71F5	...Repeated for module number 8					
720F	...Repeated for module number 9					
7229	...Repeated for module number 10					
7243	...Repeated for module number 11					
725D	...Repeated for module number 12					
7277	...Repeated for module number 13					
7291	...Repeated for module number 14					
72AB	...Repeated for module number 15					
72C5	...Repeated for module number 16					
72DF	...Repeated for module number 17					
72F9	...Repeated for module number 18					
7313	...Repeated for module number 19					
732D	...Repeated for module number 20					
7347	...Repeated for module number 21					
7361	...Repeated for module number 22					
737B	...Repeated for module number 23					
7395	...Repeated for module number 24					
73AF	...Repeated for module number 25					
73C9	...Repeated for module number 26					
73E3	...Repeated for module number 27					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Contact Inputs (Read/Write setting) (128 Modules) (Continued)</b>						
73FD	...	Repeated for module number 28				
7417	...	Repeated for module number 29				
7431	...	Repeated for module number 30				
744B	...	Repeated for module number 31				
7465	...	Repeated for module number 32				
747F	...	Repeated for module number 33				
7499	...	Repeated for module number 34				
74B3	...	Repeated for module number 35				
74CD	...	Repeated for module number 36				
74E7	...	Repeated for module number 37				
7501	...	Repeated for module number 38				
751B	...	Repeated for module number 39				
7535	...	Repeated for module number 40				
754F	...	Repeated for module number 41				
7569	...	Repeated for module number 42				
7583	...	Repeated for module number 43				
759D	...	Repeated for module number 44				
75B7	...	Repeated for module number 45				
75D1	...	Repeated for module number 46				
75EB	...	Repeated for module number 47				
7605	...	Repeated for module number 48				
761F	...	Repeated for module number 49				
7639	...	Repeated for module number 50				
7653	...	Repeated for module number 51				
766D	...	Repeated for module number 52				
7687	...	Repeated for module number 53				
76A1	...	Repeated for module number 54				
76BB	...	Repeated for module number 55				
76D5	...	Repeated for module number 56				
76EF	...	Repeated for module number 57				
7709	...	Repeated for module number 58				
7723	...	Repeated for module number 59				
773D	...	Repeated for module number 60				
7757	...	Repeated for module number 61				
7771	...	Repeated for module number 62				
778B	...	Repeated for module number 63				
77A5	...	Repeated for module number 64				
77BF	...	Repeated for module number 65				
77D9	...	Repeated for module number 66				
77F3	...	Repeated for module number 67				
780D	...	Repeated for module number 68				
7827	...	Repeated for module number 69				
7841	...	Repeated for module number 70				
785B	...	Repeated for module number 71				
7875	...	Repeated for module number 72				
788F	...	Repeated for module number 73				
78A9	...	Repeated for module number 74				
78C3	...	Repeated for module number 75				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Contact Inputs (Read/Write setting) (128 Modules) (Continued)</b>						
78DD	...	Repeated for module number 76				
78F7	...	Repeated for module number 77				
7911	...	Repeated for module number 78				
792B	...	Repeated for module number 79				
7945	...	Repeated for module number 80				
795F	...	Repeated for module number 81				
7979	...	Repeated for module number 82				
7993	...	Repeated for module number 83				
79AD	...	Repeated for module number 84				
79C7	...	Repeated for module number 85				
79E1	...	Repeated for module number 86				
79FB	...	Repeated for module number 87				
7A15	...	Repeated for module number 88				
7A2F	...	Repeated for module number 89				
7A49	...	Repeated for module number 90				
7A63	...	Repeated for module number 91				
7A7D	...	Repeated for module number 92				
7A97	...	Repeated for module number 93				
7AB1	...	Repeated for module number 94				
7ACB	...	Repeated for module number 95				
7AE5	...	Repeated for module number 96				
7AFF	...	Repeated for module number 97				
7B19	...	Repeated for module number 98				
7B33	...	Repeated for module number 99				
7B4D	...	Repeated for module number 100				
7B67	...	Repeated for module number 101				
7B81	...	Repeated for module number 102				
7B9B	...	Repeated for module number 103				
7BB5	...	Repeated for module number 104				
7BCF	...	Repeated for module number 105				
7BE9	...	Repeated for module number 106				
7C03	...	Repeated for module number 107				
7C1D	...	Repeated for module number 108				
7C37	...	Repeated for module number 109				
7C51	...	Repeated for module number 110				
7C6B	...	Repeated for module number 111				
7C85	...	Repeated for module number 112				
7C9F	...	Repeated for module number 113				
7CB9	...	Repeated for module number 114				
7CD3	...	Repeated for module number 115				
7CED	...	Repeated for module number 116				
7D07	...	Repeated for module number 117				
7D21	...	Repeated for module number 118				
7D3B	...	Repeated for module number 119				
7D55	...	Repeated for module number 120				
7D6F	...	Repeated for module number 121				
7D89	...	Repeated for module number 122				
7DA3	...	Repeated for module number 123				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Contact Inputs (Read/Write setting) (128 Modules) (Continued)</b>						
7DBD	...Repeated for module number	124				
7DD7	...Repeated for module number	125				
7DF1	...Repeated for module number	126				
7E0B	...Repeated for module number	127				
7E25	...Repeated for module number	128				
<b>Contact Outputs (Read/Write Setting) (128 Modules)</b>						
7E3F	Contact Output x Name	---	---	---	F200	"Contact Output x" .
7E53	Contact Output x Operation	0 to 65535	---	1	F300	0
7E54	Contact Output x Sealin	0 to 65535	---	1	F300	0
7E55	Contact Output x Events	0 to 1	---	1	F102	1 (Enabled)
7E56	Contact Outputs Reserved (7 items)					
7E5D	...Repeated for module number	2				
7E7B	...Repeated for module number	3				
7E99	...Repeated for module number	4				
7EB7	...Repeated for module number	5				
7ED5	...Repeated for module number	6				
7EF3	...Repeated for module number	7				
7F11	...Repeated for module number	8				
7F2F	...Repeated for module number	9				
7F4D	...Repeated for module number	10				
7F6B	...Repeated for module number	11				
7F89	...Repeated for module number	12				
7FA7	...Repeated for module number	13				
7FC5	...Repeated for module number	14				
7FE3	...Repeated for module number	15				
8001	...Repeated for module number	16				
801F	...Repeated for module number	17				
803D	...Repeated for module number	18				
805B	...Repeated for module number	19				
8079	...Repeated for module number	20				
8097	...Repeated for module number	21				
80B5	...Repeated for module number	22				
80D3	...Repeated for module number	23				
80F1	...Repeated for module number	24				
810F	...Repeated for module number	25				
812D	...Repeated for module number	26				
814B	...Repeated for module number	27				
8169	...Repeated for module number	28				
8187	...Repeated for module number	29				
81A5	...Repeated for module number	30				
81C3	...Repeated for module number	31				
81E1	...Repeated for module number	32				
81FF	...Repeated for module number	33				
821D	...Repeated for module number	34				
823B	...Repeated for module number	35				
8259	...Repeated for module number	36				
8277	...Repeated for module number	37				
8295	...Repeated for module number	38				
82B3	...Repeated for module number	39				

---

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Contact Outputs (Read/Write Setting) (128 Modules) (Continued)</b>						
82D1	...	Repeated for module number 40				
82EF	...	Repeated for module number 41				
830D	...	Repeated for module number 42				
832B	...	Repeated for module number 43				
8349	...	Repeated for module number 44				
8367	...	Repeated for module number 45				
8385	...	Repeated for module number 46				
83A3	...	Repeated for module number 47				
83C1	...	Repeated for module number 48				
83DF	...	Repeated for module number 49				
83FD	...	Repeated for module number 50				
841B	...	Repeated for module number 51				
8439	...	Repeated for module number 52				
8457	...	Repeated for module number 53				
8475	...	Repeated for module number 54				
8493	...	Repeated for module number 55				
84B1	...	Repeated for module number 56				
84CF	...	Repeated for module number 57				
84ED	...	Repeated for module number 58				
850B	...	Repeated for module number 59				
8529	...	Repeated for module number 60				
8547	...	Repeated for module number 61				
8565	...	Repeated for module number 62				
8583	...	Repeated for module number 63				
85A1	...	Repeated for module number 64				
85BF	...	Repeated for module number 65				
85DD	...	Repeated for module number 66				
85FB	...	Repeated for module number 67				
8619	...	Repeated for module number 68				
8637	...	Repeated for module number 69				
8655	...	Repeated for module number 70				
8673	...	Repeated for module number 71				
8691	...	Repeated for module number 72				
86AF	...	Repeated for module number 73				
86CD	...	Repeated for module number 74				
86EB	...	Repeated for module number 75				
8709	...	Repeated for module number 76				
8727	...	Repeated for module number 77				
8745	...	Repeated for module number 78				
8763	...	Repeated for module number 79				
8781	...	Repeated for module number 80				
879F	...	Repeated for module number 81				
87BD	...	Repeated for module number 82				
87DB	...	Repeated for module number 83				
87F9	...	Repeated for module number 84				
8817	...	Repeated for module number 85				
8835	...	Repeated for module number 86				
8853	...	Repeated for module number 87				
8871	...	Repeated for module number 88				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Contact Outputs (Read/Write Setting) (128 Modules) (Continued)</b>						
888F	...Repeated for module number	89				
88AD	...Repeated for module number	90				
88CB	...Repeated for module number	91				
88E9	...Repeated for module number	92				
8907	...Repeated for module number	93				
8925	...Repeated for module number	94				
8943	...Repeated for module number	95				
8961	...Repeated for module number	96				
897F	...Repeated for module number	97				
899D	...Repeated for module number	98				
89BB	...Repeated for module number	99				
89D9	...Repeated for module number	100				
89F7	...Repeated for module number	101				
8A15	...Repeated for module number	102				
8A33	...Repeated for module number	103				
8A51	...Repeated for module number	104				
8A6F	...Repeated for module number	105				
8A8D	...Repeated for module number	106				
8AAB	...Repeated for module number	107				
8AC9	...Repeated for module number	108				
8AE7	...Repeated for module number	109				
8B05	...Repeated for module number	110				
8B23	...Repeated for module number	111				
8B41	...Repeated for module number	112				
8B5F	...Repeated for module number	113				
8B7D	...Repeated for module number	114				
8B9B	...Repeated for module number	115				
8BB9	...Repeated for module number	116				
8BD7	...Repeated for module number	117				
8BF5	...Repeated for module number	118				
8C13	...Repeated for module number	119				
8C31	...Repeated for module number	120				
8C4F	...Repeated for module number	121				
8C6D	...Repeated for module number	122				
8C8B	...Repeated for module number	123				
8CA9	...Repeated for module number	124				
8CC7	...Repeated for module number	125				
8CE5	...Repeated for module number	126				
8D03	...Repeated for module number	127				
8D21	...Repeated for module number	128				
<b>Force Contact Inputs (Read/Write Setting) (128 Modules)</b>						
8D3F	Force Contact Input x State (128 items)	0 to 2	---	1	F144	0 (Disabled)
<b>Force Contact Outputs (Read/Write Setting) (128 Modules)</b>						
8DBF	Force Contact Output x State (128 items)	0 to 3	---	1	F131	0 (Disabled)
<b>Flex Relay Settings (Read/Write Setting) (16 Modules)</b>						
8E3F	Relay X High Curr Flex Breaker Selection	0 to 30	---	1	F001	30
8E40	Relay X High Curr Flex Alarm Enable	0 to 1	---	1	F102	0
8E41	Relay X High Curr Flex Alarm Pickup Setting	10 to 200 % LT Pickup		5	F001	200
8E42	Relay X High Curr Flex Alarm Time Delay	1 to 15	S	1	F001	15

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Flex Relay Settings (Read/Write Setting) (16 Modules) (Continued)</b>						
8E43	Flex Relay Settings Reserved					
8E45	Relay X UV Flex Voltage Source	0 to 30	---	1	F001	30
8E46	Relay X UV Flex Breaker To Trip	0 to 30	---	1	F001	30
8E47	Relay X UV Flex Trip Enable	0 to 1	---	1	F102	0 (Disabled)
8E48	Relay X UV Flex Trip Pickup Setting	10 to 95	%	1	F001	10
8E49	Relay X UV Flex Trip Time Delay	5 to 6000	S	5	F001	300
8E4A	Relay X UV Flex Trip Phase Requirement	1 to 3	---	1	F001	1
8E4B	Relay X UV Flex Trip Curve Type	0 to 1	---	1	F726	1
8E4C	Relay X UV Flex Trip Blocking Voltage Enable	0 to 1	---	1	F102	0 (Disabled)
8E4D	Relay X UV Flex Trip Blocking Voltage Setting	5 to 75	%	1	F001	5
8E4E	Relay X UV Flex Trip or Open Setting	0 to 1	---	1	F727	1
8E4F	Relay X UV Flex Alarm Enable	0 to 1	---	1	F102	0 (Disabled)
8E50	Relay X UV Flex Alarm Pickup Setting	10 to 95	%	1	F001	10
8E51	Relay X UV Flex Alarm Time Delay	5 to 6000	S	5	F001	150
8E52	Relay X UV Flex Alarm Phase Requirement	1 to 3	---	1	F001	1
8E53	Relay X UV Flex Alarm Curve Type	0 to 1	---	1	F726	1
8E54	Relay X UV Flex Alarm Blocking Voltage Enable	0 to 1	---	1	F102	0 (Disabled)
8E55	Relay X UV Flex Alarm Blocking Voltage Setting	5 to 75	%	1	F001	5
8E56	Flex Relay Settings Reserved 2					
8E58	Alarm X Demand Flex Breaker Selection	0 to 30	---	1	F001	30
8E59	Alarm X Over Demand Flex Enable	0 to 1	---	1	F102	0 (Disabled)
8E5A	Alarm X Over Demand Flex Pickup Setting	-5000 to 5000	kW	100	F002	1500
8E5B	Alarm X Over Demand Flex Interval	1 to 15		1	F001	1
8E5C	Alarm X Over Demand Flex Subinterval	1 to 900	S	1	F001	1
8E5D	Alarm X Under Demand Flex Enable	0 to 1	---	1	F102	0 (Disabled)
8E5E	Alarm X Under Demand Flex Pickup Setting	-5000 to 5000	kW	100	F002	500
8E5F	Alarm X Under Demand Flex Interval	1 to 15	---	1	F001	1
8E60	Alarm X Under Demand Flex Subinterval	1 to 900	S	1	F001	1
8E61	Flex Relay Settings Reserved 3					
8E71	...Repeated for Module 2					
8EA3	...Repeated for Module 3					
8ED5	...Repeated for Module 4					
8F07	...Repeated for Module 5					
8F39	...Repeated for Module 6					
8F6B	...Repeated for Module 7					
8F9D	...Repeated for Module 8					
8FCF	...Repeated for Module 9					
9001	...Repeated for Module 10					
9033	...Repeated for Module 11					
9065	...Repeated for Module 12					
9097	...Repeated for Module 13					
90C9	...Repeated for Module 14					
90FB	...Repeated for Module 15					
912D	...Repeated for Module 16					
<b>Restricted Breaker Control (Read/Write) (30 Modules)</b>						
94E3	SRC X Open Breaker By Restricted Control	0 to 65535	---	1	F001	0 (No)
94E4	SRC X Trip Breaker By Restricted Control	0 to 65535	---	1	F001	0 (No)
94E5	SRC X Close Breaker By Restricted Control	0 to 65535	---	1	F001	0 (No)
94E6	Restricted Breaker Control Reserved (2 items)					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Restricted Breaker Control (Read/Write) (30 Modules) (Continued)</b>						
94E8	...Repeated for module number 2					
94ED	...Repeated for module number 3					
94F2	...Repeated for module number 4					
94F7	...Repeated for module number 5					
94FC	...Repeated for module number 6					
9501	...Repeated for module number 7					
9506	...Repeated for module number 8					
950B	...Repeated for module number 9					
9510	...Repeated for module number 10					
9515	...Repeated for module number 11					
951A	...Repeated for module number 12					
951F	...Repeated for module number 13					
9524	...Repeated for module number 14					
9529	...Repeated for module number 15					
952E	...Repeated for module number 16					
9533	...Repeated for module number 17					
9538	...Repeated for module number 18					
953D	...Repeated for module number 19					
9542	...Repeated for module number 20					
9547	...Repeated for module number 21					
954C	...Repeated for module number 22					
9551	...Repeated for module number 23					
9556	...Repeated for module number 24					
955B	...Repeated for module number 25					
9560	...Repeated for module number 26					
9565	...Repeated for module number 27					
956A	...Repeated for module number 28					
956F	...Repeated for module number 29					
9574	...Repeated for module number 30					
<b>FlexLogic Status (Read Only)</b>						
9588	FlexLogic Active	0 to 1	---	1	F126	0
9589	FlexLogic Message	---	---	---	F200	(none)
959D	FlexLogic Redundancy Mode	0 to 2	---	1	F301	0
<b>External Control Transfer Settings (Written by Factory)</b>						
95A4	CPU External Control Transfer Mode Enable	0 to 1	---	1	F102	0
<b>External Control Transfer Commands</b>						
95AA	CPU External Control Transfer	0 to 1	---	1	F126	0
95AB	CPU Return To Auto Control Transfer	0 to 1	---	1	F126	0
<b>FlexLogic (Read/Write Setting)</b>						
95B1	FlexLogic Entry (4096 items)	0 to 65535	---	1	F300	16384
<b>Breaker Control (Read/Write Setting) (30 Modules)</b>						
A5B1	Breaker Control x Open Flux Shifter	0 to 65535	---	1	F300	0
A5B2	Breaker Control x Open Shunt Trip	0 to 65535	---	1	F300	0
A5B3	Breaker Control x Trip Flux Shifter	0 to 65535	---	1	F300	0
A5B4	Breaker Control x Trip Shunt Trip	0 to 65535	---	1	F300	0
A5B5	Breaker Control x Close	0 to 65535	---	1	F300	0
A5B6	Breaker Control x Lockout	0 to 65535	---	1	F300	0
A5B7	Breaker Control x Lockout Reset	0 to 65535	---	1	F300	0

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Breaker Control (Read/Write Setting) (30 Modules) (Continued)</b>						
A5B8	Breaker Control x Reduced Let Thru	0 to 65535	---	1	F300	0
A5B9	Breaker Control x Machine Output	0 to 65535	---	1	F300	0
A5BA	Breaker Control Reserved (16 items)					
A5CA	...Repeated for module number 2					
A5E3	...Repeated for module number 3					
A5FC	...Repeated for module number 4					
A615	...Repeated for module number 5					
A62E	...Repeated for module number 6					
A647	...Repeated for module number 7					
A660	...Repeated for module number 8					
A679	...Repeated for module number 9					
A692	...Repeated for module number 10					
A6AB	...Repeated for module number 11					
A6C4	...Repeated for module number 12					
A6DD	...Repeated for module number 13					
A6F6	...Repeated for module number 14					
A70F	...Repeated for module number 15					
A728	...Repeated for module number 16					
A741	...Repeated for module number 17					
A75A	...Repeated for module number 18					
A773	...Repeated for module number 19					
A78C	...Repeated for module number 20					
A7A5	...Repeated for module number 21					
A7BE	...Repeated for module number 22					
A7D7	...Repeated for module number 23					
A7F0	...Repeated for module number 24					
A809	...Repeated for module number 25					
A822	...Repeated for module number 26					
A83B	...Repeated for module number 27					
A854	...Repeated for module number 28					
A86D	...Repeated for module number 29					
A886	...Repeated for module number 30					
<b>Control Alarm FlexLogic (30 Modules)</b>						
A89F	Alarm X FlexLogic	0 to 65535	---	1	F300	0
A8A0	Alarm FlexLogic Reserved	0 to 65535	---	1	F001	0
A8A1	...Repeated for module number 2					
A8A3	...Repeated for module number 3					
A8A5	...Repeated for module number 4					
A8A7	...Repeated for module number 5					
A8A9	...Repeated for module number 6					
A8AB	...Repeated for module number 7					
A8AD	...Repeated for module number 8					
A8AF	...Repeated for module number 9					
A8B1	...Repeated for module number 10					
A8B3	...Repeated for module number 11					
A8B5	...Repeated for module number 12					
A8B7	...Repeated for module number 13					
A8B9	...Repeated for module number 14					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Control Alarm FlexLogic (30 Modules) (Continued)</b>						
A8BB	...Repeated for module number 15					
A8BD	...Repeated for module number 16					
A8BF	...Repeated for module number 17					
A8C1	...Repeated for module number 18					
A8C3	...Repeated for module number 19					
A8C5	...Repeated for module number 20					
A8C7	...Repeated for module number 21					
A8C9	...Repeated for module number 22					
A8CB	...Repeated for module number 23					
A8CD	...Repeated for module number 24					
A8CF	...Repeated for module number 25					
A8D1	...Repeated for module number 26					
A8D3	...Repeated for module number 27					
A8D5	...Repeated for module number 28					
A8D7	...Repeated for module number 29					
A8D9	...Repeated for module number 30					
<b>FlexLogic Timers (Read/Write Settings) (160 Modules)</b>						
A8DB	Reserved (960 items)	0 to 2	---	1	F129	0 (millisecond)
<b>Virtual Inputs (Read/Write Setting) (32 Modules)</b>						
AC9B	Virtual Input x Function	0 to 1	---	1	F102	0 (Disabled)
AC9C	Virtual Input x Name	---	---	---	F200	"Virtual Input x".
ACB0	Virtual Input x Programmed Type	0 to 1	---	1	F127	0 (Latched)
ACB1	Virtual Input x Events	0 to 1	---	1	F102	0 (Disabled)
ACB2	Virtual Input x Reserved (3 items)					
ACB5	...Repeated for module number 2					
ACCF	...Repeated for module number 3					
ACE9	...Repeated for module number 4					
AD03	...Repeated for module number 5					
AD1D	...Repeated for module number 6					
AD37	...Repeated for module number 7					
AD51	...Repeated for module number 8					
AD6B	...Repeated for module number 9					
AD85	...Repeated for module number 10					
AD9F	...Repeated for module number 11					
ADB9	...Repeated for module number 12					
ADD3	...Repeated for module number 13					
ADED	...Repeated for module number 14					
AE07	...Repeated for module number 15					
AE21	...Repeated for module number 16					
AE3B	...Repeated for module number 17					
AE55	...Repeated for module number 18					
AE6F	...Repeated for module number 19					
AE89	...Repeated for module number 20					
AEA3	...Repeated for module number 21					
AEBD	...Repeated for module number 22					
AED7	...Repeated for module number 23					
AEF1	...Repeated for module number 24					
AFOB	...Repeated for module number 25					

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Inputs (Read/Write Setting) (32 Modules) (Continued)</b>						
AF25	...	Repeated for module number 26				
AF3F	...	Repeated for module number 27				
AF59	...	Repeated for module number 28				
AF73	...	Repeated for module number 29				
AF8D	...	Repeated for module number 30				
AFA7	...	Repeated for module number 31				
AFC1	...	Repeated for module number 32				
<b>Virtual Outputs (Read/Write Setting) (480 Modules)</b>						
AFDB	Virtual Output x Name	---	---	---	F200	"Virtual Output x"
AFEF	Virtual Output x Events	0 to 1	---	1	F102	0 (Disabled)
AFF0	Virtual Output x Reserved					
AFF1	...	Repeated for module number 2				
B007	...	Repeated for module number 3				
B01D	...	Repeated for module number 4				
B033	...	Repeated for module number 5				
B049	...	Repeated for module number 6				
B05F	...	Repeated for module number 7				
B075	...	Repeated for module number 8				
B08B	...	Repeated for module number 9				
BOA1	...	Repeated for module number 10				
BOB7	...	Repeated for module number 11				
BOCD	...	Repeated for module number 12				
B0E3	...	Repeated for module number 13				
B0F9	...	Repeated for module number 14				
B10F	...	Repeated for module number 15				
B125	...	Repeated for module number 16				
B13B	...	Repeated for module number 17				
B151	...	Repeated for module number 18				
B167	...	Repeated for module number 19				
B17D	...	Repeated for module number 20				
B193	...	Repeated for module number 21				
B1A9	...	Repeated for module number 22				
B1BF	...	Repeated for module number 23				
B1D5	...	Repeated for module number 24				
B1EB	...	Repeated for module number 25				
B201	...	Repeated for module number 26				
B217	...	Repeated for module number 27				
B22D	...	Repeated for module number 28				
B243	...	Repeated for module number 29				
B259	...	Repeated for module number 30				
B26F	...	Repeated for module number 31				
B285	...	Repeated for module number 32				
B29B	...	Repeated for module number 33				
B2B1	...	Repeated for module number 34				
B2C7	...	Repeated for module number 35				
B2DD	...	Repeated for module number 36				
B2F3	...	Repeated for module number 37				
B309	...	Repeated for module number 38				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
B31F	...	Repeated for module number 39				
B335	...	Repeated for module number 40				
B34B	...	Repeated for module number 41				
B361	...	Repeated for module number 42				
B377	...	Repeated for module number 43				
B38D	...	Repeated for module number 44				
B3A3	...	Repeated for module number 45				
B3B9	...	Repeated for module number 46				
B3CF	...	Repeated for module number 47				
B3E5	...	Repeated for module number 48				
B3FB	...	Repeated for module number 49				
B411	...	Repeated for module number 50				
B427	...	Repeated for module number 51				
B43D	...	Repeated for module number 52				
B453	...	Repeated for module number 53				
B469	...	Repeated for module number 54				
B47F	...	Repeated for module number 55				
B495	...	Repeated for module number 56				
B4AB	...	Repeated for module number 57				
B4C1	...	Repeated for module number 58				
B4D7	...	Repeated for module number 59				
B4ED	...	Repeated for module number 60				
B503	...	Repeated for module number 61				
B519	...	Repeated for module number 62				
B52F	...	Repeated for module number 63				
B545	...	Repeated for module number 64				
B55B	...	Repeated for module number 65				
B571	...	Repeated for module number 66				
B587	...	Repeated for module number 67				
B59D	...	Repeated for module number 68				
B5B3	...	Repeated for module number 69				
B5C9	...	Repeated for module number 70				
B5DF	...	Repeated for module number 71				
B5F5	...	Repeated for module number 72				
B60B	...	Repeated for module number 73				
B621	...	Repeated for module number 74				
B637	...	Repeated for module number 75				
B64D	...	Repeated for module number 76				
B663	...	Repeated for module number 77				
B679	...	Repeated for module number 78				
B68F	...	Repeated for module number 79				
B6A5	...	Repeated for module number 80				
B6BB	...	Repeated for module number 81				
B6D1	...	Repeated for module number 82				
B6E7	...	Repeated for module number 83				
B6FD	...	Repeated for module number 84				
B713	...	Repeated for module number 85				
B729	...	Repeated for module number 86				
B73F	...	Repeated for module number 87				

---

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
B755	...	Repeated for module number 88				
B76B	...	Repeated for module number 89				
B781	...	Repeated for module number 90				
B797	...	Repeated for module number 91				
B7AD	...	Repeated for module number 92				
B7C3	...	Repeated for module number 93				
B7D9	...	Repeated for module number 94				
B7EF	...	Repeated for module number 95				
B805	...	Repeated for module number 96				
B81B	...	Repeated for module number 97				
B831	...	Repeated for module number 98				
B847	...	Repeated for module number 99				
B85D	...	Repeated for module number 100				
B873	...	Repeated for module number 101				
B889	...	Repeated for module number 102				
B89F	...	Repeated for module number 103				
B8B5	...	Repeated for module number 104				
B8CB	...	Repeated for module number 105				
B8E1	...	Repeated for module number 106				
B8F7	...	Repeated for module number 107				
B90D	...	Repeated for module number 108				
B923	...	Repeated for module number 109				
B939	...	Repeated for module number 110				
B94F	...	Repeated for module number 111				
B965	...	Repeated for module number 112				
B97B	...	Repeated for module number 113				
B991	...	Repeated for module number 114				
B9A7	...	Repeated for module number 115				
B9BD	...	Repeated for module number 116				
B9D3	...	Repeated for module number 117				
B9E9	...	Repeated for module number 118				
B9FF	...	Repeated for module number 119				
BA15	...	Repeated for module number 120				
BA2B	...	Repeated for module number 121				
BA41	...	Repeated for module number 122				
BA57	...	Repeated for module number 123				
BA6D	...	Repeated for module number 124				
BA83	...	Repeated for module number 125				
BA99	...	Repeated for module number 126				
BAAF	...	Repeated for module number 127				
BAC5	...	Repeated for module number 128				
BADB	...	Repeated for module number 129				
BAF1	...	Repeated for module number 130				
BB07	...	Repeated for module number 131				
BB1D	...	Repeated for module number 132				
BB33	...	Repeated for module number 133				
BB49	...	Repeated for module number 134				
BB5F	...	Repeated for module number 135				
BB75	...	Repeated for module number 136				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
BB8B	...	Repeated for module number 137				
BBA1	...	Repeated for module number 138				
BBB7	...	Repeated for module number 139				
BBCD	...	Repeated for module number 140				
BBE3	...	Repeated for module number 141				
BBF9	...	Repeated for module number 142				
BC0F	...	Repeated for module number 143				
BC25	...	Repeated for module number 144				
BC3B	...	Repeated for module number 145				
BC51	...	Repeated for module number 146				
BC67	...	Repeated for module number 147				
BC7D	...	Repeated for module number 148				
BC93	...	Repeated for module number 149				
BCA9	...	Repeated for module number 150				
BCBF	...	Repeated for module number 151				
BCD5	...	Repeated for module number 152				
BCEB	...	Repeated for module number 153				
BD01	...	Repeated for module number 154				
BD17	...	Repeated for module number 155				
BD2D	...	Repeated for module number 156				
BD43	...	Repeated for module number 157				
BD59	...	Repeated for module number 158				
BD6F	...	Repeated for module number 159				
BD85	...	Repeated for module number 160				
BD9B	...	Repeated for module number 161				
BDB1	...	Repeated for module number 162				
BDC7	...	Repeated for module number 163				
BDDD	...	Repeated for module number 164				
BDF3	...	Repeated for module number 165				
BE09	...	Repeated for module number 166				
BE1F	...	Repeated for module number 167				
BE35	...	Repeated for module number 168				
BE4B	...	Repeated for module number 169				
BE61	...	Repeated for module number 170				
BE77	...	Repeated for module number 171				
BE8D	...	Repeated for module number 172				
BEA3	...	Repeated for module number 173				
BEB9	...	Repeated for module number 174				
BECF	...	Repeated for module number 175				
BEE5	...	Repeated for module number 176				
BEFB	...	Repeated for module number 177				
BF11	...	Repeated for module number 178				
BF27	...	Repeated for module number 179				
BF3D	...	Repeated for module number 180				
BF53	...	Repeated for module number 181				
BF69	...	Repeated for module number 182				
BF7F	...	Repeated for module number 183				
BF95	...	Repeated for module number 184				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
BFAB	...	Repeated for module number 185				
BFC1	...	Repeated for module number 186				
BFD7	...	Repeated for module number 187				
BFED	...	Repeated for module number 188				
C003	...	Repeated for module number 189				
C019	...	Repeated for module number 190				
C02F	...	Repeated for module number 191				
C045	...	Repeated for module number 192				
C05B	...	Repeated for module number 193				
C071	...	Repeated for module number 194				
C087	...	Repeated for module number 195				
C09D	...	Repeated for module number 196				
C0B3	...	Repeated for module number 197				
C0C9	...	Repeated for module number 198				
C0DF	...	Repeated for module number 199				
C0F5	...	Repeated for module number 200				
C10B	...	Repeated for module number 201				
C121	...	Repeated for module number 202				
C137	...	Repeated for module number 203				
C14D	...	Repeated for module number 204				
C163	...	Repeated for module number 205				
C179	...	Repeated for module number 206				
C18F	...	Repeated for module number 207				
C1A5	...	Repeated for module number 208				
C1BB	...	Repeated for module number 209				
C1D1	...	Repeated for module number 210				
C1E7	...	Repeated for module number 211				
C1FD	...	Repeated for module number 212				
C213	...	Repeated for module number 213				
C229	...	Repeated for module number 214				
C23F	...	Repeated for module number 215				
C255	...	Repeated for module number 216				
C26B	...	Repeated for module number 217				
C281	...	Repeated for module number 218				
C297	...	Repeated for module number 219				
C2AD	...	Repeated for module number 220				
C2C3	...	Repeated for module number 221				
C2D9	...	Repeated for module number 222				
C2EF	...	Repeated for module number 223				
C305	...	Repeated for module number 224				
C31B	...	Repeated for module number 225				
C331	...	Repeated for module number 226				
C347	...	Repeated for module number 227				
C35D	...	Repeated for module number 228				
C373	...	Repeated for module number 229				
C389	...	Repeated for module number 230				
C39F	...	Repeated for module number 231				
C3B5	...	Repeated for module number 232				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
C3CB	...Repeated for module number	233				
C3E1	...Repeated for module number	234				
C3F7	...Repeated for module number	235				
C40D	...Repeated for module number	236				
C423	...Repeated for module number	237				
C439	...Repeated for module number	238				
C44F	...Repeated for module number	239				
C465	...Repeated for module number	240				
C47B	...Repeated for module number	241				
C491	...Repeated for module number	242				
C4A7	...Repeated for module number	243				
C4BD	...Repeated for module number	244				
C4D3	...Repeated for module number	245				
C4E9	...Repeated for module number	246				
C4FF	...Repeated for module number	247				
C515	...Repeated for module number	248				
C52B	...Repeated for module number	249				
C541	...Repeated for module number	250				
C557	...Repeated for module number	251				
C56D	...Repeated for module number	252				
C583	...Repeated for module number	253				
C599	...Repeated for module number	254				
C5AF	...Repeated for module number	255				
C5C5	...Repeated for module number	256				
C5DB	...Repeated for module number	257				
C5F1	...Repeated for module number	258				
C607	...Repeated for module number	259				
C61D	...Repeated for module number	260				
C633	...Repeated for module number	261				
C649	...Repeated for module number	262				
C65F	...Repeated for module number	263				
C675	...Repeated for module number	264				
C68B	...Repeated for module number	265				
C6A1	...Repeated for module number	266				
C6B7	...Repeated for module number	267				
C6CD	...Repeated for module number	268				
C6E3	...Repeated for module number	269				
C6F9	...Repeated for module number	270				
C70F	...Repeated for module number	271				
C725	...Repeated for module number	272				
C73B	...Repeated for module number	273				
C751	...Repeated for module number	274				
C767	...Repeated for module number	275				
C77D	...Repeated for module number	276				
C793	...Repeated for module number	277				
C7A9	...Repeated for module number	278				
C7BF	...Repeated for module number	279				
C7D5	...Repeated for module number	280				

---

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
C7EB	...Repeated for module number	281				
C801	...Repeated for module number	282				
C817	...Repeated for module number	283				
C82D	...Repeated for module number	284				
C843	...Repeated for module number	285				
C859	...Repeated for module number	286				
C86F	...Repeated for module number	287				
C885	...Repeated for module number	288				
C89B	...Repeated for module number	289				
C8B1	...Repeated for module number	290				
C8C7	...Repeated for module number	291				
C8DD	...Repeated for module number	292				
C8F3	...Repeated for module number	293				
C909	...Repeated for module number	294				
C91F	...Repeated for module number	295				
C935	...Repeated for module number	296				
C94B	...Repeated for module number	297				
C961	...Repeated for module number	298				
C977	...Repeated for module number	299				
C98D	...Repeated for module number	300				
C9A3	...Repeated for module number	301				
C9B9	...Repeated for module number	302				
C9CF	...Repeated for module number	303				
C9E5	...Repeated for module number	304				
C9FB	...Repeated for module number	305				
CA11	...Repeated for module number	306				
CA27	...Repeated for module number	307				
CA3D	...Repeated for module number	308				
CA53	...Repeated for module number	309				
CA69	...Repeated for module number	310				
CA7F	...Repeated for module number	311				
CA95	...Repeated for module number	312				
CAAB	...Repeated for module number	313				
CAC1	...Repeated for module number	314				
CAD7	...Repeated for module number	315				
CAED	...Repeated for module number	316				
CB03	...Repeated for module number	317				
CB19	...Repeated for module number	318				
CB2F	...Repeated for module number	319				
CB45	...Repeated for module number	320				
CB5B	...Repeated for module number	321				
CB71	...Repeated for module number	322				
CB87	...Repeated for module number	323				
CB9D	...Repeated for module number	324				
CBB3	...Repeated for module number	325				
CBC9	...Repeated for module number	326				
CBDF	...Repeated for module number	327				
CBF5	...Repeated for module number	328				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
CC0B	...Repeated for module number	329				
CC21	...Repeated for module number	330				
CC37	...Repeated for module number	331				
CC4D	...Repeated for module number	332				
CC63	...Repeated for module number	333				
CC79	...Repeated for module number	334				
CC8F	...Repeated for module number	335				
CCA5	...Repeated for module number	336				
CCBB	...Repeated for module number	337				
CCD1	...Repeated for module number	338				
CCE7	...Repeated for module number	339				
CCFD	...Repeated for module number	340				
CD13	...Repeated for module number	341				
CD29	...Repeated for module number	342				
CD3F	...Repeated for module number	343				
CD55	...Repeated for module number	344				
CD6B	...Repeated for module number	345				
CD81	...Repeated for module number	346				
CD97	...Repeated for module number	347				
CDAD	...Repeated for module number	348				
CDC3	...Repeated for module number	349				
CDD9	...Repeated for module number	350				
CDEF	...Repeated for module number	351				
CE05	...Repeated for module number	352				
CE1B	...Repeated for module number	353				
CE31	...Repeated for module number	354				
CE47	...Repeated for module number	355				
CE5D	...Repeated for module number	356				
CE73	...Repeated for module number	357				
CE89	...Repeated for module number	358				
CE9F	...Repeated for module number	359				
CEB5	...Repeated for module number	360				
CECB	...Repeated for module number	361				
CEE1	...Repeated for module number	362				
CEF7	...Repeated for module number	363				
CF0D	...Repeated for module number	364				
CF23	...Repeated for module number	365				
CF39	...Repeated for module number	366				
CF4F	...Repeated for module number	367				
CF65	...Repeated for module number	368				
CF7B	...Repeated for module number	369				
CF91	...Repeated for module number	370				
CFA7	...Repeated for module number	371				
CFBD	...Repeated for module number	372				
CFD3	...Repeated for module number	373				
CFE9	...Repeated for module number	374				
CFFF	...Repeated for module number	375				
D015	...Repeated for module number	376				

---

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
D02B	...	Repeated for module number 377				
D041	...	Repeated for module number 378				
D057	...	Repeated for module number 379				
D06D	...	Repeated for module number 380				
D083	...	Repeated for module number 381				
D099	...	Repeated for module number 382				
D0AF	...	Repeated for module number 383				
D0C5	...	Repeated for module number 384				
D0DB	...	Repeated for module number 385				
D0F1	...	Repeated for module number 386				
D107	...	Repeated for module number 387				
D11D	...	Repeated for module number 388				
D133	...	Repeated for module number 389				
D149	...	Repeated for module number 390				
D15F	...	Repeated for module number 391				
D175	...	Repeated for module number 392				
D18B	...	Repeated for module number 393				
D1A1	...	Repeated for module number 394				
D1B7	...	Repeated for module number 395				
D1CD	...	Repeated for module number 396				
D1E3	...	Repeated for module number 397				
D1F9	...	Repeated for module number 398				
D20F	...	Repeated for module number 399				
D225	...	Repeated for module number 400				
D23B	...	Repeated for module number 401				
D251	...	Repeated for module number 402				
D267	...	Repeated for module number 403				
D27D	...	Repeated for module number 404				
D293	...	Repeated for module number 405				
D2A9	...	Repeated for module number 406				
D2BF	...	Repeated for module number 407				
D2D5	...	Repeated for module number 408				
D2EB	...	Repeated for module number 409				
D301	...	Repeated for module number 410				
D317	...	Repeated for module number 411				
D32D	...	Repeated for module number 412				
D343	...	Repeated for module number 413				
D359	...	Repeated for module number 414				
D36F	...	Repeated for module number 415				
D385	...	Repeated for module number 416				
D39B	...	Repeated for module number 417				
D3B1	...	Repeated for module number 418				
D3C7	...	Repeated for module number 419				
D3DD	...	Repeated for module number 420				
D3F3	...	Repeated for module number 421				
D409	...	Repeated for module number 422				
D41F	...	Repeated for module number 423				
D435	...	Repeated for module number 424				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
D44B	...Repeated for module number	425				
D461	...Repeated for module number	426				
D477	...Repeated for module number	427				
D48D	...Repeated for module number	428				
D4A3	...Repeated for module number	429				
D4B9	...Repeated for module number	430				
D4CF	...Repeated for module number	431				
D4E5	...Repeated for module number	432				
D4FB	...Repeated for module number	433				
D0F1	...Repeated for module number	386				
D107	...Repeated for module number	387				
D11D	...Repeated for module number	388				
D133	...Repeated for module number	389				
D149	...Repeated for module number	390				
D15F	...Repeated for module number	391				
D175	...Repeated for module number	392				
D511	...Repeated for module number	434				
D527	...Repeated for module number	435				
D53D	...Repeated for module number	436				
D553	...Repeated for module number	437				
D569	...Repeated for module number	438				
D57F	...Repeated for module number	439				
D595	...Repeated for module number	440				
D5AB	...Repeated for module number	441				
D5C1	...Repeated for module number	442				
D5D7	...Repeated for module number	443				
D5ED	...Repeated for module number	444				
D603	...Repeated for module number	445				
D619	...Repeated for module number	446				
D62F	...Repeated for module number	447				
D645	...Repeated for module number	448				
D65B	...Repeated for module number	449				
D671	...Repeated for module number	450				
D687	...Repeated for module number	451				
D69D	...Repeated for module number	452				
D6B3	...Repeated for module number	453				
D6C9	...Repeated for module number	454				
D6DF	...Repeated for module number	455				
D6F5	...Repeated for module number	456				
D70B	...Repeated for module number	457				
D721	...Repeated for module number	458				
D737	...Repeated for module number	459				
D74D	...Repeated for module number	460				
D763	...Repeated for module number	461				
D779	...Repeated for module number	462				
D78F	...Repeated for module number	463				
D7A5	...Repeated for module number	464				
D7BB	...Repeated for module number	465				

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Virtual Outputs (Read/Write Setting) (480 Modules) (Continued)</b>						
D7D1	...Repeated for module number 466					
D7E7	...Repeated for module number 467					
D7FD	...Repeated for module number 468					
D813	...Repeated for module number 469					
D829	...Repeated for module number 470					
D83F	...Repeated for module number 471					
D855	...Repeated for module number 472					
D86B	...Repeated for module number 473					
D881	...Repeated for module number 474					
D897	...Repeated for module number 475					
D8AD	...Repeated for module number 476					
D8C3	...Repeated for module number 477					
D8D9	...Repeated for module number 478					
D8EF	...Repeated for module number 479					
D905	...Repeated for module number 480					
<b>Virtual Input Commands (Read/Write Command) (32 Modules)</b>						
D91B	Virtual Input 1 State	0 to 1	---	0	F108	0 (Off)
D91C	Virtual Input 2 State	0 to 1	---	0	F108	0 (Off)
D91D	Virtual Input 3 State	0 to 1	---	0	F108	0 (Off)
D91E	Virtual Input 4 State	0 to 1	---	0	F108	0 (Off)
D91F	Virtual Input 5 State	0 to 1	---	0	F108	0 (Off)
D920	Virtual Input 6 State	0 to 1	---	0	F108	0 (Off)
D921	Virtual Input 7 State	0 to 1	---	0	F108	0 (Off)
D922	Virtual Input 8 State	0 to 1	---	0	F108	0 (Off)
D923	Virtual Input 9 State	0 to 1	---	0	F108	0 (Off)
D924	Virtual Input 10 State	0 to 1	---	0	F108	0 (Off)
D925	Virtual Input 11 State	0 to 1	---	0	F108	0 (Off)
D926	Virtual Input 12 State	0 to 1	---	0	F108	0 (Off)
D927	Virtual Input 13 State	0 to 1	---	0	F108	0 (Off)
D928	Virtual Input 14 State	0 to 1	---	0	F108	0 (Off)
D929	Virtual Input 15 State	0 to 1	---	0	F108	0 (Off)
D92A	Virtual Input 16 State	0 to 1	---	0	F108	0 (Off)
D92B	Virtual Input 17 State	0 to 1	---	0	F108	0 (Off)
D92C	Virtual Input 18 State	0 to 1	---	0	F108	0 (Off)
D92D	Virtual Input 19 State	0 to 1	---	0	F108	0 (Off)
D92E	Virtual Input 20 State	0 to 1	---	0	F108	0 (Off)
D92F	Virtual Input 21 State	0 to 1	---	0	F108	0 (Off)
D930	Virtual Input 22 State	0 to 1	---	0	F108	0 (Off)
D931	Virtual Input 23 State	0 to 1	---	0	F108	0 (Off)
D932	Virtual Input 24 State	0 to 1	---	0	F108	0 (Off)
D933	Virtual Input 25 State	0 to 1	---	0	F108	0 (Off)
D934	Virtual Input 26 State	0 to 1	---	0	F108	0 (Off)
D935	Virtual Input 27 State	0 to 1	---	0	F108	0 (Off)
D936	Virtual Input 28 State	0 to 1	---	0	F108	0 (Off)
D937	Virtual Input 29 State	0 to 1	---	0	F108	0 (Off)
D938	Virtual Input 30 State	0 to 1	---	0	F108	0 (Off)
D939	Virtual Input 31 State	0 to 1	---	0	F108	0 (Off)
D93A	Virtual Input 32 State	0 to 1	---	0	F108	0 (Off)

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Inputs (Read/Write Setting) (256 Modules)</b>						
D93B	PLC Input x Function	0 to 1	---	1	F102	0 (Disabled)
D93C	PLC Input x Events	0 to 1	---	1	F102	0 (Disabled)
D93D	...Repeated for module number 2					
D93F	...Repeated for module number 3					
D941	...Repeated for module number 4					
D943	...Repeated for module number 5					
D945	...Repeated for module number 6					
D947	...Repeated for module number 7					
D949	...Repeated for module number 8					
D94B	...Repeated for module number 9					
D94D	...Repeated for module number 10					
D94F	...Repeated for module number 11					
D951	...Repeated for module number 12					
D953	...Repeated for module number 13					
D955	...Repeated for module number 14					
D957	...Repeated for module number 15					
D959	...Repeated for module number 16					
D95B	...Repeated for module number 17					
D95D	...Repeated for module number 18					
D95F	...Repeated for module number 19					
D961	...Repeated for module number 20					
D963	...Repeated for module number 21					
D965	...Repeated for module number 22					
D967	...Repeated for module number 23					
D969	...Repeated for module number 24					
D96B	...Repeated for module number 25					
D96D	...Repeated for module number 26					
D96F	...Repeated for module number 27					
D971	...Repeated for module number 28					
D973	...Repeated for module number 29					
D975	...Repeated for module number 30					
D977	...Repeated for module number 31					
D979	...Repeated for module number 32					
D97B	...Repeated for module number 33					
D97D	...Repeated for module number 34					
D97F	...Repeated for module number 35					
D981	...Repeated for module number 36					
D983	...Repeated for module number 37					
D985	...Repeated for module number 38					
D987	...Repeated for module number 39					
D989	...Repeated for module number 40					
D98B	...Repeated for module number 41					
D98D	...Repeated for module number 42					
D98F	...Repeated for module number 43					
D991	...Repeated for module number 44					
D993	...Repeated for module number 45					
D995	...Repeated for module number 46					
D997	...Repeated for module number 47					

—  
**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Inputs (Read/Write Setting) (256 Modules) (Continued)</b>						
D999	...Repeated for module number	48				
D99B	...Repeated for module number	49				
D99D	...Repeated for module number	50				
D99F	...Repeated for module number	51				
D9A1	...Repeated for module number	52				
D9A3	...Repeated for module number	53				
D9A5	...Repeated for module number	54				
D9A7	...Repeated for module number	55				
D9A9	...Repeated for module number	56				
D9AB	...Repeated for module number	57				
D9AD	...Repeated for module number	58				
D9AF	...Repeated for module number	59				
D9B1	...Repeated for module number	60				
D9B3	...Repeated for module number	61				
D9B5	...Repeated for module number	62				
D9B7	...Repeated for module number	63				
D9B9	...Repeated for module number	64				
D9BB	...Repeated for module number	65				
D9BD	...Repeated for module number	66				
D9BF	...Repeated for module number	67				
D9C1	...Repeated for module number	68				
D9C3	...Repeated for module number	69				
D9C5	...Repeated for module number	70				
D9C7	...Repeated for module number	71				
D9C9	...Repeated for module number	72				
D9CB	...Repeated for module number	73				
D9CD	...Repeated for module number	74				
D9CF	...Repeated for module number	75				
D9D1	...Repeated for module number	76				
D9D3	...Repeated for module number	77				
D9D5	...Repeated for module number	78				
D9D7	...Repeated for module number	79				
D9D9	...Repeated for module number	80				
D9DB	...Repeated for module number	81				
D9DD	...Repeated for module number	82				
D9DF	...Repeated for module number	83				
D9E1	...Repeated for module number	84				
D9E3	...Repeated for module number	85				
D9E5	...Repeated for module number	86				
D9E7	...Repeated for module number	87				
D9E9	...Repeated for module number	88				
D9EB	...Repeated for module number	89				
D9ED	...Repeated for module number	90				
D9EF	...Repeated for module number	91				
D9F1	...Repeated for module number	92				
D9F3	...Repeated for module number	93				
D9F5	...Repeated for module number	94				
D9F7	...Repeated for module number	95				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Inputs (Read/Write Setting) (256 Modules) (Continued)</b>						
D9F9	...Repeated for module number	96				
D9FB	...Repeated for module number	97				
D9FD	...Repeated for module number	98				
D9FF	...Repeated for module number	99				
DA01	...Repeated for module number	100				
DA03	...Repeated for module number	101				
DA05	...Repeated for module number	102				
DA07	...Repeated for module number	103				
DA09	...Repeated for module number	104				
DA0B	...Repeated for module number	105				
DA0D	...Repeated for module number	106				
DA0F	...Repeated for module number	107				
DA11	...Repeated for module number	108				
DA13	...Repeated for module number	109				
DA15	...Repeated for module number	110				
DA17	...Repeated for module number	111				
DA19	...Repeated for module number	112				
DA1B	...Repeated for module number	113				
DA1D	...Repeated for module number	114				
DA1F	...Repeated for module number	115				
DA21	...Repeated for module number	116				
DA23	...Repeated for module number	117				
DA25	...Repeated for module number	118				
DA27	...Repeated for module number	119				
DA29	...Repeated for module number	120				
DA2B	...Repeated for module number	121				
DA2D	...Repeated for module number	122				
DA2F	...Repeated for module number	123				
DA31	...Repeated for module number	124				
DA33	...Repeated for module number	125				
DA35	...Repeated for module number	126				
DA37	...Repeated for module number	127				
DA39	...Repeated for module number	128				
DA3B	...Repeated for module number	129				
DA3D	...Repeated for module number	130				
DA3F	...Repeated for module number	131				
DA41	...Repeated for module number	132				
DA43	...Repeated for module number	133				
DA45	...Repeated for module number	134				
DA47	...Repeated for module number	135				
DA49	...Repeated for module number	136				
DA4B	...Repeated for module number	137				
DA4D	...Repeated for module number	138				
DA4F	...Repeated for module number	139				
DA51	...Repeated for module number	140				
DA53	...Repeated for module number	141				
DA55	...Repeated for module number	142				
DA57	...Repeated for module number	143				

—  
**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Inputs (Read/Write Setting) (256 Modules) (Continued)</b>						
DA59	...Repeated for module number	144				
DA5B	...Repeated for module number	145				
DA5D	...Repeated for module number	146				
DA5F	...Repeated for module number	147				
DA61	...Repeated for module number	148				
DA63	...Repeated for module number	149				
DA65	...Repeated for module number	150				
DA67	...Repeated for module number	151				
DA69	...Repeated for module number	152				
DA6B	...Repeated for module number	153				
DA6D	...Repeated for module number	154				
DA6F	...Repeated for module number	155				
DA71	...Repeated for module number	156				
DA73	...Repeated for module number	157				
DA75	...Repeated for module number	158				
DA77	...Repeated for module number	159				
DA79	...Repeated for module number	160				
DA7B	...Repeated for module number	161				
DA7D	...Repeated for module number	162				
DA7F	...Repeated for module number	163				
DA81	...Repeated for module number	164				
DA83	...Repeated for module number	165				
DA85	...Repeated for module number	166				
DA87	...Repeated for module number	167				
DA89	...Repeated for module number	168				
DA8B	...Repeated for module number	169				
DA8D	...Repeated for module number	170				
DA8F	...Repeated for module number	171				
DA91	...Repeated for module number	172				
DA93	...Repeated for module number	173				
DA95	...Repeated for module number	174				
DA97	...Repeated for module number	175				
DA99	...Repeated for module number	176				
DA9B	...Repeated for module number	177				
DA9D	...Repeated for module number	178				
DA9F	...Repeated for module number	179				
DAA1	...Repeated for module number	180				
DAA3	...Repeated for module number	181				
DAA5	...Repeated for module number	182				
DA A7	...Repeated for module number	183				
DAA9	...Repeated for module number	184				
DAAB	...Repeated for module number	185				
DAAD	...Repeated for module number	186				
DAAF	...Repeated for module number	187				
DAB1	...Repeated for module number	188				
DAB3	...Repeated for module number	189				
DAB5	...Repeated for module number	190				
DAB7	...Repeated for module number	191				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Inputs (Read/Write Setting) (256 Modules) (Continued)</b>						
DAB9	...Repeated for module number	192				
DABB	...Repeated for module number	193				
DABD	...Repeated for module number	194				
DABF	...Repeated for module number	195				
DAC1	...Repeated for module number	196				
DAC3	...Repeated for module number	197				
DAC5	...Repeated for module number	198				
DAC7	...Repeated for module number	199				
DAC9	...Repeated for module number	200				
DACB	...Repeated for module number	201				
DACD	...Repeated for module number	202				
DACF	...Repeated for module number	203				
DAD1	...Repeated for module number	204				
DAD3	...Repeated for module number	205				
DAD5	...Repeated for module number	206				
DAD7	...Repeated for module number	207				
DAD9	...Repeated for module number	208				
DADB	...Repeated for module number	209				
DADD	...Repeated for module number	210				
DADF	...Repeated for module number	211				
DAE1	...Repeated for module number	212				
DAE3	...Repeated for module number	213				
DAE5	...Repeated for module number	214				
DAE7	...Repeated for module number	215				
DAE9	...Repeated for module number	216				
DAEB	...Repeated for module number	217				
DAED	...Repeated for module number	218				
DAEF	...Repeated for module number	219				
DAF1	...Repeated for module number	220				
DAF3	...Repeated for module number	221				
DAF5	...Repeated for module number	222				
DAF7	...Repeated for module number	223				
DAF9	...Repeated for module number	224				
DAFB	...Repeated for module number	225				
DAFD	...Repeated for module number	226				
DAFF	...Repeated for module number	227				
DB01	...Repeated for module number	228				
DB03	...Repeated for module number	229				
DB05	...Repeated for module number	230				
DB07	...Repeated for module number	231				
DB09	...Repeated for module number	232				
DB0B	...Repeated for module number	233				
DB0D	...Repeated for module number	234				
DB0F	...Repeated for module number	235				
DB11	...Repeated for module number	236				
DB13	...Repeated for module number	237				
DB15	...Repeated for module number	238				
DB17	...Repeated for module number	239				
DB19	...Repeated for module number	240				

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Inputs (Read/Write Setting) (256 Modules) (Continued)</b>						
DB1B	...Repeated for module number	241				
DB1D	...Repeated for module number	242				
DB1F	...Repeated for module number	243				
DB21	...Repeated for module number	244				
DB23	...Repeated for module number	245				
DB25	...Repeated for module number	246				
DB27	...Repeated for module number	247				
DB29	...Repeated for module number	248				
DB2B	...Repeated for module number	249				
DB2D	...Repeated for module number	250				
DB2F	...Repeated for module number	251				
DB31	...Repeated for module number	252				
DB33	...Repeated for module number	253				
DB35	...Repeated for module number	254				
DB37	...Repeated for module number	255				
DB39	...Repeated for module number	256				
<b>GOOSE Output Settings (64 Modules)</b>						
DB3B	GOOSE Output x Operation	0 to 65535	---	1	F300	0
DB3C	GOOSE Output Reserved	0 to 65535	---	1	F001	0
DB3D	...Repeated for Module	2				
DB3F	...Repeated for Module	3				
DB41	...Repeated for Module	4				
DB43	...Repeated for Module	5				
DB45	...Repeated for Module	6				
DB47	...Repeated for Module	7				
DB49	...Repeated for Module	8				
DB4B	...Repeated for Module	9				
DB4D	...Repeated for Module	10				
DB4F	...Repeated for Module	11				
DB51	...Repeated for Module	12				
DB53	...Repeated for Module	13				
DB55	...Repeated for Module	14				
DB57	...Repeated for Module	15				
DB59	...Repeated for Module	16				
DB5B	...Repeated for Module	17				
DB5D	...Repeated for Module	18				
DB5F	...Repeated for Module	19				
DB61	...Repeated for Module	20				
DB63	...Repeated for Module	21				
DB65	...Repeated for Module	22				
DB67	...Repeated for Module	23				
DB69	...Repeated for Module	24				
DB6B	...Repeated for Module	25				
DB6D	...Repeated for Module	26				
DB6F	...Repeated for Module	27				
DB71	...Repeated for Module	28				
DB73	...Repeated for Module	29				
DB75	...Repeated for Module	30				
DB77	...Repeated for Module	31				

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>GOOSE Output Settings (64 Modules) (Continued)</b>						
DB79	...Repeated for Module 32					
DB7B	...Repeated for Module 33					
DB7D	...Repeated for Module 34					
DB7F	...Repeated for Module 35					
DB81	...Repeated for Module 36					
DB83	...Repeated for Module 37					
DB85	...Repeated for Module 38					
DB87	...Repeated for Module 39					
DB89	...Repeated for Module 40					
DB8B	...Repeated for Module 41					
DB8D	...Repeated for Module 42					
DB8F	...Repeated for Module 43					
DB91	...Repeated for Module 44					
DB93	...Repeated for Module 45					
DB95	...Repeated for Module 46					
DB97	...Repeated for Module 47					
DB99	...Repeated for Module 48					
DB9B	...Repeated for Module 49					
DB9D	...Repeated for Module 50					
DB9F	...Repeated for Module 51					
DBA1	...Repeated for Module 52					
DBA3	...Repeated for Module 53					
DBA5	...Repeated for Module 54					
DBA7	...Repeated for Module 55					
DBA9	...Repeated for Module 56					
DBAB	...Repeated for Module 57					
DBAD	...Repeated for Module 58					
DBAF	...Repeated for Module 59					
DBB1	...Repeated for Module 60					
DBB3	...Repeated for Module 61					
DBB5	...Repeated for Module 62					
DBB7	...Repeated for Module 63					
DBB9	...Repeated for Module 64					
DBBB	(Next Available Address)					
<b>GOOSE Status (Read Setting)</b>						
DBBB	GOOSE Input Health Status	0 to 65535	---	1	F741	0
DBFB	GOOSE System Health Status	0 to 65535	---	1	F742	0
DBFC	GOOSE Input System Health Status	0 to 65535	---	1	F743	0
DBFD	GOOSE Output System Health Status	0 to 65535	---	1	F744	0
DC00	PLC Input States (16 items)	0 to 65535	---	1	F500	0
DC10	Virtual Input States (2 items)	0 to 65535	---	1	F500	0
DC12	Virtual Output States (30 items)	0 to 65535	---	1	F500	0
DC30	Contact Input States (8 items)	0 to 65535	---	1	F500	0
DC38	Contact Output States (8 items)	0 to 65535	---	1	F500	0
DC40	Breaker Control Flex Operand States (25 items)	0 to 65535	---	1	F500	0
DC59	Bus Differential Flex Operand States (2 items)	0 to 65535	---	1	F500	0
DC5B	Over Demand Flex Alarm Flex Operand States (3 items)	0 to 65535	---	1	F500	0
DC5E	Under Demand Flex Alarm Flex Operand States (3 items)	0 to 65535	---	1	F500	0

**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>PLC Interface (Read/Write Settings)</b>						
DC61	PLC Interface Reserved	0 to 65535	---	1	F500	0
DC63	Reduced Let Thru Flex Operand States (4 items)	0 to 65535	---	1	F500	0
DC67	Ground Fault Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DC73	High Current Flex Operand States (6 items)	0 to 65535	---	1	F500	0
DC79	High Current Flex Relay Flex Operand States (3 items)	0 to 65535	---	1	F500	0
DC7C	High Current Transient Flex Operand States (6 items)	0 to 65535	---	1	F500	0
DC82	HRGF Detection Flex Operand States (6 items)	0 to 65535	---	1	F500	0
DC88	HRGF Location Flex Operand States	0 to 65535	---	1	F500	0
DC89	IOC Flex Operand States (4 items)	0 to 65535	---	1	F500	0
DC8D	LT Overcurrent Flex Operand States (6 items)	0 to 65535	---	1	F500	0
DC93	MSGF Overcurrent Flex Operand States (2 items)	0 to 65535	---	1	F500	0
DC95	System Operand States (1 item)	0 to 65535	---	1	F500	0
DC96	Over Frequency Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DCA2	Over Voltage Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DCAE	Phase Loss Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DCBA	Power Reversal Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DCC6	PLC Interface Reserved 2	0 to 65535	---	1	F500	0
DCD2	ST Overcurrent Flex Operand State States (6 items)	0 to 65535	---	1	F500	0
DCD8	Summation MSGF Zone Flex Operand States	0 to 65535	---	1	F500	0
DCD9	Synch Check Flex Operand States (8 items)	0 to 65535	---	1	F500	0
DCE1	Under Frequency Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DCED	Under Voltage Flex Operand States (12 items)	0 to 65535	---	1	F500	0
DCF9	Under Voltage Flex Relay Flex Operand States (6 items)	0 to 65535	---	1	F500	0
DCFF	PLC Interface Reserved 3	0 to 65535	---	1	F500	0
DD00	Breaker IO Flex Operand States (15 items)	0 to 65535	---	1	F500	0
DD0F	GOOSE Input Flex Operand States (16 items)	0 to 65535	---	1	F500	0
<b>Source Group Settings (Read/Write Settings) (30 Modules)</b>						
DE3F	SRC X Adjustable Selective IOC Setting	0 to 48	Half Cycle	1	F001	0
DE4F	SRC X Reserved					
DE5F	...Repeated for module number 2					
DE7F	...Repeated for module number 3					
DE9F	...Repeated for module number 4					
DEBF	...Repeated for module number 5					
DEDF	...Repeated for module number 6					
DEFF	...Repeated for module number 7					
DF1F	...Repeated for module number 8					
DF3F	...Repeated for module number 9					
DF5F	...Repeated for module number 10					
DF7F	...Repeated for module number 11					
DF9F	...Repeated for module number 12					
DFBF	...Repeated for module number 13					
DFDF	...Repeated for module number 14					
DFFF	...Repeated for module number 15					
E01F	...Repeated for module number 16					
E03F	...Repeated for module number 17					

Table 54: Modbus memory map (Continued)

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Group Settings (Read/Write Settings) (30 Modules) (Continued)</b>						
E05F	...Repeated for module number 18					
E07F	...Repeated for module number 19					
E09F	...Repeated for module number 20					
E0BF	...Repeated for module number 21					
E0DF	...Repeated for module number 22					
E0FF	...Repeated for module number 23					
E11F	...Repeated for module number 24					
E13F	...Repeated for module number 25					
E15F	...Repeated for module number 26					
E17F	...Repeated for module number 27					
E19F	...Repeated for module number 28					
E1BF	...Repeated for module number 29					
E1DF	...Repeated for module number 30					
<b>Source Group Settings (Read/Write Settings) (30 Modules)</b>						
E1FF	SRC X IOC Enabled (16 items)	0 to 1	---	1	F718	1
E20F	SRC X IOC Pickup Setting Multiplier (16 items)	15 to 150	%LT Pickup	5	F001	60
E21F	SRC X Short Time Protection Switch (16 items)	0 to 1	---	1	F102	1
E22F	SRC X Short Time Pickup Setting (16 items)	15 to 90	xLT Pickup	5	F001	40
E23F	SRC X Short Time I2T Curve (16 items)	0 to 2	---	1	F725	0
E24F	SRC X Short Time Delay Band Setting (16 items)	0 to 6	---	1	F713	2
E25F	SRC X Long Time Delay Band Setting (16 items)	0 to 3	---	1	F711	1
E26F	SRC X GF Protection Switch (16 items)	0 to 1	---	1	F102	0
E27F	SRC X GF Protection Trip Pickup Setting (16 items)	20 to 60	xCT	1	F001	24
E28F	SRC X GF Protection Trip I2T Curve (16 items)	0 to 1	---	1	F102	1
E29F	SRC X GF Protection Trip Delay Band Setting (16 items)	0 to 6	---	1	F713	2
E2AF	SRC X GF Protection Trip Priority (16 items)	0 to 30	---	1	F001	0
E2BF	SRC X GF Protection Alarm Enable (16 items)	0 to 1	---	1	F102	0
E2CF	SRC X GF Protection Alarm Pickup Setting (16 items)	20 to 60	xCT	1	F001	24
E2DF	SRC X GF Protection Alarm I2T Curve (16 items)	0 to 1	---	1	F102	1
E2EF	SRC X GF Protection Alarm Delay Band Setting (16 items)	0 to 6	---	1	F713	2
E2FF	...Repeated for module number 2					
E3FF	...Repeated for module number 3					
E4FF	...Repeated for module number 4					
E5FF	...Repeated for module number 5					
E6FF	...Repeated for module number 6					
E7FF	...Repeated for module number 7					
E8FF	...Repeated for module number 8					
E9FF	...Repeated for module number 9					
EAFF	...Repeated for module number 10					
EBFF	...Repeated for module number 11					
ECFF	...Repeated for module number 12					
EDFF	...Repeated for module number 13					
EEFF	...Repeated for module number 14					
EFFF	...Repeated for module number 15					
FOFF	...Repeated for module number 16					

—  
**Table 54: Modbus memory map (Continued)**

Addr	Register Name	Range	Units	Step	Format	Factory Default
<b>Source Group Settings (Read/Write Settings) (30 Modules) (Continued)</b>						
F1FF		...Repeated for module number 17				
F2FF		...Repeated for module number 18				
F3FF		...Repeated for module number 19				
F4FF		...Repeated for module number 20				
F5FF		...Repeated for module number 21				
F6FF		...Repeated for module number 22				
F7FF		...Repeated for module number 23				
F8FF		...Repeated for module number 24				
F9FF		...Repeated for module number 25				
FAFF		...Repeated for module number 26				
FBFF		...Repeated for module number 27				
FCFF		...Repeated for module number 28				
FDFE		...Repeated for module number 29				
FEFF		...Repeated for module number 30				

# Modbus memory map format codes

Table 55: Modbus memory map format codes

Format name	Format type/Bitmask	Format definition
F001	UR_UINT16	UNSIGNED 16 BIT INTEGER
F002	UR_SINT16	SIGNED 16 BIT INTEGER
F003	UR_UINT32	UNSIGNED 32 BIT INTEGER (2 registers)
	0	High order word is stored in the first register
	1	Low order word is stored in the second register
F004	UR_SINT32	SIGNED 32 BIT INTEGER (2 registers)
	0	High order word is stored in the first register
	1	Low order word is stored in the second register
F005	UR_UINT8	UNSIGNED 8 BIT INTEGER
F006	UR_SINT8	SIGNED 8 BIT INTEGER
F008	ENUMERATION	Discrete I/O type
	0	No Discrete IO
	1	PMC Discrete IO
	2	Profinet Discrete IO
F013	POWER_FACTOR	POWER FACTOR (SIGNED 16 BIT INTEGER)
	UR_UINT32	Positive values indicate lagging power factor; negative values indicate leading TIME and DATE (UNSIGNED 32 BIT INTEGER)
F050		Gives the current time in seconds elapsed since 00:00:00 January 1, 1970
F060	FLOATING_POINT	IEEE FLOATING POINT (32 bits)
F072	HEX6	6 BYTES - 12 ASCII DIGITS
F075	HEX162	162 BYTES - 325 ASCII DIGITS
F076	HEX172	172 BYTES - 344 ASCII DIGITS
F090	ENUMERATION	Latching Output Type
	0	Operate Dominant
	1	Reset Dominant
F100	ENUMERATION	VT CONNECTION TYPE
	0	Wye
	1	Delta
F102	ENUMERATION	DISABLED/ENABLED
	0	Disabled
	1	Enabled
F108	ENUMERATION	OFF/ON
	0	Off
	1	On
F124	600+ items	Too many to list here, refer to the database or database report generator
	ENUMERATION	ACCESS LEVEL
F125	0	Restricted
	1	Command
	2	Setting
	3	Factory Service

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	ENUMERATION	NO/YES CHOICE
	0	No
<b>F126</b>	1	Yes
	ENUMERATION	DISABLED/ENABLED
	0	F176_NONE
	1	F176_LV1_AND_DV2
	2	F176_DV1_AND_LV2
	3	F176_DV1_OR_DV2
	4	F176_DV1_XOR_DV2
	5	F176_DV1_AND_DV2
<b>F176</b>	6	F176_END
	TEXT40	40 CHARACTER ASCII TEXT
<b>F200</b>		20 registers -16 Bits: 1st Char MSB, 2nd Char. LSB
	TEXT8	8 CHARACTER ASCII PASSCODE
<b>F201</b>		4 registers -16 Bits: 1st Char MSB, 2nd Char. LSB
	TEXT20	20 CHARACTER ASCII TEXT
<b>F202</b>		10 registers -16 Bits: 1st Char MSB, 2nd Char. LSB
<b>F203</b>	TEXT16	16 CHARACTER ASCII TEXT
<b>F204</b>	TEXT80	80 CHARACTER ASCII TEXT
<b>F205</b>	TEXT12	12 CHARACTER ASCII TEXT
<b>F209</b>	TEXT14	14 CHARACTER ASCII TEXT
	UR_UINT16	FLEXLOGIC BASE TYPE (6 bit type)
		"When P bit if set, the flexlogic BASE type is 5 bits [T] and is combined with a 10 bits [D] descriptor and 1 bit [P] for protection. The combined bits are of the form : PTTTTDDDDDDDDDD. P bit indicates that the flexlogic type is associated with a protection element state."
		"When P bit if not set, the flexlogic BASE type is 6 bits [T] and is combined with a 9 bits [D] descriptor and 1 bit [P] for protection. The combined bits are of the form : PTTTTDDDDDDDDDD. The values in square brackets indicate the base type with P prefix [PTTTTT] and the values in round brackets indicate the descriptor range."
		[0] Off (0) this is boolean FALSE value
		[0] On (1)This is boolean TRUE value
		[2] CONTACT INPUTS ON (1 - 128)
		[3] CONTACT INPUTS OFF (1 - 128)
		[4] VIRTUAL INPUTS ON (1-32)
		[5] VIRTUAL INPUTS OFF (1-32)
		[6] VIRTUAL OUTPUTS ON (1-480)
		[7] VIRTUAL OUTPUTS OFF (1-480)
		[8] CONTACT OUTPUTS ON (1 - 128)
		[9] CONTACT OUTPUTS OFF (1 - 128)
		[10] PLC INPUTS ON (1-256)
		[11] PLC INPUTS OFF (1-256)
		[12] DISCRETE IO BOARD
		[24] PASSWORD CHECK
		[28] INSERT (Via Keypad only)
		[30] DELETE (Via Keypad only)
		[32] END
		[34] NOT (1 INPUT)
		[36] 2 INPUT XOR (0)
		[38] LATCH SET/RESET (2 INPUTS)
<b>F300</b>		[40] OR (2-16 INPUTS)

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	UR_UNIT16	FLEXLOGIC BASE TYPE (6 bit type)
		[42] AND (2-16 INPUTS)
		[44] NOR (2-16 INPUTS)
		[46] NAND (2-16 INPUTS)
		[48] TIMER (1-32)
		[50] ASSIGN VIRTUAL OUTPUT (1 - 512)
		[54] SELF-TEST ERROR (See F141 for range)
		[62] MISCELLANEOUS EVENTS (See F146 for range)
<b>F300</b>		[64-127] ELEMENT STATES (Refer to Memory Map Element States Section)
	ENUMERATION	FLEXLOGIC REDUNDANCY MODE
	0	CPU Auto Control Transfer Mode
	1	CPU External Control Transfer Mode
<b>F301</b>	2	Island Mode
	BITFIELD	UR_UINT16 Packed Bitfield
<b>F500</b>		Bits are not defined in database
	BITFIELD	SRCx Node Internal Diagnostics Bit Mask
	0	Power-on Self Test Error Detected
	1	Built-In-Test Error Detected
	2	Invalid Data Detected
	3	Jamb sync occurred over threshold
	4	Bad node configuration detected
	5	Bad CRC check of node firmware
	6	iButton data invalid or iButton missing
	7	EEPROM config information is invalid
	8	Not Used
	9	Not Used
	10	Not Used
	11	Not Used
	12	Not Used
	13	Not Used
	14	Not Used
<b>F701</b>	15	Not Used
	BITFIELD	SRCx Node System Diagnostics 1
	0	Node not receiving a broadcast message from C/CPU 0
	1	Node not receiving a broadcast message from C/CPU 1
	2	No link pulse from C/CPU 0
	3	No link pulse from C/CPU 1
	4	Bad system frequency received from C/CPU 0
	5	Bad system frequency received from C/CPU 1
	6	Bad IOC pickup setting multiplier received from C/CPU 0
	7	Bad IOC pickup setting multiplier received from C/CPU 1
	8	Bad ST setting received from C/CPU 0
	9	Bad ST setting received from C/CPU 1
	10	Bad GF setting received from C/CPU 0
	11	Bad GF setting received from C/CPU 1
	12	Invalid command received from C/CPU 0
	13	Invalid command received from C/CPU 1
	14	C/CPU 0 command not completed due to arbitration
<b>F702</b>	15	C/CPU 1 command not completed due to arbitration

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	SRCx Node System Diagnostics 2
	0	C/CPU 0 command timed out
	1	C/CPU 1 command timed out
	2	Node synch not locked
	3	Unknown Message Received on Port 0
	4	Unknown Message Received on Port 1
	5	Node firmware download error
	6	Node firmware download complete
	7	Node firmware download verify ok
	8	Node firmware download ok
	9	Node firmware download verify error
	10	Duplicate CPU ID
	11	iButton rejected due to value(s) out of range
	12	spare
	13	spare
	14	spare
<b>F703</b>	15	spare
	BITFIELD	SRCx Node Hardware Diagnostics
	0	Node switchover to secondary control power (1 bit) - NOT USED
	1	Fan is on (1 bit)
	2	A/D reset failure (1 bit) - NOT USED
	3	A/D Calibration failure (1 bit) - NOT USED
	4	A/D Interrupt missing (1 bit) - NOT USED
	5	A/D Analog IOC failure (1 bit)
	6	Node Not Calibrated (1 bit)
	7	Unit not programmed (1 bit) - NOT USED
	8	Equipment mismatch (1 bit) - NOT USED
	9	Program memory test failed (1 bit) - NOT USED
	10	Control Power 1 Status
	11	Control Power 2 Status
	12	Node application flash CRC fail (1 bit)
	13	Node boot flash CRC fail (1 bit)
	14	Option box fail (1 bit)
<b>F704</b>	15	Spare (1 bit)
	BITFIELD	SRCx NodeProt Protection Function Configuration
	0	Ground Fault Protection Enabled
	1	Instantaneous Overcurrent Protection Enabled
	2	Short Time Protection Enabled
	3	Switchable ST/IOC Protection Enabled/Disabled
	4	Switchable GF
	5	Spare
	6	Spare
	7	Spare
	8	Not Used
	9	Not Used
	10	Not Used
	11	Not Used
	12	Not Used
	13	Not Used
	14	Not Used
<b>F705</b>	15	Not Used

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	SRCx Reflected CCPU Diagnostics
	0	C/CPU 0 is using the hardware clock
	1	C/CPU 0 is not receiving data from one or more nodes
	2	C/CPU 0 Identifier
	3	C/CPU 0 ATO - C/CPU is in control
	4	C/CPU 0 FTO State - C/CPU is in external control transfer mode
	5	spare
	6	spare
	7	spare
	8	C/CPU 1 is using the hardware clock
	9	C/CPU 1 is not receiving data from one or more nodes
	10	C/CPU 1 Identifier
	11	C/CPU 1 ATO - C/CPU is in control
	12	C/CPU 1 FTO State - C/CPU is in external control transfer mode
	13	spare
	14	spare
<b>F706</b>	15	spare
	BITFIELD	SRCx Reflected CCPU Commands
	0	No Op
	1	Open
	2	Close
	3	Trip
	4	Network Interlock
	5	Reset Interlock
	6	Light LED
	7	Messenger Machine Output On
	8	Start Firmware Download
	9	Switch Firmware
	10	Cancel Firmware Download
	11	Ignore C/CPU Message
	12	Firmware Packet Present
	13	Flux Shifter Open
	14	Flux Shifter Trip
<b>F707</b>	15	FTO Command - requesting to assume control
	BITFIELD	SRCx Node Physical Status
	0	Breaker Contacts Open
	1	Breaker Contacts Closed
	2	Lockout
	3	Closing Spring Charged
	4	Primary Connected
	5	Primary Disconnected
	6	Secondary Connected
	7	Door Interlock - NOT USED
	8	Analog IOC
	9	Shunt Trip Circuit Failure
	10	ZSI Input Active
	11	Downstream ZSI Enabled
	12	Messenger Machine Input 1
	13	Messenger Machine Input 2
	14	Messenger Machine Output
<b>F708</b>	15	spare

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	SRCx Node Logic and Trip Status
	0	Synchronization Source Bit 0
	1	Synchronization Source Bit 1
	2	Download Source Bit 0
	3	Download Source Bit 1
	4	Download Complete
	5	Test Mode
	6	GF Suspend
	7	spare
	8	Trip Flag
	9	Trip due to LT
	10	Trip due to ST
	11	Trip due to GF
	12	Trip due to IOC
	13	Phase Indicator Bit 0
	14	Phase Indicator Bit 1
<b>F709</b>	15	spare
	BITFIELD	SRCx CCPU Reduced Let Thru Status
	0	Synchronization Source
	1	Reduced Let Thru Status
	2	Topology Status (0 if topology 0; 1 if not topology 0)
	3	spare
	4	spare
	5	spare
	6	spare
	7	spare
	8	spare
	9	spare
	10	spare
	11	spare
	12	spare
	13	spare
	14	spare
<b>F710</b>	15	spare
	ENUMERATION	SRCx Long Time Delay Band Setting
	0	Band 1: KLT = 108 Seconds
	1	Band 2: KLT = 216 Seconds
	2	Band 3: KLT = 432 Seconds
<b>F711</b>	3	Band 4: KLT = 900 Seconds
	ENUMERATION	SRCx Breaker Connection (pwr flow)
	0	Forward
<b>F712</b>	1	Reverse
	ENUMERATION	Delay Band Settings
	0	Band 1
	1	Band 2
	2	Band 3
	3	Band 4
	4	Band 5
	5	Band 6
<b>F713</b>	6	Band 7

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
F714	ENUMERATION	SRCx Ground Fault Protection or Alarm Select
	0	Trip
	1	Alarm
F715	ENUMERATION	Breaker Type
	0	UL
	1	EG
	2	Other
	3	EGE Envelope 1 M1
	4	EGE Envelope 2 M2
	5	EGE Envelope 1
	6	EGE Envelope 2
F716	ENUMERATION	Product Type
	0	Low Voltage Switchgear
	1	Medium Voltage Switchgear
F717	ENUMERATION	Paralleling Switchgear
	2	Paralleling Switchgear
F718	ENUMERATION	CCPU Identifier
	0	CCPU "A"
	1	CCPU "B"
F718	ENUMERATION	IOC Protection Type
	0	Disabled
F718	ENUMERATION	Enabled
	1	Enabled
F719	ENUMERATION	SRCx PT Wiring
	0	None
	1	PT_RATING_600V_DELTA
	2	PT_RATING_600V_WYE
	3	PT_RATING_480V_DELTA
	4	PT_RATING_480V_WYE
	5	PT_RATING_240V_DELTA
	6	PT_RATING_208V_WYE
	7	PT_RATING_400V_DELTA
	8	PT_RATING_400V_WYE
	9	PT_RATING_415V_DELTA
F720	ENUMERATION	PT_RATING_415V_WYE
	10	PT_RATING_415V_WYE
	BITFIELD	Node 0 - 15 Bit Vector
	0	Bit field representing a 0 or 1 for Node 0
	1	Bit field representing a 0 or 1 for Node 1
	2	Bit field representing a 0 or 1 for Node 2
	3	Bit field representing a 0 or 1 for Node 3
	4	Bit field representing a 0 or 1 for Node 4
	5	Bit field representing a 0 or 1 for Node 5
	6	Bit field representing a 0 or 1 for Node 6
	7	Bit field representing a 0 or 1 for Node 7
	8	Bit field representing a 0 or 1 for Node 8
	9	Bit field representing a 0 or 1 for Node 9
	10	Bit field representing a 0 or 1 for Node 10
	11	Bit field representing a 0 or 1 for Node 11
	12	Bit field representing a 0 or 1 for Node 12
13	Bit field representing a 0 or 1 for Node 13	
14	Bit field representing a 0 or 1 for Node 14	
F720	15	Bit field representing a 0 or 1 for Node 15

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	Node 16 - 29 Bit Vector
	0	Bit field representing a 0 or 1 for Node 16
	1	Bit field representing a 0 or 1 for Node 17
	2	Bit field representing a 0 or 1 for Node 18
	3	Bit field representing a 0 or 1 for Node 19
	4	Bit field representing a 0 or 1 for Node 20
	5	Bit field representing a 0 or 1 for Node 21
	6	Bit field representing a 0 or 1 for Node 22
	7	Bit field representing a 0 or 1 for Node 23
	8	Bit field representing a 0 or 1 for Node 24
	9	Bit field representing a 0 or 1 for Node 25
	10	Bit field representing a 0 or 1 for Node 26
	11	Bit field representing a 0 or 1 for Node 27
	12	Bit field representing a 0 or 1 for Node 28
	13	Bit field representing a 0 or 1 for Node 29
	14	Not Used
<b>F721</b>	15	Not Used
	BITFIELD	Node 0 - 29 Bit Vector
	0	Bit field representing a 0 or 1 for Node 0
	1	Bit field representing a 0 or 1 for Node 1
	2	Bit field representing a 0 or 1 for Node 2
	3	Bit field representing a 0 or 1 for Node 3
	4	Bit field representing a 0 or 1 for Node 4
	5	Bit field representing a 0 or 1 for Node 5
	6	Bit field representing a 0 or 1 for Node 6
	7	Bit field representing a 0 or 1 for Node 7
	8	Bit field representing a 0 or 1 for Node 8
	9	Bit field representing a 0 or 1 for Node 9
	10	Bit field representing a 0 or 1 for Node 10
	11	Bit field representing a 0 or 1 for Node 11
	12	Bit field representing a 0 or 1 for Node 12
	13	Bit field representing a 0 or 1 for Node 13
	14	Bit field representing a 0 or 1 for Node 14
	15	Bit field representing a 0 or 1 for Node 15
	16	Bit field representing a 0 or 1 for Node 16
	17	Bit field representing a 0 or 1 for Node 17
	18	Bit field representing a 0 or 1 for Node 18
	19	Bit field representing a 0 or 1 for Node 19
	20	Bit field representing a 0 or 1 for Node 20
	21	Bit field representing a 0 or 1 for Node 21
	22	Bit field representing a 0 or 1 for Node 22
	23	Bit field representing a 0 or 1 for Node 23
	24	Bit field representing a 0 or 1 for Node 24
	25	Bit field representing a 0 or 1 for Node 25
	26	Bit field representing a 0 or 1 for Node 26
	27	Bit field representing a 0 or 1 for Node 27
	28	Bit field representing a 0 or 1 for Node 28
	29	Bit field representing a 0 or 1 for Node 29
	30	Not Used
<b>F722</b>	31	Not Used

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	ENUMERATION	CCPU Events
		Too many to list here, refer to the database or database report generator.
<b>F723</b>	ENUMERATION	LV Phase Info
	0	None
	1	Phase A
	2	Phase B
<b>F724</b>	3	Phase C
	ENUMERATION	I2T Curve Setting
	0	Disabled
	1	Enabled
<b>F725</b>	2	Enabled Limited
	ENUMERATION	SRCX Curvetype
	0	Inverse Time Curve
<b>F726</b>	1	Constant Time Curve
	ENUMERATION	SRCX OPEN/TRIP setting
	0	Open, Don't activate lockout
<b>F727</b>	1	Trip, Activate lockout
	BITFIELD	Options Bit Field
	1	Synch check relay
	2	Bus differential
	3	Multi-source ground fault
	4	ZSI
	5	High resistance ground fault
	6	Waveform capture
	7	Flux Shifter Backup
	8	Reduced Energy Let Through
	9	Flex Relays
	10	Reverse Current Protection
	11	Directional ZSI
	12	GF Tripping Priority
<b>F728</b>	13 to 16	Spare
	BITFIELD	Zone 0 - 3 Bit Field Vector
	0	Bus Differential Trip Alarm State
	1	Bus Differential Trip Alarm Ack
	2	Bus Differential Alarm State
	3	Bus Differential Alarm Ack
	4	Multi Source Ground Fault Trip Alarm State
	5	Multi Source Ground Fault Trip Alarm Ack
	6	Multi Source Ground Fault State
	7	Multi Source Ground Fault Ack
<b>F729</b>	8 to 31	Spare
	BITFIELD	CCPU HW Status
	0	Invalid
	1	CF Detected
	2	CF in Use
	3	Failure to restore eeprom.mem access
	4	Failure to restore sram.mem access
<b>F730</b>	5 to 31	Spare
<b>F731</b>	ENUMERATION	Deleted ZSI Type format

**Table 55: Modbus memory map format codes (Continued)**

Format name	Format type/Bitmask	Format definition
	ENUMERATION	ZSI Option
	0	ST ZSI
	1	GF ZSI
<b>F732</b>	2	ST and GF ZSI
	ENUMERATION	ZSI Zone Tier Settings
	0	ZSI Tier 0
	1	ZSI Tier 1
	2	ZSI Tier 2
<b>F733</b>	3	ZSI Tier 3
	ENUMERATION	Contact I/O Debounce values
	0	Disabled
	1	Enabled_00016
	2	Enabled_00104
	3	Enabled_04088
<b>F734</b>	4	Enabled_32760
	ENUMERATION	Multipoint delay Band Settings
	0	Band 1
	1	Band 2
	2	Band 3
	3	Band 4
	4	Band 5
<b>F735</b>	5	Band 6
	BITFIELD	Contact Input Configuration Low Vector
	0	0 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	1	1 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	2	2 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	3	3 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	4	4 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	5	5 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	6	6 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	7	7 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	8	8 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	9	9 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	10	10 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	11	11 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	12	12 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	13	13 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	14	14 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	15	15 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	16	16 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	17	17 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	18	18 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	19	19 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	20	20 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	21	21 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	22	22 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
23	23 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output	
<b>F736</b>	24	24 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	Contact Input Configuration Low Vector
	25	25 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	26	26 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	27	27 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	28	28 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	29	29 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	30	30 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
<b>F736</b>	31	31 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	BITFIELD	Contact Input Configuration High Vector
	0	32 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	1	33 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	2	34 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	3	35 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	4	36 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	5	37 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	6	38 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	7	39 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	8	40 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	9	41 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	10	42 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	11	43 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	12	44 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	13	45 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	14	46 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	15	47 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	16	48 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	17	49 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	18	50 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	19	51 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	20	52 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	21	53 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	22	54 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	23	55 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	24	56 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	25	57 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	26	58 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	27	59 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	28	60 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	29	61 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	30	62 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
<b>F737</b>	31	63 - I/O x + (bit number) Input, 1 - I/O x + (bit number) Output
	ENUMERATION	Option String Authentication Status
	0	New and Old Both Optionstrings Invalid
	1	Using Valid New OptionString
<b>F738</b>	2	Using Valid Old OptionString

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	Reduced Let Thru Bit Vector
	0	Bit field representing 0 or 1 for Node 0 RELT
	1	Bit field representing 0 or 1 for Node 1 RELT
	2	Bit field representing 0 or 1 for Node 2 RELT
	3	Bit field representing 0 or 1 for Node 3 RELT
	4	Bit field representing 0 or 1 for Node 4 RELT
	5	Bit field representing 0 or 1 for Node 5 RELT
	6	Bit field representing 0 or 1 for Node 6 RELT
	7	Bit field representing 0 or 1 for Node 7 RELT
	8	Bit field representing 0 or 1 for Node 8 RELT
	9	Bit field representing 0 or 1 for Node 9 RELT
	10	Bit field representing 0 or 1 for Node 10 RELT
	11	Bit field representing 0 or 1 for Node 11 RELT
	12	Bit field representing 0 or 1 for Node 12 RELT
	13	Bit field representing 0 or 1 for Node 13 RELT
	14	Bit field representing 0 or 1 for Node 14 RELT
	15	Bit field representing 0 or 1 for Node 15 RELT
	16	Bit field representing 0 or 1 for Node 16 RELT
	17	Bit field representing 0 or 1 for Node 17 RELT
	18	Bit field representing 0 or 1 for Node 18 RELT
	19	Bit field representing 0 or 1 for Node 19 RELT
	20	Bit field representing 0 or 1 for Node 20 RELT
	21	Bit field representing 0 or 1 for Node 21 RELT
	22	Bit field representing 0 or 1 for Node 22 RELT
	23	Bit field representing 0 or 1 for Node 23 RELT
	24	Bit field representing 0 or 1 for Node 24 RELT
	25	Bit field representing 0 or 1 for Node 25 RELT
	26	Bit field representing 0 or 1 for Node 26 RELT
	27	Bit field representing 0 or 1 for Node 27 RELT
	28	Bit field representing 0 or 1 for Node 28 RELT
	29	Bit field representing 0 or 1 for Node 29 RELT
	30	Bit field representing 0 or 1 for Multipoint RELT
<b>F739</b>	31	Bit field representing 0 or 1 for System RELT
	ENUMERATION	ST Restrained Delay Band Settings
	0	Disabled
	1	Band 1
	2	Band 2
	3	Band 3
	4	Band 4
	5	Band 5
	6	Band 6
<b>F740</b>	7	Band 7

Table 55: Modbus memory map format codes (Continued)

Format name	Format type/Bitmask	Format definition
	BITFIELD	GOOSE Input Health Status
	0	Input Data Updated
	1	Input Time to Live Expired
	2	Input Out of Sequence Detected
	3	Input Configuration Revision Mismatch
	4	Input Need Commissioning
	5	Input Test Mode
	6	Input Goose Control Block Reference Mismatch
	7	Input App ID Mismatch
	8	Input Data Set Mismatch
	9	Input Incorrect Data Type
	10	Input Data Item Not Configured
	11	Spare
	12	Spare
	13	Spare
	14	Spare
<b>F741</b>	15	Input Heartbeat Received
	BITFIELD	GOOSE System Health Status
	0	OSI File Configuration Failure
	1	Network Driver Initialization Failure
	2	Memory Initialization Failure
<b>F742</b>	3	Log File Configuration Failure
	BITFIELD	GOOSE Input System Health Status
	0	File Read Failure
	1	File Parse Failure
	2	Data Type Creation Failure
	3	Data Item Creation Failure
	4	SCL Initialization Failure
	5	GOOSE Control Block Initialization Failure
	6	Memory Initialization Failure
	7	MAC Address Initialization Failure
	8	Destination MAC Address Mismatch
	9	Configuration Timeout
	10	VLAN Priority Parse Failure
	11	VLAN ID Parse Failure
<b>F743</b>	12	Data Index Mapping Error
	BITFIELD	GOOSE Output System Health Status
	0	File Read Failure
	1	File Parse Failure
	2	Data Type Creation Failure
	3	Data Item Creation Failure
	4	SCL Initialization Failure
	5	GOOSE Control Block Initialization Failure
	6	VLAN Priority Initialization Failure
	7	VLAN ID Initialization Failure
	8	Data Map File Read Failure
	9	MAC Address Parse Failure
	10	Data Mapping Error
<b>F744</b>	11	Configuration Timeout



---

**ABB Inc.**

305 Gregson Drive  
Cary, NC 27511 USA  
[abb.com/contacts](http://abb.com/contacts)

**[abb.com/lowvoltage](http://abb.com/lowvoltage)**

**GE is a trademark of GE.**

**Manufactured by ABB Inc. under license  
from General Electric Company.**

The information contained in this document is for general information purposes only. While ABB strives to keep the information up to date and correct, it makes no representations or warranties of any kind, express or implied, about the completeness, accuracy, reliability, suitability or availability with respect to the information, products, services, or related graphics contained in the document for any purpose. Any reliance placed on such information is therefore strictly at your own risk. ABB reserves the right to discontinue any product or service at any time.

© Copyright 2022 ABB. All rights reserved.