



## The Company

We are an established world force in the design and manufacture of instrumentation for industrial process control, flow measurement, gas and liquid analysis and environmental applications.

As a part of ABB, a world leader in process automation technology, we offer customers application expertise, service and support worldwide.

We are committed to teamwork, high quality manufacturing, advanced technology and unrivalled service and support.

The quality, accuracy and performance of the Company's products result from over 100 years experience, combined with a continuous program of innovative design and development to incorporate the latest technology.

The UKAS Calibration Laboratory No. 0255 is just one of the ten flow calibration plants operated by the Company, and is indicative of our dedication to quality and accuracy.

EN ISO 9001:2000



Cert. No. Q5907

EN 29001 (ISO 9001)



Lenno, Italy – Cert. No. 9/90A

## Electrical Safety

This equipment complies with the requirements of CEI/IEC 61010-1:2001-2 'Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use'. If the equipment is used in a manner NOT specified by the Company, the protection provided by the equipment may be impaired.

## Symbols

One or more of the following symbols may appear on the equipment labelling:

	<b>Warning</b> – Refer to the manual for instructions
	<b>Caution</b> – Risk of electric shock
	Protective earth (ground) terminal
	Earth (ground) terminal

	Direct current supply only
	Alternating current supply only
	Both direct and alternating current supply
	The equipment is protected through double insulation

Information in this manual is intended only to assist our customers in the efficient operation of our equipment. Use of this manual for any other purpose is specifically prohibited and its contents are not to be reproduced in full or part without prior approval of the Technical Publications Department.

### Health and Safety

To ensure that our products are safe and without risk to health, the following points must be noted:

1. The relevant sections of these instructions must be read carefully before proceeding.
2. Warning labels on containers and packages must be observed.
3. Installation, operation, maintenance and servicing must only be carried out by suitably trained personnel and in accordance with the information given.
4. Normal safety precautions must be taken to avoid the possibility of an accident occurring when operating in conditions of high pressure and/or temperature.
5. Chemicals must be stored away from heat, protected from temperature extremes and powders kept dry. Normal safe handling procedures must be used.
6. When disposing of chemicals ensure that no two chemicals are mixed.

Safety advice concerning the use of the equipment described in this manual or any relevant hazard data sheets (where applicable) may be obtained from the Company address on the back cover, together with servicing and spares information.



## Step 3 – Setting the Parameters (Fig. GS.1)

- (A) Power-up the instrument. Press the and keys simultaneously and hold for 3 seconds to advance directly to Level 6 – Basic Configuration.
  - (B) Set the appropriate application template, output type and control action. Use the key to advance between frames and upper and keys to adjust the default values – see Section 4.2 for further information.
- 
- Note.** When the output type has been selected, the available inputs and outputs default to the settings shown in Table B on the rear fold-out.
- 
- (C) If you are not using 4 to 20mA inputs, then select Level 7 using the upper and keys and set up Analog Inputs I/P1 to I/P3 to suit your process – see Section 4.3.
  - (D) Controller templates only:  
Select Level 2 using the upper and keys and set the tune parameters:
    - **Analog or Motorized Valve Control** – set the Proportional, Integral and Derivative terms.
    - **Time Proportioning Control** – set the Cycle Time, Hysteresis and P, I & D Terms
    - **Heat/Cool Outputs** – set the points at which the Output 1 and Output 2 become active.
  - (E) Press to return to the Operating displays.
  - (F) Adjust the set point to the required value.

*Your COMMANDER 500 is now in operation*




Fig. GS.1 Setting the Parameters



## GETTING STARTED

---

The COMMANDER 500 can be configured and made ready for operation in three easy steps. This 'Getting Started' guide provides an overview of these steps and, where necessary, refers to the relevant section of the manual.

**Step 1 – Decide on the Application Template and the Output Configuration required**

**Step 2 – Connect the process inputs and outputs**

**Step 3 – Power up the instrument, set the template number and the output configuration details**

*Your COMMANDER 500 is now ready for operation*

### **Step 1 – Application Template and Output Configuration**

- Choose the Template which best suits your application from the list in Table A, located on the rear fold-out.
- Choose the Control Output Type required from the list of options in Table B on the rear foldout.

### **Step 2 – Electrical Connections**

Using the labels on the back of the instrument as a guide, connect the process inputs, outputs and power supplies. Refer to Section 5.2 of this manual (Electrical Installation) for more information.


*Continued...*

# OVERVIEW

This manual is divided into 5 sections which contain all the information needed to install, configure, commission and operate the C505 Advanced Process Controller. Each section is identified clearly by a symbol as shown in Fig. 1.

	<p><b>Displays and Controls</b></p> <ul style="list-style-type: none"> <li>• Displays and Function Keys</li> <li>• LED Indication</li> <li>• Error Messages</li> </ul>		<p><b>Configuration Mode (Levels 6 to E)</b></p> <ul style="list-style-type: none"> <li>• Level 6 – Basic Configuration</li> <li>• Level 7 – Input Configuration</li> <li>• Level 8 – Alarm Configuration</li> <li>• Level 9 – Set Point Configuration</li> <li>• Level A – Control Configuration</li> <li>• Level B – Operator Configuration</li> <li>• Level C – Output Configuration</li> <li>• Level D – Serial Communications</li> <li>• Level E – System Calibration</li> </ul>
	<p><b>Operator Mode (Level 1)</b></p> <ul style="list-style-type: none"> <li>• Single Loop Controller</li> <li>• Motorized Valve Controller</li> <li>• Auto/Manual &amp; Backup Stations</li> <li>• Feedforward Controllers</li> <li>• Cascade Controllers</li> <li>• Ratio Station/Controller</li> </ul>		<p><b>Installation</b></p> <ul style="list-style-type: none"> <li>• Siting</li> <li>• Mounting</li> <li>• Electrical Connections</li> </ul>
	<p><b>Set Up Mode (Levels 2 to 5)</b></p> <ul style="list-style-type: none"> <li>• Level 2 – Tuning</li> <li>• Level 3 – Set Points</li> <li>• Level 4 – Alarm Trip Points</li> <li>• Level 5 – Valve Setup</li> </ul>		

**Fig. 1 Overview of Contents**



<p><b>Shunt Resistors</b> 2 x 100Ω (+1 optional)</p>	<p><b>Process Labels</b> x3</p>	<p><b>Panel Clamps</b> x2</p>	<p><b>CJ Sensor</b> x1 (+1 optional)</p>


**Fig. 3 Accessories**

# CONTENTS

Section	Page	Section	Page
<b>OVERVIEW</b> .....	<b>1</b>	<b>4 CONFIGURATION MODE</b> .....	<b>47</b>
<b>CONTENTS</b> .....	<b>2</b>	4.1 Introduction .....	47
<b>1 DISPLAYS AND FUNCTION KEYS</b> .....	<b>3</b>	4.2 Level 6 – Basic Configuration .....	48
1.1 Introduction .....	3	4.3 Level 7 – Analog Inputs .....	52
1.2 Use of Function Keys .....	4	4.4 Level 8 – Alarms .....	56
1.3 Secret-til-Lit Indicators .....	8	4.5 Level 9 – Set Point Configurationm .....	60
1.4 Character Set .....	8	4.6 Level A – Control Configuration .....	63
1.5 Error Messages .....	9	4.7 Level B – Operator Configuration .....	68
1.6 Processor Watchdog .....	10	4.8 Level C – Output Assignment Configuration .....	70
1.7 Loop Break Monitor .....	10	4.9 Level D – Serial Communications Configuration .....	76
1.8 Glossary of Abbreviations .....	10	4.10 Level E – Calibration .....	77
<b>2 OPERATOR LEVEL</b> .....	<b>11</b>	<b>5 INSTALLATION</b> .....	<b>80</b>
2.1 Introduction .....	11	5.1 Mechanical Installation .....	80
2.2 Single Loop Controller (Templates 1 and 2) .....	12	5.2 Electrical Installation .....	85
2.3 Auto/Manual Station (Templates 3 and 4) .....	14	5.3 Relays .....	88
2.4 Analog Backup (Templates 5 and 6) .....	16	5.4 Digital Output .....	88
2.5 Indicator/Manual Loader Station (Templates 7 and 8) .....	18	5.5 Control or Retransmission Analog Output .....	88
2.6 Single Loop with Feedforward (Templates 9 and 10) .....	19	5.6 Motorized Valve Connections .....	89
2.7 Cascade Control (Templates 11 and 12) .....	21	5.7 Input Connections .....	89
2.8 Cascade with Feedforward (Template 13) .....	24	5.8 Output Connections .....	90
2.9 Ratio Controller (Templates 14 and 15) .....	26	5.9 Power Supply Connections .....	90
2.10 Ratio Station (Templates 16 and 17) .....	27	<b>SPECIFICATION</b> .....	<b>91</b>
2.11 Heat/Cool Output Types .....	28	<b>APPENDIX A – CONTROL TEMPLATES</b> .....	<b>95</b>
2.12 Motorized Valve Output Types .....	29	A1 Single Loop Controller (Templates 1 and 2) .....	95
2.13 Auto-tune .....	30	A2 Auto/Manual Station and Analog Backup Station .....	96
2.14 Control Efficiency Monitor .....	33	A3 Indicator/Manual Loader Station (Templates 7 and 8) .....	99
<b>3 SET UP MODE</b> .....	<b>36</b>	A4 Single Loop Controller with Feedforward (Templates 9 and 10) .....	100
3.1 Introduction .....	36	A5 Cascade Controllers (Templates 11 and 12) .....	101
3.2 Level 2 – Tune .....	37	A6 Cascade Controller with Feedforward (Template 13) .....	102
3.3 Level 3 – Set Points .....	41	A7 Ratio Controller (Templates 14 and 15) .....	103
3.4 Level 4 – Alarm Trip Points .....	43	A8 Ratio Station (Templates 16 and 17) .....	104
3.5 Level 5 – Valve Setup .....	44	<b>APPENDIX B – PC CONFIGURATOR</b> .....	<b>105</b>
		B1 Introduction .....	105
		B2 Analog Input Customization .....	105
		B3 Four Programmable Math Blocks .....	105
		B4 Six Logic Equations .....	105
		B5 Process Alarm Customization .....	105
		B6 Two Real Time Alarms .....	105
		B7 Two Delay Timers .....	106
		B8 Two Custom Linearizers .....	106
		B9 Template Customization .....	106
		B10 Connecting the PC Configurator .....	106
		<b>FRAMES INDEX</b> .....	<b>107</b>
		<b>INDEX</b> .....	<b>110</b>

## 1.1 Introduction

The C500 front panel displays, function keys and LED indicators are shown in Fig. 1.1.



### Function Keys





Fig. 1.1 Front Panel Displays and Function Keys


1.2 Use of Function Keys

A – Raise and Lower Keys




Use to change/set a parameter value... and... ...move between levels

B – Up and Down Keys



Use to adjust the output value... and... ...move between frames within a Setup or Configuration level. Any changes made on the current frame are stored when the next frame is selected.


C – Parameter Advance Key



Use to advance to the next frame within a level... or... ...select the top (LEV.x) frame from within a level

**Note.** This key also stores any changes made in the previous frame

D – Auto/Manual Key




Use to select Auto or Manual control mode

Fig. 1.2a Use of Function Keys



## ...1.2 Use of Function Keys

## E – Alarm Acknowledgement



**Note.** If no alarms have been enabled in the Set Up level, pressing the key has no effect.

- ① The first active and unacknowledged alarm is displayed (or if no alarms are active, the first enabled alarm is displayed)

<i>HPU</i>	High Process, PV	<i>H0</i>	High Output
<i>LPU</i>	Low Process, PV	<i>L0</i>	Low Output
<i>HLP</i>	High Latch, PV	<i>PFE</i>	Power Failure Time
<i>LLP</i>	Low Latch, PV	<i>Hb1</i>	Maths Block 1 High
<i>Hd</i>	High Deviation	<i>Lb1</i>	Maths Block 1 Low
<i>Ld</i>	Low Deviation	<i>Hb2</i>	Maths Block 2 High
<i>HP1</i>	High Process I/P1	<i>Lb2</i>	Maths Block 2 Low
<i>LP1</i>	Low Process I/P1	<i>Hb3</i>	Maths Block 3 High
<i>HP2</i>	High Process I/P2	<i>Lb3</i>	Maths Block 3 Low
<i>LP2</i>	Low Process I/P2	<i>Hb4</i>	Maths Block 4 High
<i>HP3</i>	High Process I/P3	<i>Lb4</i>	Maths Block 4 Low
<i>LP3</i>	Low Process I/P3		

**Note.** The time of the power failure *PFE*, is shown in the set point display.


- ② The lower display shows alarm status:  
*ACT* Alarm active and unacknowledged  
*ACK* Alarm active and acknowledged  
*CLR* Cleared or Inactive alarm  
*LAL* Unacknowledged latched alarm
- ③ Pressing again acknowledges the displayed alarm. Lower display changes to reflect new status.
- ④ Next active and unacknowledged alarm is displayed. If no alarms are active, the next enabled alarm is displayed.

Fig. 1.2b Use of Function Keys

...1.2 Use of Function Keys

F – Local / Remote Key


Changing between Local and Remote Set Points



- ① Process variable and local set point (ratio) displayed on red and green displays.
- ② Remote set point (ratio) value is displayed. The value and **R** symbol flash to indicate local set point (ratio) still selected.
- ③ Remote set point (ratio) selected.
- ④ Remote selection aborted.


**Note.** When an Analog Backup Station template is selected, the **RD** key is used to switch between local and remote mode – see Sections 2.4 and 4.2.

Selecting Local Set Points 1 to 4



- ① Process variable and local set point 1 displayed.
- ② Process variable and local set point 2 displayed
- ③ Process variable and local set point 3 displayed
- ④ Process variable and local set point 4 displayed

Selecting Master and Slave Set Points – Cascade Mode



**Note.** Abbreviations are detailed in Section 1.8.

① When the MST indicator (see Fig 1.3) is lit, the **RD** key can be used to switch between the Master local and remote set points

② When the SLV indicator (see Fig 1.3) is lit, the **RD** key can be used to switch between the local slave set point and the cascade slave set point generated from the master output.

Fig. 1.2c Use of Function Keys

## ...1.2 Use of Function Keys

## G – Short-cut Keys




LEUR  
CntL





LEU.1  
OPER

Press to move from anywhere in the Configuration level to the first frame in the Operator level




Press simultaneously and hold for 3 seconds – see **Note**



LEU6  
APPL

Press to move from anywhere in the Operator or Setup levels to the first page of the Configuration level

**Note.** This Short-cut key operates only when the configuration password is set to '0'



COdE  
0

Press and hold to move from the Operator Level to the Security Code Frame and then to other levels:

Tune Level – See Section 2.13.3

Set Up Level – See Fig. 3.1

Configuration Level – See Fig. 4.1

Fig. 1.2d Use of Function Keys

1.3 Secret-til-Lit Indicators




Fig. 1.3 Secret-til-lit Indicators

1.4 Character Set – Fig. 1.4
















Fig. 1.4 Character Set

## 1.5 Error Messages

Display	Error/Action	To clear the display:
	<b>Calibration Error</b> Turn mains power off and on again (if the error persists contact the Customer Support Organization).	Press the  key
	<b>Non-volatile Memory Error</b> x = 1, 2: Motherboard Memory x = 3: Option Board Memory Turn mains power off and on again (if the error persists, check configuration/setup settings).	Press the  key
	<b>A to D Converter Fault</b> The analog to digital converter is not communicating correctly.	Contact the Customer Support Organization
	<b>Input Value Over/Under Range</b>	Restore valid input
	<b>Auto-tune Error</b> The number displayed indicates the type of error present – see Table 2.1 on page 30.	Press the  key
	<b>Cold Junction Failed</b> Cold junction sensor is faulty or has not been fitted correctly.	Check connections or replace if faulty.
	<b>Remote Set Point or External Ratio Failed.</b> Remote set point input value is over or under-range. Only appears if the remote set point (or external ratio) is displayed or in use.	Restore valid input
	<b>Valve Sticking</b> Motorized valve not moving at the speed expected. Valve may be sticking.	Check that the correct Regulator Travel Time has been set – see Section 3.5. Check the valve.
	<b>Position Feedback Fail</b> Input value is over- or under-range. Only appears if output type set to 'PFb' – motorized valve with feedback.	Restore valid input

**1.6 Processor Watchdog**

The instrument's processor activity is monitored by an independent watchdog device. When the output of the watchdog is assigned to a relay or digital output, the relay/digital output de-energizes if the instrument fails to function correctly.

**1.7 Loop Break Monitor**

Both analog outputs are monitored continuously to detect a loop break. A warning signal or other action can be initiated by assigning the loop break signals to relays or digital outputs.

**1.8 Glossary of Abbreviations**

Abbreviation	Description	Abbreviation	Description
<i>PU</i>	Process Variable	<i>d i 1</i>	Digital Input 1
<i>LSPt</i>	Local Set Point Value	<i>d i 2</i>	Digital Input 2
<i>LSP 1</i>	Local Set Point 1 Value	<i>d i 3</i>	Digital Input 3
<i>LSP 2</i>	Local Set Point 2 Value	<i>d i 4</i>	Digital Input 4
<i>LSP 3</i>	Local Set Point 3 Value	<i>do 1</i>	Analog Output 1
<i>LSP 4</i>	Local Set Point 4 Value	<i>do 2</i>	Analog Output 2
<i>CSPt</i>	Control Set Point Value	<i>do 1</i>	Digital Output 1
<i>RSPt</i>	Remote Set Point Value	<i>do 2</i>	Digital Output 2
<i>PID, O/P</i>	Output of the PID Algorithm	<i>.PU</i>	Master Process Variable
<i>OP 1</i>	Controller Output 1 (heat)	<i>.LSPt</i>	Master Control Set Point
<i>OP 2</i>	Controller Output 2 (cool)	<i>.OP</i>	Master PID Output
<i>I/P 1</i>	Analog Input 1	<i>SSPt</i>	Slave Set Point
<i>I/P 2</i>	Analog Input 2	<i>SPU</i>	Slave Process Variable
<i>I/P 3</i>	Analog Input 3	<i>WU</i>	Wild Variable
		<i>DU</i>	Disturbance Variable

**Table 1.1 Glossary of Abbreviations**



### 2.1 Introduction

The Operator level (Level 1) is the normal day-to-day mode of the C500. This section describes the operator facilities available on each frame depending on the control template and output type selected.

The template types detailed in this section are:

- Single loop controller
- Auto/Manual station
- Analog backup station
- Indicator/manual loader station
- Single loop with feedforward control
- Cascade control
- Cascade with feedforward
- Ratio controller
- Ratio station

---

**Note.** Only the frames relevant to the selected template are displayed – see Section 4.

---

In addition, frames used to view the Control Efficiency Monitor and operate motorized valve and heat/cool output types are also described.




Fig. 2.1 Power-up Displays



### 2.2 Single Loop Controller (Templates 1 and 2)

The single loop controller is a basic feedback control system using three-term PID or on/off control with either a local set point (template 1) or remote set point (template 2).







Fig. 2.2 Single Loop Controller





### ...2.2 Single Loop Controller (Templates 1 and 2)



Return to top of page

- 1 With the Ramping Set Point function enabled (see Section 3.3, Set Points/ Ramp Rate), the bargraph shows the actual (ramping) set point value and the digital display shows the target set point value.
- 2 Displayed only if template 2 selected and Ratio Display is enabled – see Section 4.2, Basic Configuration and Section 4.7, Operator Configuration.
- 3 Displayed only if template 2 selected and Bias Display is enabled – see Section 4.2, Basic Configuration and Section 4.7, Operator Configuration.




### 2.3 Auto/Manual Station (Templates 3 and 4)

**Note.** Refer also to Appendix A2.1 – Series and Parallel Operation.


The auto/manual station provides a backup for a master controller. In normal operation the C500's analog output follows the master controller's output value. A fault in the master system can be identified either by detecting a low signal on the master output (template 3) or via a digital signal (template 4). When a fault is detected the C500 goes into manual mode with its output either set to the last valid master output value or to a configured output value – see Section 4.6, Control Configuration/ Configured Output 1. When the master output is restored or the digital input returns to its inactive state, the C500 switches back to auto mode.

**Note.** The Alarm A1 Trip value must be set when using template 3.





### ...2.3 Auto/Manual Station (Templates 3 and 4)



- 1 In template 4 the Auto/Manual switch is overridden by the digital input signal.
- 2 Template 3 only – see Section 4.2, Basic Configuration/ Template Application.
- 3 Template 4 only – see Section 4.2, Basic Configuration/ Template Application.




### 2.4 Analog Backup (Templates 5 and 6)

**Note.** Refer also to Appendix A2.1 – Series and Parallel Operation.


The analog backup station provides a backup for a master controller. In normal operation (remote control mode selected) the C500's current output follows the master controller's output value. A fault in the master system can be identified either by detecting a low signal on the master output (template 5) or via a digital signal (template 6). When a fault is detected the C500 switches into local control mode and the process is controlled by the PID output of the C500. The C500 PID algorithm tracks the master output value continuously in order to ensure bumpless transfer from remote to local mode operation. When the master output is restored or the digital input returns to its inactive state, the C500 switches back to remote control mode.

**Note.** The Alarm A1 Trip value must be set when using template 5.





...2.4 Analog Backup (Templates 5 and 6)




- 1 Template 5 only – see Section 4.2, Basic Configuration/ Template Application.
- 2 Template 6 only – see Section 4.2, Basic Configuration/ Template Application.



### 2.5 Indicator/Manual Loader Station (Templates 7 and 8)

One or two process variables can be displayed on the digital and bargraph displays. If the control output is assigned to an analog output, the lower display indicates its value which can be adjusted by the user.





- 1 Displayed only if template 8 selected – see Section 4.2, Basic Configuration/Template Application.
- 2 Displayed only if control output type is 'analog' (output is assigned to Analog Output 1).



**2.6 Single Loop with Feedforward (Templates 9 and 10)**


These templates provide three-term PID control with feedforward. The disturbance variable is weighted by the feedforward gain ( $FFG_n$ ) and the feedforward bias ( $FFb5$ ) values and added to the controller output value.



- 1 With the Ramping Set Point function enabled (see Section 3.3, Set Points/ Ramp Rate), the bargraph shows the actual (ramping) set point value and the digital display shows the target set point value.



...2.6 Single Loop with Feedforward (Templates 9 and 10)



•1 Displayed only if template 10 selected – see Section 4.2, Basic Configuration/Template Application and Section 4.7, Operator Configuration/Operator Ratio Display and Operator Bias Display.





### 2.7 Cascade Control (Templates 11 and 12)

For cascade control, two internally-linked PID controllers are used, with the first (master) PID controller providing the set point for the second (slave) controller. The master output is weighted using the cascade ratio ( $C_r \cdot \epsilon \theta$ ) and bias ( $C_b \cdot IR$ ) values to create the slave set point value.








Fig. 2.6 Cascade Controller



•1 With the Ramping Set Point function enabled (see Section 3.3, Set Points/ Ramp Rate), the bargraph shows the actual (ramping) set point value and the digital display shows the target set point value.



...2.7 Cascade Control (Templates 11 and 12)




Continued...

- 1 Displayed only if template 12 selected and ratio/bias display enabled – see Section 4.2, Basic Configuration and Section 4.7, Operator Configuration.
- 2 Displayed only if ratio/bias display enabled – see Section 4.7, Operator Configuration.



### ...2.7 Cascade Control (Templates 11 and 12)





- 1 Displayed only if ratio/bias display enabled – see Section 4.7, Operator Configuration.



### 2.8 Cascade with Feedforward (Template 13)


For cascade control, two internally-linked PID controllers are used, with the first (master) PID controller providing the set point for the second (slave) controller. The feedforward disturbance variable signal is added to the master output (slave set point). The disturbance signal is weighted by the feedforward gain ( $FFG_n$ ) and the feedforward bias ( $FFb_s$ ) values.



•1 With the Ramping Set Point function enabled (see Section 3.3, Set Points/ Ramp Rate), the bargraph shows the actual (ramping) set point value and the digital display shows the target set point value.




...2.8 Cascade with Feedforward (Template 13)



**Feedforward Disturbance Variable**


**Note.** To disable feedforward action (e.g. during system tuning), set the Feedforward Gain parameter to *OFF* – see Section 3.2, Tune.

[0 to 100%]  
Feedforward disturbance variable input.



**Cascade Slave Set Point Ratio**

[0.001 to 9.999]  
Slave set point (CSP2) value =  
(ratio x master output) + bias [in engineering units]



**Cascade Slave Set Point Bias**

[In engineering units]



Return to **Master Process Variable (L PV)** display.

•1 Displayed only if enabled in Level B, Operator Configuration – see Section 4.7.



### 2.9 Ratio Controller (Templates 14 and 15)

Ratio control enables a controlled process variable to be maintained automatically in definite proportion to another variable known as the wild variable. The wild variable, weighted by ratio (*r R t D*) and bias (*b I R S*), values forms the control set point for the process variable.



•1 Displayed only if enabled in Level B, Operator Configuration – see Section 4.7.



**2.10 Ratio Station (Templates 16 and 17)**

The ratio station provides a set point for a subsequent slave controller. The wild variable (WV) is weighted by ratio ( $rRt0$ ) and bias ( $bIR5$ ) values and is then retransmitted as an analog output value.





Fig. 2.9 Ratio Station



•1 Displayed only if enabled in Level B, Operator Configuration – see Section 4.7.



### 2.11 Heat/Cool Output Types

#### 2.11.1 Reverse (Heat)/Direct (Cool) or Direct (Heat)/Reverse (Cool)

The active output, either OP1 (Heat) or OP2 (Cool) is displayed and may be adjusted in manual mode. The OP1 and OP2 l.e.d.s indicate which output is changing.





Fig. 2.10 Typical Response – Reverse/Direct or Direct/Reverse Control Action









**2.11.2 Reverse (Heat)/Reverse (Cool) or Direct (Heat)/Direct (Cool)**

It is not possible to view or adjust the heat/cool outputs directly. The PID output (0 to 100%), used to calculate the heat (OP1) and cool (OP2) outputs, is displayed and may be adjusted in manual mode. The OP1 and OP2 I.e.d.s indicate which output is changing.



**2.12 Motorized Valve Output Types**

**2.12.1 Motorized Valve with Feedback**




**Valve Position Display**

[0 to 100% of travel]

**Note.** In manual mode, the and keys can be used to drive the valve open and valve close relays directly.

**2.12.2 Motorized Valve without Feedback (Boundless)**



**Valve State Display**

*OPN*      Valve opening  
*STP*      Valve stopped  
*CLS*      Valve closing

**Note.** In manual mode, the and keys can be used to drive the valve open and valve close relays directly.



### 2.13 Auto-tune


#### Notes.

- Auto-tune is not available for Auto/Manual Station, Indicator or Ratio Station templates, or when boundless or heat/cool control types are selected.
- Auto-tune optimizes process control by manipulating the C500 output and then monitoring the process response.
- At the end of an auto-tune, the control parameters are updated automatically.
- Before starting auto-tune, the process variable must be stable.
- The C500 monitors the noise level of the process variable for 30 seconds and if it is greater than 2% of the engineering range the auto-tune is aborted.
- The C500 selects either 'start-up' or 'at set point' tuning automatically, depending upon the level of the process variable relative to the control set point.

#### 2.13.1 Start-up Auto-tune

If the process variable is more than  $\pm 10\%$  from the set point, 'start-up' tuning is carried out.

- 'Start-up' tuning – steps the output to drive the process towards the set point. The process response to this step change is monitored and PID parameters are calculated.
- The output step applied = % deviation from the set point  $\times 1.5$ .
- If no errors exist, the C500 enters auto mode and begins to control the process using the new PID parameters.
- If an error occurs during the auto-tune, the C500 reverts to manual mode with the control output set to the default output value. An error message is displayed in the operator level – see Table 2.1.



Error	Description	Error	Description
1	PV failed during auto-tune	7	A resultant P, I or D value was calculated out of range
2	Auto-tune has timed out during an auto-tune step	8	PV limit exceeded ('Start up' auto-tune)
3	Process too noisy to auto-tune	9	Controller put into configuration mode
4	Process too fast to auto-tune	10	Auto-tune terminated by user
5	Process too slow to auto-tune (max 12 hours between half-cycles).	11	PV is changing in the wrong direction during step test
6	PV deviated from set point by >25% eng. span during frequency response test		


Table 2.1 Auto-tune Error Codes



### 2.13.2 'At Set Point' Auto-tune

If the process variable is within 10% of the set point, 'at set point' tuning is carried out.

- 'At set point' tuning – manipulates the control output to produce a controlled oscillation of the process.
- A step change of  $\pm 10\%$  of the starting output value is applied initially. This is adjusted to give an amplitude of oscillation 3 times the noise level.
- Once the amplitude and period of oscillation are consistent (minimum 2 cycles, maximum 4 cycles) PID parameters are calculated.
- If no errors exist the controller enters auto mode and begins to control the process using the new PID parameters.
- If an error occurs during the auto-tune, the controller reverts to manual mode with the control output set to the default output value. An error message is displayed in the operator level – see Table 2.1.



**Note.** The time taken to complete auto-tune depends upon the system response time.

#### Notes For Special Cases.


**Cascade Control** – the slave loop must be tuned before the master loop. The slave must be placed into local set point mode (cascade disabled) and the slave set point adjusted to the required value prior to tuning.

**Feedforward Control** – during an auto-tune with a controller with feedforward the feedforward signal is not applied. The feedforward gain and bias values are not changed by the auto-tune and must be adjusted separately.

**Time Proportioning** – the cycle time must be set prior to running an auto-tune. The cycle time is not changed by the auto-tune.



2.13.3 Auto-tune



Accessing the Auto-tune Facility

From any operating frame, press and hold the key until the 'COdE' frame is displayed.

Set the correct auto-tune password.

Auto-tune Enable

Select the type of auto-tune required.

Single Loop Templates

- OFF – Off
- A – Type A
- b – Type B

Cascade Templates

- SLU.A – Slave type A
- SLU.b – Slave type B
- SL.A – Master type A
- SL.b – Master type B

Auto-tune is started automatically when the key is pressed.

Auto-tune can be stopped at any time by pressing the key.

**Note. Slave control loops only** – place the slave into local set point mode and adjust the set point to the required value prior to autotuning.

**Note. P + I control only** – set the derivative term to 'OFF' in the Tuning Level – see Section 3.2.

Return to the Operating Level.




Fig. 2.13 Autotune Types



## 2.14 Control Efficiency Monitor

**Note.** With cascade control, the Control Efficiency Monitor is applicable only to the master controller.

The Control Efficiency Monitor can be used either to compare the relative performance with different tuning parameters, or when fine tuning the PID settings, to give optimum control.

When the set point is changed, auto mode is selected or following a power failure, input failure or a large load disturbance, the control monitor performs a series of measurements to indicate the effectiveness of the current control parameters.

General guidelines are shown in Table 2.2.







Parameter	Ideal Setting	Actual Setting	Effect on Response	Action
Rate of Approach	Fast	Too slow		<ul style="list-style-type: none"> <li>• Decrease proportional band</li> <li>• Decrease integral time</li> <li>• Increase derivative time</li> </ul>
Overshoot	Small	Too large		<ul style="list-style-type: none"> <li>• Increase proportional band</li> <li>• Increase derivative time</li> </ul>
Decay Ratio	Small	Too large (Oscillatory)		<ul style="list-style-type: none"> <li>• Increase proportional band</li> <li>• Increase integral time</li> </ul>
Settling Time	Short	Too long		<ul style="list-style-type: none"> <li>• Increase proportional band</li> <li>• Decrease integral time</li> </ul>
Error Integral	Small	Too large	 	<p>If large overshoot and oscillatory then:</p> <ul style="list-style-type: none"> <li>• Increase proportional band</li> <li>• Increase integral time</li> <li>• Increase derivative time</li> </ul> <p>If slow approach and overdamped then:</p> <ul style="list-style-type: none"> <li>• Decrease proportional band</li> <li>• Decrease integral time</li> </ul>

Table 2.2 Control Efficiency Monitor Settings



...2.14 Control Efficiency Monitor




Fig. 2.14 Control Efficiency Monitor Parameters

2.14.1 Manual Tuning

The Control Efficiency Monitor may be used for manually tuning the PID parameters. The following method describes how to tune the controller for 1/4 wave damping:

- a) Set the integral and derivative action times to OFF.
- b) Set the proportional band (PB) to a low setting.
- c) Apply a small set point change.
- d) Use the Control Efficiency Monitor to note the decay ratio.
- e) If the decay ratio > 0.25, increase the Proportional Band until decay ratio = 0.25  
If the decay ratio < 0.25, decrease the Proportional Band until decay ratio = 0.25
- f) Leave the proportional band at the setting which gives 0.25 decay ratio and, using the Control Efficiency Monitor, note the period between peaks.
- g) Calculate and set the following parameters:  
Integral action time = Period/1.5  
Derivative action time = Period/6


---



**Note.** The manual tuning facility must not be used with boundless motorized valve control, as an Integral Action Time is required for these applications.

---



## 2.14.2 Using the Control Efficiency Monitor



Press and hold the lower  and  keys for 2 seconds.

**Note.**

If the front panel keys are not operated for 60 seconds whilst any Control Efficiency Monitor frame is being displayed, the instrument reverts to the first operating frame.

**Rate of Approach to Set Point**

The rate of change of the process variable between 5 and 95% of the step change ( $Y_2$ ), measured in engineering units per minute.

$$\text{Rate of approach} = \frac{Y_1}{t_{\text{approach}}}$$

**Overshoot**

The maximum error, expressed as a percentage of the set point.

$$\text{Overshoot} = \frac{X_1}{\text{Set Point}} \times 100$$

**Decay Ratio**

The ratio of the amplitude of the first and second overshoots.

$$\text{Ratio} = \frac{X_2}{X_1}$$

**Period**

The time (in seconds) between the first two peaks ( $t_{\text{period}}$ ).

**Settling Time**

The time taken (in minutes) for the process variable to settle within  $\pm 2\%$  of the set point value ( $t_{\text{settle}}$ ).

**Error Integral**

The integral of the error value until the process variable settles to within  $\pm 2\%$  of the set point value in 'engineering-unit hours'.

$$\text{Error integral} = \int_0^{t_{\text{settle}}} |PV - SP| dt$$



Return to the first operating frame.



## 3 SET UP MODE

### 3.1 Introduction

To access the Set Up mode (Levels 2 to 5) the correct password must be entered in the security code frame.





## 3.2 Level 2 – Tune

2.00...2.04

**Note.** Level 2 is not applicable if an Auto/Manual Station, Indicator or Ratio Station template is selected.

2.00

LEU.2  
TUNE

## Level 2 – Tune

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.

2.01

CYC.1 \*1  
1.0

## Cycle Time Output 1

[1.0 to 300.0 seconds for time proportioning or 'OnOF' for on/off control]

**Note.** On/off Control is not available on output 1 with heat/cool control or with cascade templates.

2.02

CYC.2 \*1  
\*2  
1.0

## Cycle Time Output 2 (Cool)

[1.0 to 300.0 seconds for time proportioning or 'OnOF' for on/off control]



**Note.** On/off Control is not available on output 2 with cascade templates.

2.03

HYS.1 \*3  
0

## Output 1 On/Off Hysteresis Value

[In engineering units]




2.04

HYS.2 \*4  
0


## Output 2 On/Off Hysteresis Value

[0% to (Y.15E – Y2.5E)%] – see parameters 2.22 and 2.23



Continued on next page

- 1 Displayed only if Relay or Digital output type is selected – see Section 4.2, Basic Configuration/ Output Type.
- 2 Displayed only if Heat/Cool output type is selected.
- 3 Only if On/Off control is selected – see parameters 2.01 and 2.02 above.
- 4 Displayed only if Heat/Cool output type is select and the 'CYC.2' parameter is set to 'OnOF'.



- 1 Heat/cool outputs use a common proportional band. The default is 'Pb - 1'.
- 2 Displayed only if a cascade template or a tune parameter source is selected – see Section 4.2, Basic Configuration/ Template Application and Section 4.6, Control Configuration/ Tune Parameter Source.
- 3 Displayed only if a tune parameter source is selected – see section 4.6, Control Configuration/ Tune Parameter Source.

## ...3.2 Level 2 – Tune

2.14...2.19

2.14

**Derivative Action Time 2**

[0.1 to 999.9 seconds or 'OFF']

The derivative action time for the slave controller if a cascade template is selected – see Section 4.2, Control Configuration/ Template Application.

2.15

**Approach Band 1**

[0.1 to 3.0 proportional bands]

This parameter limits when derivative action time 1 is applied. When the process variable is outside the approach band, derivative action is not applied.

2.16

**Approach Band 2**

[0.1 to 3.0 proportional bands]

This parameter limits when derivative action time 2 is applied to the slave control loop when a cascade template is selected.

2.17

**Manual Reset Value 1**

The value applied to bring the master control output to the zero error point under normal load conditions (integral action disabled) or the offset applied to the control output (integral action enabled).

[0.0 to 100%]

**Note.** Manual reset is applied whether or not an integral action time is set.

2.18

**Manual Reset Value 2**

As **Manual Reset Value 1**, but applied to the slave output.

[0.0 to 100%]

**Note.** Manual reset is applied whether or not an integral action time is set.

2.19

**Feedforward Gain**


The feedforward value applied to the control output is: (disturbance variable x feedforward gain) + bias. When set to OFF, feedforward action is disabled.

[0.1 to 999.9 or OFF]

**Note.** The feedforward value is normally added to the PID output. Using the PC Configurator, the value can also be multiplied by the PID output.

→ Continued on next page.

- 1 Displayed only if a cascade template is selected – see Section 4.2, Basic Configuration/ Template Application.
- 2 Not displayed if the associated derivative action time is set to OFF.
- 3 If manual control is selected and no integral action time is set, the manual reset value is calculated automatically to give bumpless transfer into auto control.
- 4 Displayed only if a feedforward template is selected – see Section 4.2, Basic Configuration/ Template Application.




**Feedforward Bias**

[-100.0% to 100.0%]


**Control Deadband**

When the process variable is in the deadband, changes to the control output due to proportional and integral action are suppressed. When a cascade template is selected, the control deadband is applied to the master output only.



**Heat/Cool Output 1 Start**

This parameter defines the PID output value above which Output 1 (heat) becomes active.



**Heat/Cool Output 2 Start**

This parameter defines the PID output value below which Output 2 (cool) becomes active.

[0.0 to  $y_{1st}$  %] – see Heat/Cool Output 1


Return to top of page

- 1 Displayed only if a feedforward template is selected – see Section 4.2, Basic Configuration/ Template Application. Not applied to Control Output when Feedforward Gain (frame 2.19) is set to 'OFF'.
- 2 Displayed only if a Heat/Cool output type is selected – see Section 4.2, Basic Configuration/ Output Type.


## 3.3 Level 3 – Set Points

3.00...3.07

**Note.** Level 3 is not applicable if Auto/Manual Station or Indicator templates are selected.



- 1 Not displayed for ratio controller or ratio station templates.
- 2 Displayed only if a local set point source is selected – see Section 4.5/ Set Point Configuration/ Local/Remote Set Point Source.
- 3 Displayed only if a cascade template is selected.
- 4 Displayed only for templates with a remote set point.



**Cascade Set Point Ratio**

In automatic mode, the slave set point value is:  
(ratio x master output) + bias.

[0.001 to 9.999]


**Cascade Set Point Bias**

[In engineering units]

**Ramp Rate**

[1 to 9999 engineering units per hour, or OFF]

The Ramping Set Point facility can be used to prevent a large disturbance to the control output when the set point value is changed. The rate set applies to both the local and the remote set points.



\* e.g. Ramp Rate = 200 Increments/Hour

Return to top of page.


•1 Displayed only if a Cascade template is selected – see Section 4.2, Basic Configuration/ Template Application.



3.4 Level 4 – Alarm Trip Points

4.00...4.08

**Note.** Level 4 is not applicable if all alarm types are set to 'None' – see Section 4.4, Alarms/ Alarm Type.



Level 4 – Alarm Trip Points

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.

Alarm 1 Trip

Alarm Number and Type

Display	Description	Display	Description
<i>NONE</i>	None	<i>LP3</i>	Low Process I/P3
<i>HPU</i>	High Process, PV	<i>HO</i>	High Output •2
<i>LPU</i>	Low Process, PV	<i>LO</i>	Low Output •2
<i>HLP</i>	High Latch, PV	<i>Hb1</i>	Maths Block 1 High
<i>LLP</i>	Low Latch, PV	<i>Lb1</i>	Maths Block 1 Low
<i>Hd</i>	High Deviation	<i>Hb2</i>	Maths Block 2 High
<i>Ld</i>	Low Deviation	<i>Lb2</i>	Maths Block 2 Low
<i>HP1</i>	High Process I/P1	<i>Hb3</i>	Maths Block 3 High
<i>LP1</i>	Low Process I/P1	<i>Lb3</i>	Maths Block 3 Low
<i>HP2</i>	High Process I/P2	<i>Hb4</i>	Maths Block 4 High
<i>LP2</i>	Low Process I/P2	<i>Lb4</i>	Maths Block 4 Low
<i>HP3</i>	High Process I/P3		

Trip Value

[In engineering units]

**Note.** When an auto/manual station template or analog backup template is selected, Alarm 1 is set automatically as a low process alarm on Analog Input 2.

Alarm 2 to Alarm 8 Trip

Alarm Number and Type

See Alarm 1.

Trip Value

[In engineering units]

Return to top of page.

- 1 Not displayed if alarm type set to 'None' – see Section 4.4, Alarms/ Alarm Type.
- 2 Applies to PID output with single or heat/cool outputs.

### 3.5 Level 5 – Valve Setup

5.00...5.04

**Note.** Level 5 is applicable only for a motorized valve output type – see Section 4.2, Basic Configuration/ Output Type.





Fig. 3.3 Motorized Valve Output with Feedback – Schematic

#### 3.5.1 Valve Setup (Feedback Types)



#### Level 5 – Valve Setup

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.

#### Motorized Valve Ratio and Bias

Desired valve position = (Ratio x PID output) + Bias

#### Motorized Valve Ratio

[0.01 to 10.00]


#### Motorized Valve Bias

[-100.0 to 100.0%]

#### Motorized Valve Deadband

[0.0 to 100% of the position feedback span]

Position %



**Example** If the valve is set to be driven to the 50% open position and the deadband is set to 4%, the motor stops driving when the position feedback is 48%. The deadband is between 48% and 52%.

#### Regulator Travel Time

The time entered is compared with the actual travel time. If the valve is sticking an error message is generated.

[0 to 5000 seconds, 0 = no check]

Return to top of page.



### 3.5.2 Valve Setup (Boundless Types) – Fig. 3.4

A 'boundless' process controller provides an output that is effectively the time derivative of the required regulator position, i.e. the C500 signals the regulator, not where to go to (position derivative), but in which direction to travel and how far to move, by a series of integral action pulses. Thus, the C500 does not need to know the absolute regulator position and is unaffected when regulator reaches the upper or lower limit, as determined by the regulator's limit switches (giving rise to the term 'boundless').

When a deviation from set point is introduced the regulator is driven, for a length of time equivalent to the proportional step. The regulator is then driven by integral action pulses until the deviation is within the deadband setting.




Fig. 3.4 Boundless Control Action

#### Calculation for Control Pulses (Boundless Control)

The following calculations are shown for guidance when setting deadband, proportional and integral values. They can be used to check the suitability of boundless control for a particular actuator/application.

Minimum 'ON' time of integral action pulses (for a fixed control deviation).

$$= \frac{\text{Travel Time} \times \text{Deadband } \%}{\% \text{ Proportional Band}} \quad (\text{in seconds})$$

Minimum (approximate) time between integral action pulses (for a fixed control deviation)

$$= \frac{\text{Integral Action Time} \times \text{Deadband } \%}{2 \times \% \text{ Control Deviation}} \quad (\text{in seconds})$$

Duration of the proportional step

$$= 2 \times \left[ \frac{\% \text{ Control Deviation}}{\% \text{ Proportional Band}} \right] \times \text{Travel Time in Seconds}$$

% Control Deviation

$$= \frac{\text{Set Point} - \text{Process Variable}}{\text{Eng Hi} - \text{Eng Lo}} \times 100\%$$

% Deadband

$$= \frac{\text{Deadband (eng units)}}{\text{Eng Hi} - \text{Eng Lo}} \times 100\%$$




...3.5.2 Valve Setup – Boundless

5.00...5.04

5.00 LEUS  
ULUE



Level 5 – Valve Setup

**Note.** To select this frame from anywhere in this page, press and hold the  key for a few seconds.


5.03 d.bnd  
0



Boundless Deadband

[In engineering units]

Position %



5.04 r.t.r.U.  
0



Regulator Travel Time

The time taken for the regulator to travel from the fully open to the fully closed position.

[1 to 5000 seconds]

LEUS  
ULUE

Return to top of page.

# 4 CONFIGURATION MODE



## 4.1 Introduction

To access the Configuration mode (Levels 6 to E) the correct password must be entered in the security code frame.





Fig. 4.1 Configuration Mode – Summary



## 4.2 Level 6 – Basic Configuration

6.00...6.01



## Level 6 – Basic Configuration

**Note.** To select this frame from anywhere in this page, press the  key for a few seconds.

## Template Application

Templates are provided to make the basic configuration for a particular application as simple as possible. The appropriate template should be selected before any other parameters are configured. When a template is selected, the C500 assumes the preset form for that template (see Appendix A). The inputs and software blocks are automatically soft-wired to perform the selected function.

Select the Template required

Display	Template Description
0 1SL	Single loop with local set point only
02SL	Single loop with remote set point
03R_	Auto/Manual station with low signal selection
04R_	Auto/Manual station with digital selection
05Rb	Analog backup with low signal selection
06Rb	Analog backup with digital selection
07.1I	Single indicator/manual loader
08.1I	Double indicator/manual loader
09FF	Single loop with feedforward with local set point only
10FF	Single loop with feedforward with remote set point
11.CC	Cascade with local set point only
12.CC	Cascade with remote set point
13.CF	Cascade with feedforward with local set point only
14.rC	Ratio controller
15.rC	Ratio controller with external ratio
16.rS	Ratio station
17.rS	Ratio station with external ratio

**Note 1.** When a template is selected, the following default values apply: The 'Analog Input Type' of all inputs used by the template defaults to '2', i.e. 4 to 20mA; The engineering ranges of all inputs used default to '0.0 to 100.0'. All other inputs are set to 'OFF'.

**Note 2.** Templates customized using the PC Configurator are identified by the letter 'U' in the template code – i.e. template '01.SL' becomes '01.U'.


Continued...

•1 Available only with option board fitted.



## ...4.2 Level 6 – Basic Configuration

5.02

**Control Output Type**

The appropriate relays, digital outputs and analog outputs are assigned to the control output variables. The other hardware outputs are provisionally assigned to alarm and retransmission functions but these may be changed in the output assignment level – see Section 4.8.

Select the Output Type required – see also Fig. 4.2 overleaf and Rear Fold-out/ Table B.

Display	Output Type	
<i>nOnE</i>	None	
<i>RnLG</i>	Analog output (Control output = ao1)	
<i>rLY</i>	Relay output (Control output = RLY1)	
<i>dIG</i>	Digital output (Control output = do1)	
<i>PFb</i>	Motorized valve with feedback (Open = RLY1, Close = RLY2)	•2 •3
<i>bPd</i>	Motorized valve without feedback (Open = RLY1, Close = RLY2)	•4
<i>HCrr</i>	Heat/cool with OP1 = relay, OP2 = relay	
<i>HCrd</i>	Heat/cool with OP1 = relay, OP2 = digital output	
<i>HCdr</i>	Heat/cool with OP1 = digital output, OP2 = relay	
<i>HCdd</i>	Heat/cool with OP1 = digital output, OP2 = digital output	•2
<i>HCrr</i>	Heat/cool with OP1 = analog, OP2 = relay	
<i>HCrd</i>	Heat/cool with OP1 = analog, OP2 = digital	•2
<i>HCRR</i>	Heat/cool with OP1 = analog, OP2 = analog	•2

Continued...


- 1 Only output types '*nOnE*' and '*RnLG*' are applicable to indicator templates. Only output type '*RnLG*' is applicable to auto/manual station, analog backup and ratio station templates.
- 2 Available only with option board fitted.
- 3 Analog Input 3 Type defaults to '11' – Resistance Feedback. This output type is not available with templates 10, 12, 13 and 15.
- 4 Output type '*bPd*' (Motorized valve without feedback) is not available with templates 9, 10 and 13.



...4.2 Level 6 – Basic Configuration

Output Types:


- RNLG**
- rLY**
- dIG**



A – Single Output

Output Type:


- PFb**



B – Motorized Valve Output with Feedback

Output Type:

- bnd**




C – Motorized Valve Output without Feedback (Boundless)

Output Types:

- HCrr**
- HCrd**
- HCdr**
- HCdd**
- HCRR**
- HCrd**
- HCRR**

See Note

See Note



D – Heat/cool Output


**Note.** Available only if option board fitted.

Fig 4.2 Output Type Schematic Diagrams



## ...4.2 Level 6 – Basic Configuration

6.03...6.06



- 1 Not displayed for auto/manual, indicator, ratio station or cascade templates.
- 2 Displayed only if a Cascade template is selected.
- 3 Not displayed if Heat/Cool output types selected – see parameter 6.02.
- 4 Displayed only if Heat/Cool output types selected – see parameter 6.02.



4.3 Level 7 – Analog Inputs

7.00...7.03

7.00

LEU.1  
INPE



7.01

ETYP.1  
2



7.02

UNL.1 \*1  
C




7.03

dP.1  
0



Level 7 – Analog Inputs

**Note 1.** Refer also to Table A – Template Applications on the rear fold-out.

**Note 2.** To select this frame from anywhere in this page, press the  key for a few seconds.

Analog Input 1 (I/P1) Type & Electrical Range

Display	Description	Display	Description
OFF	Not Used	P	PT100 RTD
b	THC Type B	i	0 to 20mA
E	THC Type E	2	4 to 20mA
J	THC Type J	3	0 to 5V
K	THC Type K	4	1 to 5V
L	THC Type L	6	0 to 50mV
N	THC Type N	7	4 to 20mA square root linearizer
R	THC Type R	8	4 to 20mA power 3/2
S	THC Type S	9	4 to 20mA power 5/2
t	THC Type T	U	Custom

Temperature Units (I/P1)

- C – THC/PT100 readings displayed in °C
- F – THC/PT100 readings displayed in °F

Decimal Places (Engineering Range, I/P1)

- 0 XXXX
- 1 XXX.X
- 2 XX.XX
- 3 X.XXX

Continued...


\*1 Displayed only if THC or RTD input types are selected





... 4.3 Level 7 – Analog Inputs

7.04...7.07



**Engineering High (I/P1)**

[-999 to 9999]

**Note.** This parameter defaults to the maximum allowed value when THC or RTD inputs are selected – see Table 4.1.

THC/RTD Type	°C			°F		
	Min.	Max.	Min. Span	Min.	Max.	Min. Span
Type B	-18	1800	710	0	3272	1278
Type E	-100	900	45	-148	1652	81
Type J	-100	900	50	-148	1652	90
Type K	-100	1300	65	-148	2372	117
Type L	-100	900	50	-148	1652	90
Type N	-200	1300	90	-328	2372	162
Type R & S	-18	1700	320	0	3092	576
Type T	-250	300	60	-418	572	108
Pt100	-200	600	25	-328	1112	45

**Table 4.1 Engineering Limits, THC & RTD Inputs**

**Engineering Low (I/P1)**

[-999 to 9999]

**Note.** This parameter defaults to the minimum allowed value when THC or RTD inputs are selected – see Table 4.1.

**Broken Sensor Drive (I/P1)**

- none* – No action. Actual input values remain valid.
- UP* – Input driven to the maximum upscale value (999)
- dN* – Input driven to the minimum downscale value (-999)

In the event of a fault being detected on the input, the input is driven in the direction selected.

**Input Filter Time Constant (I/P1)**


The input values are averaged over the time set.

[0 to 60 seconds]

Continued...



7.08




Analog Input Type & Electrical Range (I/P2)

Note. THC inputs can only be used on I/P2 if I/P1 is also set to THC.

Display	Description	Display	Description
OFF	Not Used	t	THC Type 1
b	THC Type B	1	0 to 20mA
E	THC Type E	2	4 to 20mA
J	THC Type J	5	0 to 50mV
K	THC Type K	7	4 to 20mA square root linearizer
L	THC Type L	8	4 to 20mA power 3/2
n	THC Type N	9	4 to 20mA power 5/2
r	THC Type R	U	Custom
S	THC Type S		


7.09



Temperature Units (I/P2)

C - THC readings displayed in °C  
F - THC readings displayed in °F

7.10



Decimal Places (Engineering Range, I/P2)

0 XXXX  
1 XXX.X  
2 XX.XX  
3 X.XXX


7.11



Engineering High (I/P2)

[-999 to 9999]


7.12



Engineering Low (I/P2)

[-999 to 9999]


7.13



Broken Sensor Drive (I/P2)

none - No action. Actual input values remain valid.  
UP - Input driven to the maximum upscale value (999)  
dN - Input driven to the minimum downscale value (-999)

7.14



Filter Time Constant (I/P2)

The input values are averaged over the time set.

[0 to 60 seconds]


Continued...

- 1 Frames 7.09 to 7.14 are not displayed if Analog Input Type 2 is set to 'OFF'.
- 2 Displayed only if THC input type is selected.



... 4.3 Level 7 – Analog Inputs

7.1 5...7.21



Analog Input Type & Electrical Range (I/P3)

Display	Description	Display	Description
<i>OFF</i>	Not Used	<i>1</i>	0 to 20mA
<i>b</i>	THC Type B	<i>2</i>	4 to 20mA
<i>E</i>	THC Type E	<i>3</i>	0 to 5V
<i>J</i>	THC Type J	<i>4</i>	1 to 5V
<i>K</i>	THC Type K	<i>5</i>	0 to 50mV
<i>L</i>	THC Type L	<i>7</i>	4 to 20mA square root linearizer
<i>N</i>	THC Type N	<i>8</i>	4 to 20mA power 3/2
<i>r</i>	THC Type R	<i>9</i>	4 to 20mA power 5/2
<i>S</i>	THC Type S	<i>!!</i>	Resistance feedback for motorized valve
<i>t</i>	THC Type T	<i>U</i>	Custom
<i>P</i>	PT100 RTD		

Temperature Units

- C* – THC readings displayed in °C
- F* – THC readings displayed in °F

Decimal Places

- 0* XXXX
- 1* XXX.X
- 2* XX.XX
- 3* X.XXX

Engineering High

[–999 to 9999]

**Note.** This parameter defaults to the maximum allowed value when THC or RTD inputs are selected – see Table 4.1.

Engineering Low

[–999 to 9999]

**Note.** This parameter defaults to the minimum allowed value when THC or RTD inputs are selected – see Table 4.1.

Broken Sensor Drive (I/P3)

- NONE* – No action. Actual input values remain valid.
- UP* – Input driven to the maximum upscale value (999)
- dN* – Input driven to the minimum downscale value (–999)

Filter Time Constant (I/P3)

The input values are averaged over the time set.

[0 to 60 seconds]



Return to top of page.

- 1 Frames 7.16 to 7.21 are not displayed if Analog Input Type 3 is set to 'OFF'.
- 2 Displayed only if THC or RTD input types are selected.



### 4.4 Level 8 – Alarms



**Note.** Any type of alarm can be used to sound an annunciator (klaxon/horn) which is disabled when the alarm is acknowledged. This is achieved by assigning the relay to the acknowledge state of the alarm instead of the actual alarm state.



**Fig 4.4 High and Low Deviation Alarm Action**



## ...4.4 Level 8 – Alarms





8.00

LEU.8  
AL\_5



8.01

LYP.1  
HP.1



Level 8 – Alarms

**Note.** To select this frame from anywhere in this page, press the key for a few seconds.

Alarm 1 Type

See Figs 4.3 to 4.6

Display	Description	Display	Description
<i>NONE</i>	None	<i>LP3</i>	Low Process I/P3
<i>HPU</i>	High Process, PV	<i>HO</i>	High Output •1
<i>LPV</i>	Low Process, PV	<i>LO</i>	Low Output •1
<i>HLP</i>	High Latch, PV	<i>Hb1</i>	Maths Block 1 High
<i>LLP</i>	Low Latch, PV	<i>Lb1</i>	Maths Block 1 Low
<i>Hd</i>	High Deviation	<i>Hb2</i>	Maths Block 2 High
<i>Ld</i>	Low Deviation	<i>Lb2</i>	Maths Block 2 Low
<i>HP1</i>	High Process I/P1	<i>Hb3</i>	Maths Block 3 High
<i>LP1</i>	Low Process I/P1	<i>Lb3</i>	Maths Block 3 Low
<i>HP2</i>	High Process I/P2	<i>Hb4</i>	Maths Block 4 High
<i>LP2</i>	Low Process I/P2	<i>Lb4</i>	Maths Block 4 Low
<i>HP3</i>	High Process I/P3		

**Note.** Alarm 1 is set automatically as a Low Process alarm on I/P2 when template 3 or 5 is selected.

8.02

LP.1  
0



Alarm 1 Trip

Alarm Number

Trip Value

[In engineering units]



8.03

HYS.1  
0



Alarm 1 Hysteresis

Set the hysteresis value (in engineering units) for Alarm 1.

The alarm is activated at the trip level but is only deactivated when the process variable has moved into the safe region by an amount equal to the hysteresis value – see Figs. 4.4 to 4.6.

[In engineering units]



**Note.** Time hysteresis is set using the PC Configurator.


Continued...

•1 Applies to the PID output with single or heat/cool output types selected – see Section 3.4.



... 4.4 Level 8 – Alarms

8.04...8.25




•1 A digital input becomes active when a volt-free contact is closed or a low TTL signal is applied.



4.5 Level 9 – Set Point Configurationm

9.00...9.05

**Note.** Level 9 is not applicable when an Indicator template (templates 7 and 8) or an Auto/Manual station template (templates 3 and 4) is selected.



Level 9 – Set Point Configuration

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.

Set Point Tracking Enable

Display	Local Set Point Tracking	Remote Set Point Tracking	
OFF	OFF	OFF	
LOC	ON	OFF	•2
rE-	OFF	ON	•3
L-r	ON	ON	•3

**Local Set Point Tracking** – the local set point tracks the process variable when manual mode is selected. Applies to master and slave set points with cascade templates.

**Remote Set Point Tracking** – local set point tracks the remote set point when in remote set point mode. If the controller is put into manual mode the set point reverts from remote to local. Also applies to the local and remote ratio when the ratio controller template is selected.

Set Point Limits

The set point limits define the maximum and minimum values to which the local and/or remote set points can be adjusted. The set point limits do not apply when in Manual mode with local set point tracking enabled. If the set point is outside its limits when Automatic mode is selected, the set point value can only be adjusted towards its limits. Once within the limits they apply as normal.

**Control Set Point (CSPT) or Master Set Point (MSPT) High Limit**  
[-999 to 9999 in engineering units]

**Control Set Point (CSPT) or Master Set Point (MSPT) Low Limit**  
[-999 to 9999 in engineering units]

**Note.** Operator level adjustment of the set point can be disabled – see Section 4.7, Operator Configuration/ Set Point Adjustment Enable.

**High Limit for Slave Set Point**  
[In engineering units]

**Low Limit for Slave Set Point**  
[In engineering units]

Continued...

- 1 Displayed only if a Cascade template is selected.
- 2 Not available with ratio controller and ratio station templates.
- 3 Available only if a remote set point template is selected.





## ...4.5 Level 9 – Set Point Configuration

9.06...9.11

9.06

 SPFA  
 NONE

\*1

**Remote Set Point Fault Action**

The action required when a fault occurs with the remote set point.

NONE – No action

LOC – Select local set point mode

dFLT – Select local set point mode and set to the default value

9.07

 dFSP  
 0.0

\*1

**Local Set Point Default Value**

Set the value required for the local set point under remote set point fault conditions.

[In engineering units]

9.08

 LSP1  
 NONE
**Local Set Point Source 1**

The source required to select local set point 1 (LSP1) as the current local set point.


See Rear Fold-out/  
Table C – Digital Sources.

\*2

9.09

 LSP2  
 NONE
**Local Set Point Source 2**

The source required to select local set point 2 (LSP2) as the current local set point.

See Rear Fold-out/  
Table C – Digital Sources.

\*2

9.10

 LSP3  
 NONE
**Local Set Point Source 3**

The source required to select local set point 3 (LSP3) as the current local set point.

See Rear Fold-out/  
Table C – Digital Sources.

\*2

9.11

 LSP4  
 NONE
**Local Set Point Source 4**

The source required to select local set point 4 (LSP4) as the current local set point.

See Rear Fold-out/  
Table C – Digital Sources.

\*2

Continued...


- 1 Displayed only if a remote set point template is selected.
- 2 A digital input becomes active when a volt-free contact is closed or a low TTL signal is applied.




...4.5 Level 9 – Set Point Configuration

9.12...9.14


9.12




**Local/Remote Set Point (or Ratio) Selection Source**

The source required to lock into remote set point mode or remote ratio mode when the ratio controller template is selected. When the source is active the  key does not operate.

See Rear Fold-out/  
Table C – Digital Sources.




9.13




**Local Set Point (or Ratio) Selection Source**

The source required to select local set point mode or remote ratio mode when the ratio controller template is selected.

See Rear Fold-out/  
Table C – Digital Sources.



9.14



**Remote Set Point (or Ratio) Selection Source**

The source required to select remote set point mode or remote ratio mode when the ratio controller template is selected.

See Rear Fold-out/  
Table C – Digital Sources.



Return to top of page.


•1 Digital inputs are active when a volt-free contact is closed or a low TTL signal is applied.



## 4.6 Level A – Control Configuration

R.00...R.02

**Note.** Level A is not displayed if an indicator template is selected.



## Level A – Control Configuration

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.

## Power Fail Recovery Mode

Select the default power failure mode required following a power interruption or failure.

Display	Setting	Display	Setting
0	Last mode	5	Auto mode, integral term reset
1	Manual mode, using last output	6	Auto mode, using last integral term
2	Manual mode with 0.0% output	7	Power outage $\leq$ Recovery time: Auto mode. Power outage $>$ Recovery time: Manual mode, last output
3	Manual mode with 100.0% output	8	Power outage $\leq$ Recovery time: Auto mode. Power outage $>$ Recovery time: Manual mode, configured output
4	Manual mode with configured output		

## Recovery Time

If power is restored within the recovery time, the controller continues in the last mode when power fail recovery modes 7 or 8 are selected.

[0 to 9999 seconds]

Continued...

•1 Not displayed if power fail recovery modes 0 to 6 are selected.



...4.6 Level A – Control Configuration

R.03

PUFA  
NONE

**Process Variable Fail Action**

Determines controller output when the process variable input fails.

- NONE* No action
- HOLD* Put into Manual mode
- DFLT* Put into Manual mode and select default output

R.04

DFOP  
0

**Default Output**

This output is used in conjunction with Power Recovery mode 8 and Process Variable Fail action.

[0 to 100%] (-100% to +100% for heat/cool)

R.05

OPH1 •1  
100

**Output High Limit – Single Output Control**

Limits the high level of the control output in automatic mode. If the control output is above this limit when automatic mode is selected, the current output value becomes the high limit until the value falls below the limit set.

[0.0 to 100.0%]

R.06

OPLO •1  
0

**Output Low Limit – Single Output Control**

Limits the low level of the control output in automatic mode. If the control output is below this limit when automatic mode is selected, the current output value becomes the low limit until the value rises above the limit set.

[0.0 to 100.0%]

R.07

OP1H •2  
1000

**Output 1 (Heat) High Limit – Heat/Cool Control**

Limits the high level of control output 1 in automatic mode. If the control output is above this limit when automatic mode is selected, the current output value becomes the high limit until the value falls below the limit set.

[0.0 to 100.0%]


R.08

OP2H •2  
100

**Output 2 (Cool) High Limit – Heat/Cool Control**

Limits the high level of control output 2 in automatic mode, when either 'reverse-direct' or 'direct-reverse' control action is selected in the Basic Configuration level. If the control output is above this limit when automatic mode is selected, the current output value becomes the high limit until the value falls below the limit set.

[0.0 to -100.0%]



Continued...


- 1 Displayed only if a single output type is selected.
- 2 Displayed only if a heat/cool output type is selected.



...4.6 Level A – Control Configuration


R.09...R.12

R.09




**Output 2 (Cool) Low Limit – Heat/Cool Control**

Limits the low level of control output 2 in automatic mode, when 'reverse-reverse' or 'direct-direct' control action is selected in the Basic Configuration level. If the control output is below this limit when automatic mode is selected, the current output value becomes the low limit until the value rises above the limit set.



**Output Slew Rate**

The maximum rate of change of the control output (or both control outputs for heat/cool).



**Note.** The default slew rate setting is applied to both increasing and decreasing output values. The slew rate setting can be applied to either increasing values only or decreasing values only using the PC Configurator.

R.10




[0.01 to 99.99% change per second or 'OFF']

R.11




See Rear Fold-out/ Table C – Digital Sources.



R.12



See Rear Fold-out/ Table C – Digital Sources.



Continued...

- 1 Displayed only if reverse-reverse or direct-direct control actions are selected.
- 2 Digital inputs are active when a volt free contact is closed or a low TTL signal is applied.



...4.6 Level A – Control Configuration

R.13...R.17

R.13



**Configured Output 1**

The control output value required when manual is selected by manual mode source 1.

- ▲ [0 to 100% or LAST (non-heat/cool)]
- ▼ [-100 to 100% (heat/cool only)]

R.14



**Manual Mode Selection Source 2**

The digital source required to select manual mode and Configured Output 2.

- ▲ See Rear Fold-out/ Table C – Digital Sources.
- ▼

Manual with output = COP2 •1



R.15



**Configured Output 2**

The control output value required when manual is selected by manual mode source 2.

- ▲ [0 to 100% or LAST (non-heat/cool)]
- ▼ [-100 to 100% (heat/cool only)]

R.16



**Auto/Manual Selection Source**

Used with auto/manual station.

The source required to lock into manual mode with Configured Output 3. Switching from manual to auto is not possible via the front panel.

- ▲ See Rear Fold-out/ Table C – Digital Sources.
- ▼

Manual with output = COP3 •1



**Note.** If template 3 is selected, the source is assigned to alarm 1. If template 4 is selected, the source is assigned to digital input 1.

R.17



**Configured Output 3**

The control output value required when manual mode is selected by the auto/manual selection source.

- ▲ [0 to 100% or LAST (non-heat/cool)]
- ▼ [-100 to 100% (heat/cool only)]

Continued...


•1 Digital inputs are active when a volt free contact is closed or a low TTL signal is applied



...4.6 Level A – Control Configuration

R.18...R.22

R.18




**Auto Mode Selection Source**  
Select the digital source used to activate auto mode.

See Rear Fold-out/ Table C – Digital Sources.




•1

R.19




**Tune Parameter Source 1 (Gain Scheduling)**  
Determine the digital source used to select the proportional 1 and integral 1 terms as the tuning parameters.

See Rear Fold-out/ Table C – Digital Sources.




•1

R.20




**Tune Parameter Source 2 (Gain Scheduling)**  
Determine the digital source used to select the proportional 2 and integral 2 terms as the tuning parameters.

See Rear Fold-out/ Table C – Digital Sources.




•1

R.21




**Tune Parameter Source 3 (Gain Scheduling)**  
Determine the digital source used to select the proportional 3 and integral 3 terms as the tuning parameters..

See Rear Fold-out/ Table C – Digital Sources.




•1

R.22



**Tune Parameter Source 4 (Gain Scheduling)**  
Determine the digital source used to select the proportional 4 and integral 4 terms as the tuning parameters.

See Rear Fold-out/ Table C – Digital Sources.



•1



Return to top of page.

- 1 Digital inputs are active when a volt free contact is closed or a low TTL signal is applied.
- 2  $PB-x$  and  $IRt_x$  values are set in Level 2 – see Section 3.2, Tune/Proportional Band x and Integral Action Time x. This function is not available with Cascade control and it is not applicable to Auto/Manual Station, Indicator or Ratio Station templates.



4.7 Level B – Operator Configuration

b.00...b.06

Level B – Operator Configuration

Note. To select this frame from anywhere in this page, press and hold the  key for a few seconds.

Front Panel Auto/Manual Key Enable

YES – Enabled  
NO – Disabled

Front Panel Local/Remote Key Enable

Display	Local/Remote Key Action
NO	Local/Remote key disable.
Lr	Switches between local and remote set point modes.
2L	Selects local set point 1 or 2.
3L	Selects local set point 1, 2 or 3.
4L	Selects local set point 1, 2, 3 or 4.
•3 Lr.Lc	As above, but with switching between local and cascade when slave parameters are displayed
•3 2L.Lc	
•3 3L.Lc	
•3 4L.Lc	

Front Panel Alarm Acknowledge Key Enable

YES – Enabled  
NO – Disabled

Operator Level Set Point Adjustment Enable

YES – Enabled  
NO – Disabled

Note. Applies to master and slave set points in cascade mode.






Operator Ratio Display

YES – Ratio setting for Remote and Cascade set point displayed in operator level.  
NO – Ratio setting for Remote and Cascade set point not displayed in operator level.

Operator Bias Display

YES – Bias setting for Remote and Cascade set point displayed in operator level.  
NO – Bias setting for Remote and Cascade set point not displayed in operator level.

Continued...




- 1 Not displayed if the Indicator template is in use.
- 2 Displayed only if a template with remote set point or cascade control is selected.
- 3 Cascade templates only.





## ...4.7 Level B – Operator Configuration

b.07...b.13




•1 Not displayed on Indicator or Auto/manual station templates.



### 4.8 Level C – Output Assignment Configuration


C.00, C.01, C.07, C.08

**Note.** The Output Assignment default settings are preconfigured to each template – see Table B, Output Sources on the rear fold-out.



#### Level C – Output Assignment

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.




#### Analog/Digital Output 1 (ao1/do1) Type

Select the output type for Output 1.

- ANLG - Analog
- DIG - Digital


Press to advance to Analog Output 1 Assignment Source.

or



Press to advance to Digital Output 1 Assignment Source.


#### 4.8.1 Digital Output 1



#### Digital Output 1 (do1) Assignment Source

Select the source required to activate Digital Output 1

See Rear Fold-out/ Table C – Digital Sources.



#### Digital Output 1 (do1) Polarity

The output can be set to energize for either an active or inactive digital signal.


- POS - Output energized when source is active.
- NEG - Output energized when source is inactive.

Continued...

- 1 If the output is assigned to a control output by the control type, the setting displayed cannot be changed – see Section 4.2, Basic Configuration/ Control Output Type.
- 2 Not applicable if digital output 1 is assigned to a control output.



## 4.8.2 Analog Output 1




- 1 If the output is assigned to a control output by the control type, the setting displayed cannot be changed – see Section 4.2, Basic Configuration/ Control Output Type.
- 2 Not applicable if analog output 1 is assigned to a control output.



### 4.8.3 Output 2 Assignment

C09, C15, C16




**Analog/Digital Output 2 (ao2/do2) Type**  
Select the output type for Output 2.

- ANLG - Analog
- dIG - Digital

Press to advance to Analog Output 2 Assignment Source.

Press to advance to Digital Output 2 Assignment Source.

### 4.8.4 Digital Output 2



**Digital Output 2 (do2) Assignment Source**  
Select the source required to activate Digital Output 2

See Rear Fold-out/ Table C – Digital Sources.

**Digital Output 2 (do2) Polarity**  
The output can be set to energize for either an active or inactive digital signal.

- PBS - Output energized when source is active.
- NEG - Output energized when source is inactive.

Continued...

- 1 Displayed only if optional ouput is fitted. If the output is assigned to a control output by the control type, the setting displayed cannot be changed – see Section 4.2, Basic Configuration/ Control Output Type.
- 2 Not applicable if digital output 2 is assigned to a control output.



## 4.8.5 Analog Output 2

**C.10**

**AN2A** \*1  
**NONE**

**Analog Output 2 (ao2) Assignment Source**  
 Select the source required to activate Analog Output 2  
 See Rear Fold-out/ Table D – Analog Sources.

---

**C.11**

**AN2H** \*1  
**20.0**

**Analog Output 2 (ao2) Electrical High**  
 The maximum current output required for the retransmission range.  
 [0.0 to 20.0mA]

---

**C.12**

**AN2L** \*1  
**4.0**

**Analog Output 2 (ao2) Electrical Low**  
 The minimum current output required for the retransmission range.  
 [0.0 to 20.0mA]

---

**C.13**

**r2H** \*1  
**100.0** \*2

**Retransmission 2 Engineering High**  
 The engineering range value at which maximum output is required.  
 [In engineering units]

---

**C.14**

**r2L** \*1  
**0.0** \*2

**Retransmission 2 Engineering Low**  
 The engineering range value at which minimum output is required.  
 [In engineering units]

---


**rLY1**  
**NONE** → Continued...

- 1 Displayed only if optional output is fitted. If the output is assigned to a control output by the control type, the setting displayed cannot be changed – see Section 4.2, Basic Configuration/ Control Output Type.
- 2 Not applicable if analog output 2 is assigned to a control output.



4.8.6 Relay Outputs 1 to 4

C17...C22




- 1 If the output is assigned to a control output by the control type, the setting displayed cannot be changed – see Section 4.2, Basic Configuration/ Control Output Type.
- 2 Not displayed if relay is assigned to a control output signal.
- 3 Not applicable if relay is assigned to a control output.
- 4 Displayed only if optional relay output is fitted.



## ...4.8.6 Relay Outputs 1 to 4

C23...C24




- 1 If the output is assigned to a control output by the control type, the setting displayed cannot be changed – see Section 4.2, Basic Configuration/ Control Output Type.
- 2 Not displayed if relay is assigned to a control output signal.
- 3 Not applicable if relay is assigned to a control output.
- 4 Displayed only if relay output is fitted.



### 4.9 Level D – Serial Communications Configuration

d.00...d.03

**Note.** Level D is applicable only if the serial communications option is fitted.



#### Level D – Serial Communications Configuration

**Note.** To select this frame from anywhere in this page, press and hold the key for a few seconds.

#### Serial Configuration

- 0 – Off
- 1 – 2-wire connection, 2400 baud rate
- 2 – 4-wire connection, 2400 baud rate
- 3 – 2-wire connection, 9600 baud rate
- 4 – 4-wire connection, 9600 baud rate
- 5 – 2-wire connection, 19200 baud rate
- 6 – 4-wire connection, 19200 baud rate

#### Parity

- none* – None
- odd* – Odd
- even* – Even

#### Modbus™ Address

Each slave on a Modbus link must be assigned a unique address – see IM/C500-MOD.

[1 to 99]

Return to top of page.






## 4.10 Level E – Calibration


E.00...E.04

**Note.** This page enables fine tuning of the inputs to eliminate system errors.





...4.10 Level E – Calibration




- 1 Displayed only if option board is fitted.
- 2 Displayed only if Motorized Valve with feedback output type is selected – see Section 4.2, Basic Configuration.



## ...4.10 Level E – Calibration

E.11...E.16



- 1 Displayed only if Motorized Valve with feedback output type is selected – see Section 4.2, Basic Configuration.
- 2 Displayed only if corresponding input type is set to 'THC'.
- 3 Displayed only if option board is fitted.



## 5 INSTALLATION

### EC Directive 89/336/EEC

In order to meet the requirements of EC Directive 89/336/EEC for EMC regulations, this product must not be used in a non-industrial environment.

### End of Life Disposal




- The instrument contains a small lithium battery which should be removed and disposed of responsibly in accordance with local environmental regulations.
- The remainder of the instrument does not contain any substance that will cause undue harm to the environment and may therefore be considered as normal waste and disposed of accordingly.

### Cleaning


Clean only the front panel, using warm water and a mild detergent.

## 5.1 Mechanical Installation

### 5.1.1 Siting – Figs. 5.1 and 5.2




A – Within Temperature Limits



0 to 90% RH





B – Within Humidity Limits



IP66/  
NEMA4X  
(front panel)

IP20  
(rear)

C – Within Protection Rating Limits



**Note.** Select a location away from strong electrical and magnetic fields. If these cannot be avoided, particularly in applications where 'walkie talkies' are used, connect using screened cables within grounded metal conduit.

D – Use Screened Cables


Fig. 5.2 Environmental Requirements



### 5.1.2 Mounting – Figs. 5.3 to 5.5

The instrument is designed for panel mounting (Fig. 5.4). Overall dimensions are shown in Fig. 5.3.

**Note.** For NEMA4X protection, a minimum panel thickness of 2.5mm is recommended.





...5.1.2 Mounting – Figs. 5.3 to 5.5





Fig. 5.4 Mounting




## ...5.1.2 Mounting – Figs. 5.3 to 5.5



① Unclip the process label cover and remove the process label, if fitted.

② Loosen the captive screw securing the instrument to the case



③ Remove the instrument from the case

---


**Note.** Refitting is the reversal of removal.

---

Fig. 5.5 Inserting/Removing the Instrument from the Case



5.1.3 Process Labels – Fig. 5.6







## 5.2 Electrical Installation



### Warnings.

- The instrument is not fitted with a switch therefore a disconnecting device such as a switch or circuit breaker conforming to local safety standards must be fitted to the final installation. It must be fitted in close proximity to the instrument within easy reach of the operator and must be marked clearly as the disconnection device for the instrument.
- Remove all power from supply, relay and any powered control circuits and high common mode voltages before accessing or making any connections.
- Use cable appropriate for the load currents. The terminals accept cables up to 14AWG (2.5mm<sup>2</sup>).
- The instrument conforms to Mains Power Input Insulation Category II. All other inputs and outputs conform to Category II.
- All connections to secondary circuits must have basic insulation.
- After installation, there must be no access to live parts e.g. terminals.
- Terminals for external circuits are for use only with equipment with no accessible live parts.
- If the instrument is used in a manner not specified by the Company, the protection provided by the equipment may be impaired.
- All equipment connected to the instrument's terminals must comply with local safety standards (CEI/IEC 61010-1:2001-2).

---

### Notes.

- Always route signal leads and power cables separately, preferably in earthed (grounded) metal conduit.
- It is strongly recommended that screened cable is used for signal inputs and relay connections. Connect the screen to the earth (ground stud) – see Fig. 5.4.
- The battery is a 3V non-replaceable lithium cell.




This equipment is protected through double insulation (Class II).

---





5.2.1 Electrical Connections – Figs 5.7 to 5.9





...5.2.1 Electrical Connections – Figs. 5.7 to 5.9





### 5.3 Relays

**Note.** Refer to rear fold-out/ Table B – Output Sources for default relay assignments.

Relay contacts are rated at:

115/230V a.c. at 5A (non-inductive)  
250V d.c. 25W max.

### 5.4 Digital Output

15V d.c. min. at 20mA  
Min. load 750Ω

### 5.5 Control or Retransmission Analog Output

Max. load 15V (750Ω at 20mA).  
Isolated from analog input, dielectric strength 500V for 1 minute.

#### 5.3.1 Setting the Relay Links – Fig. 5.10

Set the links on the processor board and the option board (if fitted).




Fig. 5.10 Relay Links



### 5.6 Motorized Valve Connections – Fig. 5.11

**Note.** Relays used to drive the motorized valve must be set for 'Normally Open' operation – see Section 5.3.1.




Fig. 5.11 Motorized Valve Connections

### 5.7 Input Connections

Make connections to each input – see Fig 5.8.

**Refer to rear fold-out/ Table A – Template Applications for the default input assignment settings.**

#### 5.7.1 Thermocouple (THC) Inputs

**Note.** Use the correct compensating cable between the THC and the terminals – see Table 5.1.

Automatic Cold Junction Compensation (ACJC) is incorporated by use of CJ sensors wired across the input terminals of I/P1 and I/P3 – see Fig. 5.12.

Alternatively, the CJ sensor can be mounted remotely at the point where the thermocouple cable terminates into copper panel – see Fig. 5.13.

It is possible to use an external fixed cold (reference) junction, if the instrument is programmed for use with millivolt inputs and the appropriate thermocouple linearizer is selected. This is only possible via the PC configurator.




Fig. 5.12 CJ Sensor – Connections




Fig. 5.13 Remote-mounted CJ Sensor –



### 5.7.2 3-lead Resistance Thermometer (RTD) Inputs

The three leads must have equal resistance, not exceeding 50Ω each.

### 5.7.3 2-lead Resistance Thermometer (RTD) Inputs

If long leads are necessary it is preferable to use a 3-lead RTD. If the RTD is to be used in a hazardous area, a 3-lead RTD connected via a suitable Zener barrier, must be used.

### 5.8 Output Connections

Make connections as shown in Fig 5.7.

**Refer to rear fold-out/ Table B – Output Sources for the default output assignment settings.**

### 5.9 Power Supply Connections



#### Warning.

- A fuse (315mA Type T) must be fitted in the live (+ve) supply line.
- The ground line must be connected to the ground stud and not to terminal 18 on the terminal block – see Fig. 5.7.

Do not disturb the link between terminal 18 and the Earth (Ground Stud).

- The type of power supply required (a.c. or d.c.) is stated at the time of order and can be identified from the instrument code number:

C50X/XX0X/STD = 85V min. to 265V max. a.c.

C50X/XX1X/STD = 24V d.c.

Type of Thermo-couple	Compensating Cable											
	BS1843			ANSI MC 96.1			DIN 43714			BS4937 Part No.30		
	+	-	Case	+	-	Case	+	-	Case	+	-	Case
Ni-Cr/Ni-Al (K)	Brown	Blue	Red	Yellow	Red	Yellow	Red	Green	Green	Green	White	Green *
Nicrsil/Nisil (N)	Orange	Blue	Orange	Orange	Red	Orange	—			Pink	White	Pink *
Pt/Pt-Rh (R and S)	White	Blue	Green	Black	Red	Green	Red	White	White	Orange	White	Orange *
Pt-Rh/Pt-Rh (B)	—			—			—			Grey	White	Grey *
Cu/Cu-Ni (T)	White	Blue	Blue	Blue	Red	Blue	Red	Brown	Brown	Brown	White	Brown *
Fe/Con (J)	Yellow	Blue	Black	White	Red	Black	Red	Blue	Blue	Black	White	Black *
* Case Blue for intrinsically safe circuits												
Fe/Con (L) (DIN 43710)	—			—			DIN 43710			—		
							Blue/red	Blue	Blue			

**Connections**  
**Table 5.1 Thermocouple Compensating Cable**

# SPECIFICATION

## Summary

17 application templates: Single loop, Cascade, Feedforward, Ratio, Auto/Manual

Two Autotune options

Control Efficiency Monitor

PC configuration

IP66/NEMA4X front face

## Operation

### Display

2 x 100 mm 40-segment LED bargraphs

2 x 10 mm 4-digit LED indicators

1 x 10 mm 3-digit LED indicators

Display range -1999 to +9999

### Configuration

Basic configuration via front panel keys

Advanced feature configuration by PC only

### Security

Internal security switch and password-protected menus

## Standard Functions

### Control Strategies

Single-loop, Auto/Manual Station, Analog Backup, Indicator/Manual Loader, Cascade\*, Feedforward, Ratio

### Output Types

Current proportioning, Time proportioning, On/off, Motorized Valve\* (with and without feedback), Heat/cool.

### Control Parameters

Four sets of PID settings, selectable via digital signals

### Set Points

Local, remote and four local set points, selectable via digital signals

### Configured Outputs

Three preset output values, selectable via digital signals

### Autotune

On demand for 1/4 wave or minimal overshoot

### Process Alarms

Number 8

Types High/low process, High/low output, High/low deviation

Hysteresis Level and time\*\*

Alarm enable/disable Enable/disable of alarms via digital signal

### Real Time Alarms\*\*

Number 2

Programmable On time/day and duration

\* Motorized valve without feedback output is not available with the Cascade template

\*\* Accessed via PC Configurator

## ...SPECIFICATION

### Analog Inputs

#### Universal Process Inputs

##### Number

- 1 standard
- 1 optional

##### Type

- Universally configurable to provide
  - Thermocouple (THC)
  - Resistance thermometer (RTD)
  - mV
  - Volts
  - mA
  - Resistance

##### Input Impedance

- mA 100 Ω
- mV, V 10 MΩ

##### Linearizer Functions

- THC types B, E, J, K, L, N, R, S, T, PT100,  $\sqrt{\quad}$ ,  $\frac{3}{2}$ ,  $\frac{5}{2}$

##### Broken Sensor Protection

- Programmable for upscale or downscale drive

##### Sample Interval

- 125 ms (1 input)

##### Digital filter

- Programmable

##### Cold Junction Compensation

- Automatic CJC incorporated as standard
- Stability 0.05 °C/°C change in ambient temperature

##### Input Protection

- Common mode rejection >120 dB at 50/60 Hz with 300 Ω imbalance resistance
- Series mode rejection >60 dB at 50/60 Hz

##### Transmitter Power Supply

- Number 1 standard, 1 optional
- Voltage 24 V DC nominal
- Drive Up to 45 mA as standard, up to 23 mA on option board

##### Non-universal Process Input

##### Number

- 1 standard
- Input types mA, mV only (THC only if IP1 is a THC)
- Linearization B, E, J, K, L, N, R, S, T, PT100,  $\sqrt{\quad}$ ,  $\frac{3}{2}$ ,  $\frac{5}{2}$

### Standard Analog Input Ranges

Thermocouple	Maximum Range °C	Maximum Range °F	Accuracy (% of reading)
B	-18 to 1800	0 to 3270	0.1 % or ±1 °C (1.8 °F) [above 200 °C (392 °F)] *
E	-100 to 900	-140 to 1650	0.1 % or ±0.5 °C (0.9 °F)
J	-100 to 900	-140 to 1650	0.1 % or ±0.5 °C (0.9 °F)
K	-100 to 1300	-140 to 2350	0.1 % or ±0.5 °C (0.9 °F)
L	-100 to 900	-140 to 1650	0.1 % or ±1.5 °C (2.7 °F)
N	-200 to 1300	-325 to 2350	0.1 % or ±0.5 °C (0.9 °F)
R	-18 to 1700	0 to 3000	0.1 % or ±0.5 °C (0.9 °F) [above 300 °C (540 °F)] *
S	-18 to 1700	0 to 3000	0.1 % or ±0.5 °C (0.9 °F) [above 200 °C (392 °F)] *
T	-250 to 300	-400 to 550	0.1 % or ±0.5 °C (0.9 °F)

\* For B, R and S thermocouples, accuracy is not guaranteed below value stated

Min. span below zero    Type T 70 °C (126 °F)    THC standards    DIN 43710  
 Type N 105 °C (189 °F)    IEC 584

RTD	Maximum Range °C	Maximum Range °F	Accuracy (% of reading)**
Pt100	-200 to 600	-325 to 1100	0.1 % or ±0.5 °C (0.9 °F)

\*\* RTD, 3-wire platinum, 100 Ω per DIN 43760 standard (IEC 751), with range of 0 to 400 Ω

Linear Inputs	Range	Accuracy (% of reading)
Millivolts	0 to 500 mV	0.1 % or ±10 μA
Milliamperes	0 to 50 mA	0.2 % or ±2 μA
Volts	0 to 5 V	0.2 % or ±2 mV
Resistance	0 to 5000 Ω	0.2 % or ±0.08 Ω



**Outputs****Control/Retransmission Outputs**

Number	1 standard, 1 optional
Type	Programmable as analog or logic (digital) output
Dielectric	Galvanically isolated from the rest of the circuitry
Analog range	0 and 20 mA (programmable), accuracy: 0.25 %
Digital voltage	17 V @ 20 mA

**Relay Outputs**

Number	2 standard, 2 optional
Type	SPST, rated 5 A at 115/230 V AC

**Digital Inputs**

Number	2 standard, 2 optional
Type	Volt-free
Minimum pulse	200 ms

**Advanced Features****Maths Blocks \***

Number	4
Operators	+, -, x, ÷, Average, Maximum, Minimum, High select, Low select, √, Median select, Relative Humidity Input multiplexer (digitally selected)

**Delay Timers \***

Number	2
Programmable	Delay and Duration in seconds

**Logic Equations \***

Number	6
Elements	15 per equation
Operators	OR, AND, NOR, NAND, NOT, EXOR

**Custom Linearizers \***

Number	2
Breakpoints	15 per linearizer

\* Accessed via PC Configurator

**Options****Analog Inputs**

Number	1
Isolation	Galvanically isolated from the rest of the circuitry
Type	Universal (see <b>Universal Process Inputs</b> on page 11)

**Analog/Digital Output**

Number	1
Isolation	Galvanically isolated from the rest of the circuitry
Type	Programmable 0 to 20 mA analog or 17 V @ 20 mA digital

**Relay Outputs**

Number	2
Type	SPST, rated 5 A at 115/230 V AC

**Digital Inputs**

Number	2
Type	Volt-free
Minimum pulse	200 ms

**Serial Communications**

Connections	RS485, 2- or 4-wire
Protocol	Modbus RTU
Isolation	Galvanically isolated from the rest of the circuitry

**Physical****Size**

76 mm x 148 mm x 149.5 mm  
(2.99 in. x 5.83 in. x 5.87 in.)

**Weight**

750 g (1.6 lb)

---

**EMC****Emissions and Immunity**

Meets requirements of IEC 61326 for an Industrial Environment

**Electrical****Voltage**

85 min. to 265 V max. AC 50/60 Hz  
24 V DC

**Power consumption**

15 VA max.

**Power interruption protection**

Up to 60 ms

**Safety**

General safety EN 61010-1

**Dielectric Strength**

500 V DC to earth:

Analog/digital output 1 to rest of the circuitry  
(500 V DC for 1 minute)

Analog/digital output 2 to rest of the circuitry  
(500 V DC for 1 minute)

Analog input 3 (IP3) to rest of the circuitry  
(500 V DC for 1 minute)

Serial communications to rest of the circuitry  
(500 V DC for 1 minute)

---

**Environmental****Operating Limits**

0 ° to 55 °C (32 ° to 130 °F)

5 to 95 %RH (non-condensing)

**Temperature stability**

<0.02 %/°C or 2 μV/°C (<0.011 %/°F or 1.11 μV/°F)

Long term drift <0.02 % of reading or 20 μV annually


**Front face**

NEMA4X (IP66)



A1 Single Loop Controller (Templates 1 and 2)

**Single Loop Control** provides basic feedback control using three term PID or On/off control. The controller output is calculated from the difference between the process variable and the control set point. The control set point can be a fixed value entered by the user or from a remote source.




- 1 Template 2 Only

A2 Auto/Manual Station and Analog Backup Station

A2.1 Series and Parallel Operation


**Note.** See Sections A2.2 and A2.3 for detailed templates.



## ...A2.2 Auto/Manual Station (Templates 3 and 4)

The **Auto/manual Station** provides a backup for a Master controller. In normal operation the C500's current output follows the master controller's output value. A fault in the master system can be identified either by detecting a low signal on the master output (template 3) or via a digital signal (template 4). When a fault is detected the C500 selects manual mode with its output either set to the last valid master output value or to a configured output value – see Section 4.6/ Control Configuration/ Configured Output 1. When the master signal is restored or the digital input returns to its normal state the C500 switches back to auto mode (i.e. C500 output = master output).

The auto/manual station can be used in series or in parallel with the master output signal – see Fig. A1. Parallel operation is achieved by using relay 1 in the C500 to energize an external relay (with suitable changeover contacts for switching low level signals) which selects the output to be routed to the actuator.




- 1 Template 3 only. Alarm A1 trip value can be set to give the desired low signal detection
- 2 Template 4 only

A2.3 Analog Backup (Templates 5 and 6)

The **Analog Backup** provides a backup for a master controller. In normal operation (remote control mode selected) the C500's current output follows the master controller's output value. A fault in the master system can be identified either by detecting a low signal on the master output (template 5) or via a digital signal (template 6). When a fault is detected the C500 switches into local control mode and the process is controlled by the PID output of the C500. The C500 PID algorithm continually tracks the master output value to ensure bumpless transfer from remote to local mode operation. When the master signal is restored or the digital input returns to its normal state the C500 switches back to remote control mode (i.e. C500 output = master output).



The analog backup station can be used in series or in parallel with the master output signal. (See Fig. A1). Parallel operation is achieved by using relay 1 in the C500 to energize an external relay (with suitable changeover contacts for switching low level signals) which selects the output to be routed to the actuator.



- 1 Template 5 only. Alarm A1 trip value can be set to give the desired low signal detection
- 2 Template 6 only.

A3 Indicator/Manual Loader Station (Templates 7 and 8)


The **Indicator/manual Loader Station** is used to display one or two process variables on the digital and bargraph displays. If the control output is assigned to an analog output, the lower display indicates its value which can be adjusted by the user. This output can be used to manually control a process or to provide a set point value for another controller.



- 1 Template 8 Only
- 2 Not applicable if Control Output Type is set to 'None' – see Section 4.2/Basic Configuration.

A4 Single Loop Controller with Feedforward (Templates 9 and 10)

**Single Loop Controller with Feedforward.** A disturbance variable is weighted by the feedforward gain ( $FFG_n$ ) and the feedforward bias ( $FFB_5$ ) values and then added to the controller output value. Multiplication of the feedforward signal with the control output (instead of addition) can be selected using the configurator. When in Manual mode, the PID output tracks the difference between the control output value and the feedforward signal, to ensure bumpless transfer back to auto mode.




- 1 Template 10 only
- 2 Can be set to multiplication using the PC configurator
- 3 Feedforward operation is disabled by setting FFGn to OFF





A5 Cascade Controllers (Templates 11 and 12)


**Cascade Controller:** Two PID controllers are used with the first (master) controller providing the set point for the second (slave) controller. The two controllers are linked internally. The master output can be weighted using the cascade ratio ( $C_r$ ,  $t_a$ ) and bias ( $C_b$ ,  $t_b$ ) values to create the slave set point value. When the auto/manual mode is changed (from the front panel or by a digital signal) both the master and slave controllers change mode. In manual the slave set point can be adjusted by the user and the value is tracked by the master controller to ensure bumpless transfer back into auto. The slave can also be taken out of cascade mode by selecting local mode using the front panel key (when slave values are displayed).




•1 Template 12 only

**Note.** It is not possible to have Motorized Valve without feedback on a Cascade template (templates 11 & 12)

A6 Cascade Controller with Feedforward (Template 13)

**Cascade with Feedforward Control.** Two PID controllers are implemented within the C500 with the first (master) controller providing the set point for the second (slave) controller. The two controllers are linked internally. To the master output (slave set point) a feedforward signal is added. This signal is a disturbance variable which is weighted by the feedforward gain ( $FFG_n$ ) and the feedforward bias ( $FFb_s$ ) values. When the auto/manual mode is changed (from the front panel or by a digital signal) both the master and slave controllers change mode. In manual the slave set point can be adjusted by the user and the value is tracked by the master controller (taking account of the feedforward signal) to ensure bumpless transfer back into auto. The slave can also be taken out of cascade mode using the front panel  switch (when the slave values are displayed).




- 1 The feedforward signal can be multiplied by the control output (instead of added) using the PC configurator
- 2 Feedforward operation is disabled by setting FFGN to OFF



A7 Ratio Controller (Templates 14 and 15)

The **Ratio Controller** enables a controlled process variable to be maintained automatically in definite proportion to another variable known as the wild variable. The wild variable weighted by ratio ( $r \cdot RL\ D$ ) and bias ( $b \cdot IR\ S$ ) values forms the control set point for the process variable. The ratio value applied to the wild variable can be either a local value set on the front panel or a remote signal on an analog input.




•1

•1 Template 15 only

**A8 Ratio Station (Templates 16 and 17)**

The **Ratio Station** provides a set point for a subsequent slave controller. The wild variable is weighted by ratio ( $r \cdot R\&t\&D$ ) and bias ( $b \cdot IR\&S$ ) values and is then retransmitted as an analog output value. The ratio value applied to the wild variable can be either a local value set on the front panel or a remote signal on an analog input.

The actual ratio of the process variable to the wild variable is also displayed.



\* Template 17 Only

**B1 Introduction**

Using the PC Configurator, the C500 can be programmed without using any of the front panel keys.

In addition to the standard settings, the PC Configurator also gives access to more advanced features not accessible via the front panel keys. These are summarized below.

For information on using individual features, refer to the on-line help facility.

---

**Note.** The instrument must be in Configuration Mode (Level 6 or above) and Modbus serial communications must be disabled when uploading or downloading from the PC Configurator.

---

**B2 Analog Input Customization**

- Custom mA, mV, Voltage and Resistance ranges
- Standard Linearizers can be assigned to electrical inputs (eg. allowing transmitter inputs to have thermocouple or resistance linearizers to be applied)
- Programmable fault detection levels (default = 10%)

**B3 Four Programmable Math Blocks**

One of seven types can be assigned to each math block:

<b>Standard Arithmetic</b>	Up to 4 operands and 3 operators can be combined in each block, with the operands being calculated sequentially.  Operators: add, subtract, divide, multiply, high select, low select, median select  Operands: any analog or digital signals (digital signals have the value '1' or '0')
<b>Average</b>	The average value of an analog signal over a selectable time period, reset by digital signal
<b>Maximum detection</b>	The maximum value of an analog signal, reset by digital signal
<b>Minimum detection</b>	The minimum value of an analog signal, reset by digital signal
<b>Relative humidity</b>	Calculated from wet and dry bulb temperature sensors
<b>Square root</b>	The square root value of any analog signal
<b>Input multiplexer</b>	Selection of one or two analog variables using a digital signal

**B4 Six Logic Equations**

<b>Elements</b>	Up to 15 per equation
<b>Operators</b>	Up to 7 per equation: OR, AND, NOR, NAND, NOT, EXOR
<b>Operands</b>	Up to 8 per equation: any digital signal. The NOT operator can be used to invert digital signals.

**B5 Process Alarm Customization**

- Time Hysteresis, 0 to 9999 seconds
- Alarm Disable Source

**B6 Two Real Time Alarms**

- Programmable ON days, hours, minutes and duration (00:00 to 23:59)
- Wildcard (\*) to allow operation every x minutes past the hour

### B7 Two Delay Timers

- Programmable delay and duration (0 to 9999 seconds)

### B8 Two Custom Linearizers

- 15 breakpoints per linearizer
- The source can be any analog signal

### B9 Template Customization

Each template can be customized by changing the sources for various functions in the C500. This allows maths blocks and custom linearizers to be added into the standard template format.

The following sources can be programmed:

- process variable inputs
- set point inputs
- position feedback input
- input to ratio/bias block
- ratio inputs
- bias inputs
- disturbance variable inputs
- input to feedforward block
- feedforward term: add to or multiply with PID O/P

### B10 Connecting the PC Configurator




Fig. B1 Connecting the PC Configurator

# FRAMES INDEX

## Set Up Frames

Frame Title

Frame Title	Mnemonic	Number
<b>A</b>		
Alarm 1 Trip	<i>1xxx</i>	<i>4.01</i>
Alarm 2 Trip	<i>2xxx</i>	<i>4.02</i>
Alarm 3 Trip	<i>3xxx</i>	<i>4.03</i>
Alarm 4 Trip	<i>4xxx</i>	<i>4.04</i>
Alarm 5 Trip	<i>5xxx</i>	<i>4.05</i>
Alarm 6 Trip	<i>6xxx</i>	<i>4.06</i>
Alarm 7 Trip	<i>7xxx</i>	<i>4.07</i>
Alarm 8 Trip	<i>8xxx</i>	<i>4.08</i>

Approach Band 1	<i>Ab 1</i>	<i>2.15</i>
Approach Band 2	<i>Ab 2</i>	<i>2.16</i>

## C

Cascade (Slave) Set Point	<i>SSPt</i>	<i>3.05</i>
Cascade Set Point Bias	<i>Cb 1R</i>	<i>3.09</i>
Cascade Set Point Ratio	<i>Crt 0</i>	<i>3.08</i>
Control Zone Deadband	<i>Cbnd</i>	<i>2.21</i>
Cycle Time 1	<i>CYC 1</i>	<i>2.01</i>
Cycle Time 2	<i>CYC 2</i>	<i>2.02</i>

## D

Deadband (Feedback only)	<i>dbnd</i>	<i>5.03</i>
Derivative Action Time 1	<i>dr U.1</i>	<i>2.13</i>
Derivative Action Time 2	<i>dr U.2</i>	<i>2.14</i>

## F

Feedforward Bias	<i>FFb 5</i>	<i>2.20</i>
Feedforward Gain	<i>FFGn</i>	<i>2.19</i>

## H

Heat/Cool Output 1 Start	<i>H 1St</i>	<i>2.22</i>
Heat/Cool Output 2 Start	<i>H 2St</i>	<i>2.23</i>

## I

Integral Action Time 1	<i>IRt - 1</i>	<i>2.09</i>
Integral Action Time 2	<i>IRt - 2</i>	<i>2.10</i>
Integral Action Time 3	<i>IRt - 3</i>	<i>2.11</i>
Integral Action Time 4	<i>IRt - 4</i>	<i>2.12</i>

## L

Local Set Point 1	<i>LSP.1</i>	<i>3.01</i>
Local Set Point 2	<i>LSP.2</i>	<i>3.02</i>
Local Set Point 3	<i>LSP.3</i>	<i>3.03</i>
Local Set Point 4	<i>LSP.4</i>	<i>3.04</i>

## M

Manual Reset	<i>rSt.1</i>	<i>2.17</i>
Manual Reset 2	<i>rSt.2</i>	<i>2.18</i>
Motorised Valve Bias	<i>Ub 1R</i>	<i>5.02</i>
Motorised Valve Ratio	<i>Ur Rt</i>	<i>5.01</i>

## O

Output 1 On/off Hysteresis Value	<i>HYS.1</i>	<i>2.03</i>
Output 2 On/off Hysteresis Value	<i>HYS.2</i>	<i>2.04</i>

## P

Proportional Band 1	<i>Pb - 1</i>	<i>2.05</i>
Proportional Band 2	<i>Pb - 2</i>	<i>2.06</i>
Proportional Band 3	<i>Pb - 3</i>	<i>2.07</i>
Proportional Band 4	<i>Pb - 4</i>	<i>2.08</i>

## R

Ramp Rate	<i>r.r tE</i>	<i>3.10</i>
Regulator Travel Time	<i>r.t.r.U.</i>	<i>5.04</i>
Remote Set Point Bias	<i>b 1RS</i>	<i>3.07</i>
Remote Set Point Ratio	<i>r Rt 0</i>	<i>3.06</i>

## S

Set Points	<i>LEU3</i>	<i>3.00</i>
------------	-------------	-------------

## T

Tune	<i>LEU2</i>	<i>2.00</i>
------	-------------	-------------

## V

Valve Set Up	<i>LEU5</i>	<i>5.00</i>
--------------	-------------	-------------




Fig. I.1 Parameter Identification

**Configuration Frames**

<i>Frame Title</i>	<i>Mnemonic</i>	<i>Number</i>
<b>A</b>		
Alarm 1 Hysteresis	<i>HY5.1</i>	<i>8.03</i>
Alarm 1 Trip	<i>trP.1</i>	<i>8.02</i>
Alarm 1 Type	<i>tyP.1</i>	<i>8.01</i>
Alarm 2 Hysteresis	<i>HY5.2</i>	<i>8.06</i>
Alarm 2 Trip	<i>trP.2</i>	<i>8.05</i>
Alarm 2 Type	<i>tyP.2</i>	<i>8.04</i>
Alarm 3 Hysteresis	<i>HY5.3</i>	<i>8.09</i>
Alarm 3 Trip	<i>trP.3</i>	<i>8.08</i>
Alarm 3 Type	<i>tyP.3</i>	<i>8.07</i>
Alarm 4 Hysteresis	<i>HY5.4</i>	<i>8.12</i>
Alarm 4 Trip	<i>trP.4</i>	<i>8.11</i>
Alarm 4 Type	<i>tyP.4</i>	<i>8.10</i>
Alarm 5 Hysteresis	<i>HY5.5</i>	<i>8.15</i>
Alarm 5 Trip	<i>trP.5</i>	<i>8.14</i>
Alarm 5 Type	<i>tyP.5</i>	<i>8.13</i>
Alarm 6 Hysteresis	<i>HY5.6</i>	<i>8.18</i>
Alarm 6 Trip	<i>trP.6</i>	<i>8.17</i>
Alarm 6 Type	<i>tyP.6</i>	<i>8.16</i>
Alarm 7 Hysteresis	<i>HY5.7</i>	<i>8.21</i>
Alarm 7 Trip	<i>trP.7</i>	<i>8.20</i>
Alarm 7 Type	<i>tyP.7</i>	<i>8.19</i>
Alarm 8 Hysteresis	<i>HY5.8</i>	<i>8.24</i>
Alarm 8 Trip	<i>trP.8</i>	<i>8.23</i>
Alarm 8 Type	<i>tyP.8</i>	<i>8.22</i>
Alarm Acknowledge Enable	<i>FPRP.</i>	<i>b.03</i>
Alarm Configuration	<i>LEUB, RL.5</i>	<i>8.00</i>
Analog I/P 1 Offset Cal	<i>OFF.1</i>	<i>E.01</i>
Analog I/P 1 Span Cal	<i>SPN.1</i>	<i>E.02</i>
Analog I/P 2 Offset Cal	<i>OFF.2</i>	<i>E.03</i>
Analog I/P 2 Span Cal	<i>SPN.2</i>	<i>E.04</i>
Analog I/P 3 Offset Cal	<i>OFF.3</i>	<i>E.05</i>
Analog I/P 3 Span Cal	<i>SPN.3</i>	<i>E.06</i>
Analog O/P 1 Electrical High	<i>RN IH</i>	<i>C.03</i>
Analog O/P 1 Electrical Low	<i>RN IL</i>	<i>C.04</i>
Analog O/P 1 Engineering High	<i>r IH</i>	<i>C.05</i>
Analog O/P 1 Engineering Low	<i>r IL</i>	<i>C.06</i>
Analog O/P 2 Electrical High	<i>RN2H</i>	<i>C.11</i>
Analog O/P 2 Electrical Low	<i>RN2L</i>	<i>C.12</i>
Analog O/P 2 Engineering High	<i>r2H</i>	<i>C.13</i>
Analog O/P 2 Engineering Low	<i>r2L</i>	<i>C.14</i>
Analog Output 1 Source	<i>RN IR</i>	<i>C.02</i>
Analog Output 2 Source	<i>RN2R</i>	<i>C.10</i>
Analog/Dig Output 1 Type	<i>tyP.1</i>	<i>C.01</i>
Analog/Dig Output 2 Type	<i>tyP.2</i>	<i>C.09</i>
Auto Selection Source	<i>RS-C</i>	<i>R.18</i>
Auto/Manual Switch Enable	<i>FPR.</i>	<i>b.01</i>
Autotune Password	<i>RPRS</i>	<i>b.07</i>

**B**

Basic Configuration	<i>LEUB, APPL</i>	<i>6.00</i>
Bias Display Enable	<i>bd IS</i>	<i>b.06</i>

**C**

Calibration	<i>LEUE, CAL</i>	<i>E.00</i>
CJ Beta Value	<i>bEER</i>	<i>E.14</i>
CJ Reading - I/P1 & I/P2	<i>CJ 1</i>	<i>E.15</i>
CJ Reading - I/P3	<i>CJ 2</i>	<i>E.16</i>
CJ Reference Value	<i>rEF</i>	<i>E.13</i>
Configuration Password	<i>CPRS</i>	<i>b.09</i>
Configured Output 1	<i>COP.1</i>	<i>R.13</i>
Configured Output 2	<i>COP.2</i>	<i>R.15</i>
Configured Output 3	<i>COP.3</i>	<i>R.17</i>
Control Action	<i>CACt</i>	<i>6.03</i>

Control Configuration	<i>LEUR</i>	<i>R.00</i>
-----------------------	-------------	-------------

**D**

Day Setting	<i>dAY</i>	<i>b.10</i>
Digital Output 1 Polarity	<i>dG IP</i>	<i>C.08</i>
Digital Output 1 Source	<i>dG IR</i>	<i>C.07</i>
Digital Output 2 Polarity	<i>dG2P</i>	<i>C.16</i>
Digital Output 2 Source	<i>dG2R</i>	<i>C.15</i>

**F**

Feedback Range High	<i>FbH1</i>	<i>E.12</i>
Feedback Range Low	<i>FbL0</i>	<i>E.11</i>

**I**

Input 1 Broken Sensor	<i>b5d.1</i>	<i>7.06</i>
Input 1 Decimal Point	<i>dP.1</i>	<i>7.03</i>
Input 1 Engineering High	<i>EN IH</i>	<i>7.04</i>
Input 1 Engineering Low	<i>EN IL</i>	<i>7.05</i>
Input 1 Filter Time Constant	<i>FLt.1</i>	<i>7.07</i>
Input 1 Temp Units	<i>UNt.1</i>	<i>7.02</i>
Input 1 Type	<i>tyP.1</i>	<i>7.01</i>
Input 2 Broken Sensor	<i>b5d.2</i>	<i>7.13</i>
Input 2 Decimal Point	<i>dP.2</i>	<i>7.10</i>
Input 2 Engineering High	<i>EN2H</i>	<i>7.11</i>
Input 2 Engineering Low	<i>EN2L</i>	<i>7.12</i>
Input 2 Filter Time Constant	<i>FLt.2</i>	<i>7.14</i>
Input 2 Temp Units	<i>UNt.2</i>	<i>7.09</i>
Input 2 Type	<i>tyP.2</i>	<i>7.08</i>
Input 3 Broken Sensor	<i>b5d.3</i>	<i>7.20</i>
Input 3 Decimal Point	<i>dP.3</i>	<i>7.17</i>
Input 3 Engineering High	<i>EN3H</i>	<i>7.18</i>
Input 3 Engineering Low	<i>EN3L</i>	<i>7.19</i>
Input 3 Filter Time Constant	<i>FLt.3</i>	<i>7.21</i>
Input 3 Temp Units	<i>UNt.3</i>	<i>7.16</i>
Input 3 Type	<i>tyP.3</i>	<i>7.15</i>





**A**

Accessories ..... 1

Alarms ..... 43, 56

    Acknowledge ..... 5

    Acknowledge enable ..... 68

    Configuration ..... 56

    Hysteresis ..... 58, 59

    Set Up ..... 43

    Trip Settings ..... 43, 56

    Type ..... 43, 58

Analog Backup Station ..... 16, 93

Analog Inputs – Level 7 ..... 52

    Broken Sensor ..... 53, 54, 55

    Decimal Places ..... 52, 54, 55

    Engineering Range ..... 53, 54, 55

    Calibration ..... 77

    Failure Action ..... 64

    Over/Under Range ..... See Fault Detection Level

Analog Outputs 1 and 2 ..... 70

    See Also: Digital Outputs 1 and 2

    Electrical Ranges ..... 71, 73

    Engineering Ranges ..... 71, 73

    Sources ..... 71, 73

        See Also: Rear Fold-out/ Table D

    Output Type ..... ?

Analog Sources ..... Rear Fold-out/ Table D

Approach Band ..... 39

Autotune30

    Error ..... 30

    Password ..... 69

    Starting ..... 32

Auto/Manual

    Mode Selection Source ..... 65, 66, 67, 68

    A/M Station Template ..... 14, 92

    A/M Switch ..... 4, 68

**B**

Bargraphs ..... 3

    See Also: Relevant Operator Template in Section 2

Basic Configuration – Level 6 ..... 48

Boundless Control – see Motorized Valves

Broken Sensor Drive ..... 53, 54, 55

**C**

Calibration – see Analog Inputs

Calibration Error ..... 9

Cascade Controllers 21, 24, 96, 97

    Control Action ..... 51

    Control Parameters ..... 38, 39

    Set Point Limits ..... 60

    Set Point Scaling ..... 42

    Tuning ..... 31, 32

Character Set ..... 8

Clock Setting ..... 69

Cold Junction

    Compensation ..... 79, 86, 89

    Failed ..... 9

**...C**

Configuration Error ..... 9

Configuration Password ..... 69

Configured Outputs 1 to 3 ..... 66

    See Also: Auto/Manual and Backup Templates

Control Action ..... 51

Control Configuration – Level A ..... 63

Control Efficiency Monitor ..... 33

Control Set Point – see Set Points

Control Output Deadband ..... 40

Custom Linearizer ..... 100

**D**

Date and Time Setting ..... 69

Deadband

    Control Output ..... 40

    MV Feedback ..... 44

Default Outputs ..... 61, 64, 66

Delay Timers ..... 101

Derivative Action Time ..... 39

Deviation Alarms ..... 56

Digital Inputs 1 to 4 ..... 85, 86

    See Also: Rear Fold-out/ Table C

Digital Outputs 1 and 2 ..... 70

    Polarity ..... 70, 72

    Source ..... 70, 72

Digital Sources ..... Rear Fold-out/ Table C

Direct Control Action ..... 51

Displays ..... 8, 9, 11

    LCD Alphabet ..... 8

Disturbance Variable – see Feedforward

**E**

Electrical Connections ..... 85

Error Messages ..... 9

**F**

Failure Modes

    Analog Input ..... 64

    Power Failure ..... 63

    Process Variable ..... 64

    Remote Set Point ..... 61

Fault-finding – see Error Messages

Fault Detection Level ..... 100

Feedback (Motorized Valves) ..... 44

    See Also: Analog Inputs (Process Variable)

Feedforward Controllers ..... 19, 24, 95

    Disturbance Variable ..... 19, 24, 39

Filter Time Constant ..... 53, 54, 55

Fine Tuning ..... 34, 77

**G**

Gain Scheduling

    Selection ..... 67

    Sources ..... 67

    Proportional and Integral Terms ..... 38

Glossary of Abbreviations ..... 10

- H**
- Heat/Cool ..... 28
    - Control Action ..... 49, 51
    - Output limits ..... 64
    - Start positions ..... 40
  - Hysteresis
    - Alarms ..... 56 to 59
    - On/off Control ..... 37
- I**
- Inputs – see Analog Inputs
  - Installation ..... 80
  - Integral Action Time ..... 38
- K**
- Klaxon Alarms ..... 56
- L**
- Latch Alarms ..... 57
  - LEDs ..... 8
  - Linearizers ..... 52, 54, 55, 100
  - Line Filter Frequency ..... 51
  - Local Set Point – see Set Points
  - Local/Remote Key Enable ..... 68
  - Local/Remote Mode Selection ..... 6, 16, 61, 62
  - Locking Front Panel Keys ..... 68
  - Logic Equations ..... 100
  - Loop Break Monitor ..... 10
- M**
- Mains Rejection Frequency ..... 51
  - Manual Mode Selection ..... 65, 66, 68
    - Pre-set manual output ..... 66
  - Manual Reset ..... 39
  - Master – see Cascade Controllers
  - Maths Blocks ..... 100
  - Mechanical Installation ..... 80
  - MODBUS ..... 76, 85
  - Mounting ..... 81
  - Motorized Valve
    - Boundless ..... 45
    - Calibration ..... 78
    - Connections ..... 88
    - Control Type Selection ..... 49
    - Feedback ..... 44
    - Regulator Travel Time ..... 44, 46, 78
    - Set Up ..... 44
- O**
- On/Off Control ..... 37
    - See Also: Control Types
  - Operator Configuration – Level B ..... 68
  - Operating Displays ..... 3
  - Operator Ratio/Bias Display Enable ..... 68
  - Operator Level ..... 11
- ...O**
- Output**
- Assignment – Level C ..... 70
  - Connections ..... 85, 87, 88
  - Heat/Cool ..... 28
  - Limits ..... 64
  - Slew Rate ..... 65
  - Output Sources ..... Rear Fold-out/ Table B
  - Types ..... 49
  - Option Board ..... 85
- P**
- Panel Clamps ..... 2, 82
  - PC Configurator ..... 100
  - PID Parameters ..... 38, 39
    - See Also: Gain Scheduling
  - Power Fail Recovery ..... 63
  - Power Supplies ..... 85, 89
  - Power Up Displays ..... 11
  - Process
    - Alarms ..... 57
    - Labels ..... 84
    - Optimization – see Control Efficiency Monitor
    - Variable – see Analog Inputs
  - Proportional Band Settings ..... 38, 39
- R**
- Ramp Rate (Set Point) ..... 42
    - See Also: Output Slew Rate
  - Ratio
    - Cascade Set Point ..... 42
    - Controller ..... 26, 98
    - Disturbance Variable ..... 39, 40
    - Ratio Display Enable ..... 68
    - Remote Set Point ..... 41
    - Station ..... 27, 99
  - Real-time Alarms ..... 100
  - Reference Tables ..... Rear Fold-out
  - Relative Humidity ..... 100
  - Regulator Travel Time – see Motorized Valves
  - Relay
    - Connections ..... 85
    - Links ..... 87
    - See Also: Output Assignment, Output Types
  - Remote Set Point
    - Failure Action ..... 61
    - Scaling ..... 41
    - Selection Source ..... 62
  - Resistance Thermometer ..... 52, 55, 85, 86
  - Retransmission – See Analog Outputs,
    - Analog Sources
  - Reverse Control Action ..... 51

**S**

Secret-til-Lit Indicators .....	8
Security Options .....	69
Serial Communications – Level d .....	76
Set Points	
Configuration – Level 9 .....	60
Default Value .....	61
Limits .....	60
Operator Adjust enable .....	68
Ramp Rate .....	42
Scaling .....	41
Selecting .....	61
Setting – see Relevant Operator Template	
Sources .....	61
Tracking .....	60
Single Loop	
Controllers .....	12, 16, 19, 26, 90, 93, 95, 98
Siting .....	80
Short-cut keys .....	7
Slave Controller – see Cascade Controllers	
Slave Set Point – see Cascade Controllers	
Slew Rate .....	65
Soft-start – see Set Point Ramp Rate, Output Slew Rate	
Span Adjustment – see Calibration	

**T**

Temperature Units .....	52, 54, 55
Template Applications .....	11, 48, 90,
Rear Fold-out, Table A	
Terminals and Connections .....	85
Thermocouple .....	52, 53, 54, 55, 85, 86
Time	
Setting .....	69
Real-time alarms .....	100
Delay Timers .....	101
Tuning	
Automatic .....	30
Manual .....	34
Tune Parameter Source .....	67

**U**

Units – see Temperature Units

**V**

Valve – see Motorized Valve	
Valve Sticking .....	9

**W**

Warning Messages .....	9
Watchdog .....	10
Wild Variable – see Ratio Controller	

REFERENCE TABLES

Table A – Template Applications

Config. Display	Template Title	Analog Input 1 (I/P1)	Analog Input 2 (I/P2)	Analog Input 3 (I/P3) *
1. 5L	Single loop	Process Variable		Feedback †
2. 5L	Single loop + Remote set point	Process Variable	Remote Set Point	Feedback †
3. R.	Auto/Manual station (low signal select)	Process Variable	Master Output	–
4. R.	Auto/Manual station (digital select)	Process Variable	Master Output	–
5. Rb	Analog backup (low signal select)	Process Variable	Master Output	–
6. Rb	Analog backup (digital select)	Process Variable	Master Output	–
7. In	Single indicator/manual loader	Process Variable	–	–
8. In	Double indicator/manual loader	Process Variable 1	Process Variable 2	–
9. FF	Single loop + Feedforward	Process Variable	Disturbance Variable	Feedback †
10. FF	Single loop + Feedforward + Remote set point *	Process Variable	Disturbance Variable	Remote Set Point
11. CC	Cascade	Master PV	Slave PV	Feedback †
12. CC	Cascade + Remote set point *	Master PV	Slave PV	Remote Set Point
13. CF	Cascade with Feedforward *	Master PV	Slave PV	Disturbance Variable
14. rC	Ratio controller	Process Variable	Wild Variable	Feedback †
15. rC	Ratio controller with remote ratio *	Process Variable	Wild Variable	Remote ratio
16. rS	Ratio station	Process Variable	Wild Variable	–
17. rS	Ratio station with external ratio *	Process Variable	Wild Variable	Remote ratio

\* Only available with option board fitted

† Motorized Valve output types only

Table B – Output Sources

**Note.** Settings shown in **bold** are fixed and cannot be adjusted. Other settings are changed in Level C/ Output Assignment.

Setting	Output Type	Relays				Analog Outputs		Digital Outputs	
		Rly 1	Rly 2	Rly 3	Rly 4	ao1	ao2	do1	do2
<i>None</i>	None	–	–	–	–	–	–	–	–
<i>RNLG</i>	Analog Output	Alm1#	Alm 2#	Alm 3	Alm 4	<b>OP1</b>	PV	–	–
<i>rLY</i>	Relay Output	<b>OP1</b>	Alm 1#	Alm 2	Alm 3	PV	CSPT	–	–
<i>dIG</i>	Digital Output	Alm 1	Alm 2	Alm 3	Alm 4	OP1	PV	<b>OP1</b>	–
<i>PFb</i>	Motorized valve with FB*	<b>OPEN</b>	<b>CLOSE</b>	Alm 1	Alm 2	PV	CSPT	–	–
<i>bnd</i>	Motorized valve without FB	<b>OPEN</b>	<b>CLOSE</b>	Alm 1	Alm 2	PV	CSPT	–	–
<i>HCrr</i>	Heat/Cool	<b>OP1</b> (Heat)	<b>OP2</b> (Cool)	Alm 1	Alm 2	PV	CSPT	–	–
<i>HCrd</i>	Heat/Cool	<b>OP1</b>	Alm 1	Alm 2	Alm 3	–	PV	<b>OP2</b>	–
<i>HCdr</i>	Heat/Cool	<b>OP2</b>	Alm 1	Alm 2	Alm 3	–	PV	<b>OP1</b>	–
<i>HCdd</i>	Heat/Cool*	Alm 1	Alm 2	Alm 3	Alm 4	–	–	<b>OP1</b>	<b>OP2</b>
<i>HCRR</i>	Heat/Cool	<b>OP2</b>	Alm 1	Alm 2	Alm 3	<b>OP1</b>	PV	–	–
<i>HCrd</i>	Heat/Cool*	Alm 1	Alm 2	Alm 3	Alm 4	<b>OP1</b>	PV	–	<b>OP2</b>
<i>HCRR</i>	Heat/Cool*	Alm 1	Alm 2	Alm 3	Alm 4	<b>OP1</b>	<b>OP2</b>	–	–

\* Available only with option board fitted

# Relay 1 is assigned to energize when in manual mode and templates 3, 4, 5 or 6 are selected

Alm = Alarm  
 Rly = Relay  
 ao1 = Analog Output1  
 ao2 = Analog Output2  
 do1 = Digital Output 1

do2 = Digital Output 2  
 OP1, 2 = Output 1, 2  
 PV = Process Variable RTX  
 CSPT = Set Point RTX

Table C – Digital Sources

Source Type	Display	Description	Source Type	Display	Description
<b>Control Outputs</b>	<i>OP 1</i>	Control output 1 (heat)	<b>Failure States</b>	<i>F. IN 1</i>	Input 1 failed
	<i>OP 2</i>	Control output 2 (cool)		<i>F. IN 2</i>	Input 2 failed
	<i>OPEN</i>	Motorized valve Open Relay		<i>F. IN 3</i>	Input 3 failed
	<i>CLOSE</i>	Motorized valve Close Relay		<i>LB P. 1</i>	Loop break - analog output 1
<b>Process Alarms</b>	<i>A 1</i>	Alarm 1 active		<i>LB P. 2</i>	Loop break - analog output 2
	<i>A 2</i>	Alarm 2 active		<i>DOG</i>	Watchdog active
	:			<i>PF</i>	Power fail
<b>Alarm Acknowledge</b>	<i>ACK 1</i>	Alarm 1 acknowledge	<b>Logic equations*</b>	<i>LG 1</i>	Logic equation 1 true
	<i>ACK 2</i>	Alarm 2 acknowledge		<i>LG 2</i>	Logic equation 2 true
	:			:	
<b>Digital inputs</b>	<i>DI 1</i>	Digital input 1 active	<b>Timers</b>	<i>LG 6</i>	Logic equation 6 true
	<i>DI 2</i>	Digital input 2 active		<i>rt 1</i>	Real time alarm 1
	<i>DI 3</i>	Digital input 3 active		<i>rt 2</i>	Real time alarm 2
	<i>DI 4</i>	Digital input 4 active		<i>dt 1</i>	Delay timer 1
<b>Control Modes</b>	<i>_RN</i>	Manual mode selected	<b>Other Signals</b>	<i>dt 2</i>	Delay timer 2
	<i>RUt</i>	Auto mode selected		<i>ON</i>	Always enabled
	<i>LDC</i>	Local set point/ Local control selected		<i>_b. 1</i>	MODBUS Signal 1
	<i>rE_</i>	Remote set point/ Remote control selected		<i>_b. 2</i>	MODBUS Signal 2
			<i>_b. 3</i>	MODBUS Signal 3	
			<i>_b. 4</i>	MODBUS Signal 4	

\* The default factory settings for each logic equation is:

LG1 - The OR of all alarm states; LG2 – The AND of all alarm states

LG3 - The OR of the alarm acknowledge states

LG4 - The OR of the first four alarm state; LG5 – The OR of the second four alarm states

LG6 - The OR of the input fail states

Table D – Analog Sources

Display	Description	Display	Description
<i>OP 1</i>	Control output 1 (heat)	<i>SSPt</i>	Slave setpoint
<i>OP 2</i>	Control output 2 (cool)	<i>dEU. 1</i>	PID (master loop) deviation (PV – control setpoint)
<i>PU</i>	Process variable 1	<i>dEU. 2</i>	PID (slave loop) deviation (PV – control setpoint)
<i>PU. 2</i>	Process variable 2	<i>RUP</i>	Actual valve position
<i>_PU</i>	Master process variable	<i>bLP. 1</i>	Maths block 1 output
<i>SPU</i>	Slave process variable	<i>bLP. 2</i>	Maths block 2 output
<i>I/P 1</i>	Analog input 1	<i>bLP. 3</i>	Maths block 3 output
<i>I/P 2</i>	Analog input 2	<i>bLP. 4</i>	Maths block 4 output
<i>I/P 3</i>	Analog input 3	<i>CU. 1</i>	Custom linearizer 1 output
<i>CSPt</i>	Control setpoint	<i>CU. 2</i>	Custom linearizer 2 output
<i>rSPt</i>	Remote setpoint	<i>PID. 1</i>	PID block (master loop) output
<i>LSP 1</i>	Local setpoint 1	<i>PID. 2</i>	PID block (slave loop) output
<i>LSP 2</i>	Local setpoint 2	<i>rb.</i>	Remote set point ratio/bias
<i>LSP 3</i>	Local setpoint 3	<i>Crb.</i>	Cascade ratio/bias output
<i>LSP 4</i>	Local setpoint 4	<i>FF</i>	Feedforward block output

# PRODUCTS & CUSTOMER SUPPORT

## Products

### Automation Systems

- *for the following industries:*
  - Chemical & Pharmaceutical
  - Food & Beverage
  - Manufacturing
  - Metals and Minerals
  - Oil, Gas & Petrochemical
  - Pulp and Paper

### Drives and Motors

- *AC and DC Drives, AC and DC Machines, AC Motors to 1kV*
- *Drive Systems*
- *Force Measurement*
- *Servo Drives*

### Controllers & Recorders

- *Single and Multi-loop Controllers*
- *Circular Chart , Strip Chart and Paperless Recorders*
- *Process Indicators*

### Flexible Automation

- *Industrial Robots and Robot Systems*

### Flow Measurement

- *Electromagnetic Magnetic Flowmeters*
- *Mass Flow Meters*
- *Turbine Flowmeters*
- *Wedge Flow Elements*

### Marine Systems & Turbochargers

- *Electrical Systems*
- *Marine Equipment*
- *Offshore Retrofit and Refurbishment*

### Process Analytics

- *Process Gas Analysis*
- *Systems Integration*

### Transmitters

- *Pressure*
- *Temperature*
- *Level*
- *Interface Modules*

### Valves, Actuators and Positioners

- *Control Valves*
- *Actuators*
- *Positioners*

### Water, Gas & Industrial Analytics

#### Instrumentation

- *pH, conductivity, and dissolved oxygen transmitters and sensors*
- *ammonia, nitrate, phosphate, silica, sodium, chloride, fluoride, dissolved oxygen and hydrazine analyzers.*
- *Zirconia oxygen analyzers, katharometers, hydrogen purity and purge-gas monitors, thermal conductivity.*

## Customer Support

We provide a comprehensive after sales service via a Worldwide Service Organization. Contact one of the following offices for details on your nearest Service and Repair Centre.

### United Kingdom

ABB Limited  
Tel: +44 (0)1480 475321  
Fax: +44 (0)1480 217948

### United States of America

ABB Inc  
Instrumentation Division  
Tel: +1 215 674 6000  
Fax: +1 215 674 7183

#### Client Warranty

Prior to installation, the equipment referred to in this manual must be stored in a clean, dry environment, in accordance with the Company's published specification.

Periodic checks must be made on the equipment's condition. In the event of a failure under warranty, the following documentation must be provided as substantiation:

1. A listing evidencing process operation and alarm logs at time of failure.
2. Copies of all storage, installation, operating and maintenance records relating to the alleged faulty unit.

---

**ABB** has Sales & Customer Support expertise  
in over 100 countries worldwide

[www.abb.com](http://www.abb.com)

The Company's policy is one of continuous product  
improvement and the right is reserved to modify the  
information contained herein without notice.

Printed in UK (10.07)

© ABB 2007



**ABB Limited**

Howard Road, St. Neots  
Cambridgeshire  
PE19 8EU  
UK  
Tel: +44 (0)1480 475321  
Fax: +44 (0)1480 217948

**ABB Inc.**

125 E. County Line Road  
Warminster  
PA 18974  
USA  
Tel: +1 215 674 6000  
Fax: +1 215 674 7183