

Field^{IT}

Temperature Transmitter PROFIBUS-PA TF12 / TF212

1.16.2

Industrial^{IT}
enabled™

Version Information



ABB

Field^{IT}
Temperature Transmitter PROFIBUS-PA
TF12 / TF212
1.16.2

Version Information

NOTICE

The information in this document is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this document.

In no event shall ABB be liable for direct, indirect, special, incidental or consequential damages of any nature or kind arising from the use of this document, nor shall ABB be liable for incidental or consequential damages arising from use of any software or hardware described in this document.

This document and parts thereof must not be reproduced or copied without written permission from ABB, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

The software or hardware described in this document is furnished under a license and may be used, copied, or disclosed only in accordance with the terms of such license.

Copyright © 2004 ABB
All rights reserved.

Release: October 2004
Document number: 3BDD015008R0301 Rev. A

CE MARKING

This product meets the requirements specified in EMC Directive 89/336/EEC and in Low Voltage Directive 73/23/EEC.

TRADEMARKS

FieldController is a registered trademark of ABB Automation Products GmbH, Germany.

PROFIBUS and PROFIBUS-DP are trademarks of PROFIBUS International (P.I.).

HART is a trademark of HART Communication Foundation.

TABLE OF CONTENTS

TABLE OF CONTENTS	5
1. Introduction	6
Abbreviations / Symbols	6
Firmware revision history.....	7
Compatibility	7
Limitations.....	7
Applicable reference documents	7
2. Functions description	8
Functions not yet released	8
New functions	8
Modified functions.....	8
Functions that are no longer supported.....	8
Identified problem areas and remedial measures	8
Corrected behavior	8
Frozen value when powered up under failure condition (2 x 3 wire)	8
Recommendations.....	9

1. Introduction

Abbreviations / Symbols

This publication includes **Warnings**, **Cautions** and **Information** issues where appropriate to point out safety-related or other important information. It also includes **Tips** to point useful hints to the reader. The corresponding symbols should be interpreted as follows:



Warnings indicate the presence of a hazard which could result in personal injury.



Cautions indicate the presence of a hazard which could result in equipment or property damage.



Information alerts the reader to pertinent facts and conditions.



Indicates special conditions for meeting explosion protection requirements.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it should be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

Firmware revision history

1.16.0 (1.16)		
1.16.1	August 2004	Correction startup at 2 x 3 wire resistor. This version was not released.
1.16.2	October 2004	Improved startup behavior

Compatibility

Interface	Recom. revision level	Supported compatible revision levels
GSD ABB_04C4.GSD	1.1.0	1.0.3 →
DTM (FDT 0.98)	last released (newest)	all released
DTM (FDT 1.2)	last released (newest)	all released
EDD (für PDM)	1.2.0	1.2.0 →

The file name of the device data file (GSD file) is stipulated by the standard and, therefore, must not include the revision level. However, the engineering tool usually permits to indicate the GSD file revision number as a comment in the header when opening the file.

Limitations

None.

Applicable reference documents

Topics / Documents	Reference document No.
Manual TF12	3BDD015005
Datasheet TF12 / TF12-Ex	10/11-8.26 DE
Datasheet TF212 / TF212-Ex	10/11-8.70 DE
Manual Linking Device LD800P	3BDD011704
Manual Multibarriere MB204	42/63-15 DE
DPV1 Object Dictionary TF12 / TF212	3BDD015007

2. Functions description

Functions not yet released

None.

New functions

None.

Modified functions

None.

Functions that are no longer supported

All functions used so far, especially the I/O modules and the parameter setting and redundancy modes are still fully supported.

Identified problem areas and remedial measures



The commissioning / connection of the transmitter on the PROFIBUS is not allowed with open sensor-input(s).
At operating mode '2 x 4-wire thermo-resistor' the sensor has to be connected prior to power up the device.

Corrected behavior

Frozen value when powered up under failure condition (2 x 3 wire)

At firmware version 1.16.0 (1.16) the input value would not be updated when the transmitter is operated in mode '2 x 3-wire resistor' and the sensor of channel 2 remains disconnected during startup.

This behavior is now corrected with firmware version 1.16.2.

Recommendations

None.



Printed in Germany

Copyright © 2003 by ABB. All Rights Reserved

® Registered Trademark of ABB.

™ Trademark of ABB.

<http://www.abb.com/>

ABB Automation Products GmbH

Borsigstrasse 2, D-63755 Alzenau

Phone +49(0)6023 92-0, Fax +49(0)6023 92-3430