

#### Install Steps:

1. Disconnect your Edgeport device.
2. Using Winzip, Unzip file 40002537.zip to a temporary directory of your choice.
3. If you have not previously installed your Edgeport Device got to step 6.
4. Else “Left” Click on the Start button on the desktop and navigate to the “Programs/Digi USB configuration Utility”.
5. Next go to the “Advanced Tab” and Select “Uninstall”
6. Plug in your Edgeport device.
7. When the New hardware Wizard pops up answer “No” to Can Windows connect to Windows Update to search for Software”
8. Click “Next”
9. Choose “Install from a list or specific location”
10. Click “Next”
11. Navigate to the “location where you unzipped the files”.
12. Click “Next”
13. Click “Finish”
14. “Right” Click on “MyComputer” and select “Properties.”
15. Select “Hardware” then “Device Manager”.
16. Next expand the “Ports(COM LPT1)”
17. Select the Edgeport Device
18. Right “Click”
19. Select “Properties”
20. Select the “Driver” Tab
21. Verify that the driver version is 4.50.0.0 date 2/28/2008
22. Reboot your computer.
23. You’re Ready to Go.