

*DEH-41414 Installation Instructions*

**EntelliGuard® G Circuit Breaker Accessories**

Pushbutton Padlock Device

**Introduction**

**Pushbutton Padlock Device:**


The optional pack contains a Pushbutton lock kit, which has to be fixed in the fascia. It denies unauthorized access to the ON/OFF Pushbuttons.




**Cat No. GPBDR**

Use the following procedure to install the Pushbutton Padlock Device accessory into the circuit breaker.

1. Turn the breaker off and discharge the closing springs by depressing the OFF and ON buttons in the sequence OFF-ON-OFF. Verify that the breaker OFF-ON indicator shows OFF on a green background and that the charge indicator shows DISCHARGE on a white background. If installing in a draw-out type breaker remove breaker from adaptor (cassette) before continuing.

 **WARNING:** Before installing any accessories, turn the breaker OFF, disconnect it from all voltage sources, and discharge the closing springs.

 **AVERTISSEMENT:** Avant d'installer tout accessoire, mettre le disjoncteur en position OFF, le déconnecter de toute tension d'alimentation, et décharger les ressorts d'armement

2. Loosen the 6 screws on front cover (fascia) using a posidrive screw driver as shown in Fig 1.B Rotate the charging handle down and slide the front cover over the handle to remove the front cover as shown in Fig. 1.C.



**Figure 1. (A) Front Cover (B) Screw Removal (C) Handle Rotation**

3. Knock out the regions shown in Fig. 2 in fascia to locate the push button lock kit.




Figure 2.

4. Fix the Padlocking device kit with fascia using the screws provided refer Fig. 3




Figure 3: Assembly of Padlock Device

5. Raise the appropriate windows of ON/OFF buttons. Install padlock hasp through the locking eye (Fig. 4). Padlock hasp can be of 3 to 8mm diameter.



Figure 4: Fixing the screws

6. To Reinstall the cover, rotate the charging handle down and slide the front cover over the handle to assemble the front cover to housing as shown in Fig. 5.



Figure 5.

7. Ensure the fascia is aligned properly with the trip unit and the pad lock features of the breaker.

8. Fasten the 6 mounting screws of fascia with the housing using a pozidrive screwdriver. Apply torque of 6 Nm (4.42 ft-lbs).

## Reference:

These instructions do not cover all details or variations in equipment nor do they provide for every possible contingency that may be met in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise that are not covered sufficiently for the purchaser's purposes, the matter should be referred to the ABB Inc.

—  
**ABB Inc.**  
305 Gregson Drive  
Cary, NC 27511.  
[electrification.us.abb.com](http://electrification.us.abb.com)

—  
We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB Inc. does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB Inc.  
Copyright© 2019 ABB  
All rights reserved