

8188 PROTECTIVE CONTACT (SCHUKO) – R60 SKY NIESSEN SOCKET

# PEP ecopassport®

# Environmental Product Declaration





Document in compliance with ISO 14025: 2006 "Environmental labels and declarations. Type III environmental declarations"

ABB Niessen		CONTACT INFORMATION	CONTACT INFORMATION Lide Brito - lide.brito@es.abb.com				
		Lide Brito - lide.brito@es.abb.					
		WEBSITE	WEBSITE				
Aranguren Pol., 6, 20180 Oiartzun, Gipuzkoa			www.new.abb.com	www.new.abb.com			
STATUS		SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE	
In Review		Public	ABBG-00224-V01.01-EN	1	en	1/11	

# ABB Purpose & Embedding Sustainability

ABB is committed to continually promoting and embedding sustainability across its operations and value chain, aspiring to become a role model for others to follow. With its ABB Purpose, ABB is focusing on reducing harmful emissions, preserving natural resources and championing ethical and humane behavior.

Scan QR code for more information




# **General Information**

Reference product	2CLA818800A1001 R60 socket with 2CLA858700A5101 cover and 2CLA857110A1101 frame
Description of the product	Schuko socket-type product family, which is used to connect appliances to the electrical current in a circuit
Functional unit	Connect during 20 years the plug of a load consuming 16A under a voltage of 250V while protecting the user from direct contact with live parts and with a protection class IP20.  In= Rated current of the socket (16A).  U = Voltage (250V)  IP = Type F: 2P + E.
Other products covered	List of other products covered or a reference to page 9.10.11

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE			
In Review	Public	ABBG-00224-V01.01-EN	1	en	2/11			
© Copyright 2022 ABB. All rights reserved.								

# **Constituent Materials**



■ Plastics 74.61 g ■ Metals 95.12 g ■ Others 19.73 g

**Total weight of Reference** product

189.46

Plastics as % of weight		Metals as % of weight		Others as % of weight		
Name and CAS number	Weight%	Name and CAS number	Weight%	Name and CAS number	Weight%	
PC	23.8	STEEL	31.1	CARDBOARD	10.4	
UREA RESIN	14.5	STAINLESS STEEL	10.0	-	-	
PA	1.2	BRASS	9.0	-	-	

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE			
In Review	Public	ABBG-00224-V01.01-EN	1	en	3/11			
© Copyright 2022 ABR All rights reserved								



# Additional Environmental Information

Manufacturing	Includes the environmental impacts associated with extraction and processing of the raw materials used to produce the product and its pacakging, transport to the manufacturing site and assembly.
Distribution	Includes the transportation of the product in its packaging from the manufacturer's last logistic platform to the distributor.
Installation	Installation stage includes the installation of the products made manually and the end of life of packaging.
Use	The use scenario requirements take into account the loss of energy at a 50% of the load rate with a use time rate of 30% during 20 years: 7,23 kWh. The energy models used in this phase are the specific energy mixes based on ABB distribution. No maintenance is necessary.
End of life	Includes its transportation from the installation site to the final end of life treatment site, and end of life treatment processes. A value of 1000 km transport by lorry is used for the transportation.
Benefits and loads beyond the system boundaries	Prevented impacts of recycling materials.

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE
In Review	Public	ABBG-00224-V01.01-EN	1	en	4/11





# **Environmental Impacts**

Reference lifetime	20 years
Product category	Sockets
Installation elements	End of life of packaging
Use scenario	Europe
Geographical representativeness	Global
Technological representativeness	Materials and processes data are specific for the production of socket and its family
Software and database used	SimaPro 9.3 and ecoinvent 3.8.
Energy model used	
Manufacturing	Spain
Installation	Global
Use	Europe
End of life	Global

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE			
In Review	Public	ABBG-00224-V01.01-EN	1	en	5/11			
© Copyright 2022 ABB. All rights reserved.								

## Common base of mandatory indicators





Indicator	Unit	Total	Manu- facturing	Distri- bution	Installation	Use	End of life	Bene- fits
GWP-total	kg CO <sub>2</sub> eq.	3.98E+00	1.13E+00	2.30E-02	6.35E-03	2.78E+00	4.25E-02	-7.14E-0
GWP-fossil	kg CO <sub>2</sub> eq.	3.94E+00	1.12E+00	2.30E-02	3.43E-03	2.75E+00	4.18E-02	-7.14E-0
GWP-biogenic	kg CO <sub>2</sub> eq.	2.41E-02	9.55E-03	2.06E-05	2.92E-03	1.09E-02	7.28E-04	9.82E-0
GWP-luluc	kg CO <sub>2</sub> eq.	2.02E-02	1.75E-03	9.04E-06	1.35E-06	1.84E-02	1.16E-05	-4.49E-0
GWP-fossil = Globa GWP-biogenic = Glo GWP-luluc = Global	obal Warming Po	tential biog	enic	nge				
ODP	kg CFC-11 eq.	1.09E-06	9.09E-07	5.31E-09	7.87E-10	1.71E-07	6.77E-09	-2.84E-0
ODP = Depletion po	otential of the str	atospheric	ozone layer					
AP	H+ eq.	3.42E-02	0.00E+00	9.58E-05	1.42E-05	2.24E-02	1.22E-04	-8.51E-0
AP = Acidification p	ootential, Accumu	lated Excee	edance					
EP-freshwater	kg P eq.	2.13E-04	1.75E-03	1.61E-07	2.43E-08	1.42E-04	2.14E-07	-4.24E-0
EP-marine	kg N eq.	4.39E-03	1.18E-03	2.84E-05	4.32E-06	3.14E-03	3.89E-05	-7.53E-0
EP-terrestrial	mol N eq.	4.95E-02	1.34E-02	3.14E-04	4.76E-05	3.53E-02	4.07E-04	-9.27E-0
<b>EP-terrestrial</b> EP-freshwater = Eu EP-marine = Eutrop EP-terrestrial = Eut	trophication pot phication potenti	ential, fract al, fraction	ion of nutrients reach	eaching freshv	vater end compart		4.07E-04	-9.27E-(
EP-freshwater = Eu EP-marine = Eutrop	trophication pot phication potenti	ential, fract al, fraction	ion of nutrients reach	eaching freshv	vater end compart		4.07E-04 1.24E-04	
EP-freshwater = Eu EP-marine = Eutrop EP-terrestrial = Eut	trophication pot phication potenti prophication pote kg NMVOCeq.	ential, fract al, fraction o ntial, Accun	ion of nutrients ro of nutrients reach nulated Exceedan 4.04E-03	eaching freshv iing marine en ice	vater end compart d compartment	ment		
EP-freshwater = Eu EP-marine = Eutrop EP-terrestrial = Eut POCP	trophication pot phication potenti prophication pote kg NMVOCeq.	ential, fract al, fraction o ntial, Accun	ion of nutrients ro of nutrients reach nulated Exceedan 4.04E-03	eaching freshv iing marine en ice	vater end compart d compartment	ment		-2.94E-(
EP-freshwater = Eu EP-marine = Eutrop EP-terrestrial = Eut  POCP  POCP = Formation  ADP-minerals &	trophication pot shication potenti rophication pote kg NMVOCeq. potential of trop	ential, fraction on tial, Accunial, Accunial, Accunial, Accunial, Accunial, Accunial, Accunial, Accuniate of the time of time of time of the time of time	ion of nutrients ro of nutrients reach nulated Exceedan 4.04E-03	eaching freshv ning marine en Ice 9.57E-05	vater end compart: d compartment 1.44E-05	9.64E-03	1.24E-04	-2.94E-0 -1.53E-0
EP-freshwater = Eu EP-marine = Eutrop EP-terrestrial = Eut  POCP  POCP = Formation  ADP-minerals & metals	kg NMVOCeq. potential of trop  kg Sb eq.  MJ  tals = Abiotic dep	ential, fraction on tial, Accumum 1.39E-02 o-spheric or 2.15E-04 7.59E+01 oletion pote	ion of nutrients ro of nutrients reach nulated Exceedan 4.04E-03 zone 1.89E-04 1.52E+01 ntial for non-foss	eaching freshv hing marine en ice 9.57E-05 7.96E-08 3.47E-01	vater end compart d compartment 1.44E-05 7.87E-10	9.64E-03	1.24E-04 1.02E-07	-2.94E-1 -1.53E-0
EP-freshwater = Eu EP-marine = Eutrop EP-terrestrial = Eut  POCP  POCP = Formation  ADP-minerals & metals  ADP-fossil  ADP-minerals & me	kg NMVOCeq. potential of trop  kg Sb eq.  MJ  tals = Abiotic dep	ential, fraction on tial, Accumum 1.39E-02 o-spheric or 2.15E-04 7.59E+01 oletion pote	ion of nutrients ro of nutrients reach nulated Exceedan 4.04E-03 zone 1.89E-04 1.52E+01 ntial for non-foss	eaching freshv hing marine en ice 9.57E-05 7.96E-08 3.47E-01	vater end compart d compartment 1.44E-05 7.87E-10	9.64E-03	1.24E-04 1.02E-07	-9.27E-0 -2.94E-0 -1.53E-0 -9.04E+0

	STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE	
	In Review	Public	ABBG-00224-V01.01-EN	1	en	6/11	
© Copyright 2022 ABB. All rights reserved.							

### Common base of mandatory indicators

#### Inventory flows indicator - Resource use indicators

Indicator	Unit	Total	Manu- facturing	Distri- bution	Installation	Use	End of life	Bene- fits
PERE	МЈ	1.51E+01	1.35E+00	4.88E-03	7.35E-04	1.37E+01	6.32E-03	-8.41E-01
PERM	МЈ	2.86E-01	2.86E-01	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
PERT	МЈ	1.54E+01	1.64E+00	4.88E-03	7.35E-04	1.37E+01	6.32E-03	-8.41E-01
PENRE	МЈ	7.45E+01	1.38E+01	3.47E-01	5.15E-02	5.99E+01	4.44E-01	-9.04E+00
PENRM	МЈ	1.42E+00	1.42E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
PENRT	МЈ	7.59E+01	1.52E+01	3.47E-01	5.15E-02	5.99E+01	4.44E-01	-9.04E+00

PERE = Use of renewable primary energy excluding renewable primary energy resources used as raw materials

PERM = Use of renewable primary energy resources used as raw materials

PERT = Total Use of renewable primary energy resources

PENRE = Use of non-renewable primary energy excluding non-renewable primary energy resources used as raw materials

PENRM = Use of non-renewable primary energy resources used as raw materials

PENRT = Total Use of non-renewable primary energy re-sources)

# Inventory flows indicator – Indicators describing the use of secondary materials, water, and energy re-sources

Indicator	Unit	Total	Manu- facturing	Distri- bution	Installation	Use	End of life	Bene- fits
SM	kg	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
RSF	МЈ	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
NRSF	МЈ	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
FW	m³	4.56E-02	1.50E-02	3.86E-05	8.26E-06	3.05E-02	5.90E-05	-9.27E-03

SM = Use of secondary material

RSF = Use of renewable secondary fuels

NRSF = Use of non-renewable secondary fuels

FW = Use of net fresh water

#### Inventory flows indicator - Waste category indicators

Indicator	Unit	Total	Manu- facturing	Distri- bution	Installation	Use	End of life	Bene- fits
Hazardous waste disposed	kg	1.12E-04	6.79E-05	9.04E-07	1.34E-07	4.17E-05	1.16E-06	-5.37E-05
Non- hazardous waste disposed	kg	4.71E-01	1.79E-01	1.78E-02	4.57E-03	2.37E-01	3.27E-02	-1.81E-01
Radioactive waste disposed	kg	4.73E-04	3.67E-05	2.35E-06	3.46E-07	4.31E-04	2.99E-06	-1.26E-05

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE		
In Review	Public	ABBG-00224-V01.01-EN	1	en	7/11		
© Copyright 2022 ABB. All rights reserved.							

## Common base of mandatory indicators

#### Inventory flows indicator – Output flow indicators

Indicator	Unit	Total	Manu- facturing	Distri- bution	Installation	Use	End of life	Bene- fits
Components for re- use	kg	1.63E-03	1.63E-03	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Materials for recycling	kg	1.62E-01	2.90E-03	0.00E+00	1.61E-02	0.00E+00	1.43E-01	0.00E+00
Materials for energy recovery	kg	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00
Exported energy	МЈ	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00

#### Inventory flow indicator – other indicators

Indicator	Unit	Total
Biogenic carbon content of the product	kg of C	0.00E+00
Biogenic carbon content of the associated packaging	kg of C	9.87E-03

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE		
In Review	Public	ABBG-00224-V01.01-EN	1	en	8/11		
© Copyright 2022 ABB. All rights reserved.							

#### **Extrapolation Factors**

For other products than the Reference product covered by this PEP, the environmental impacts for each phase of the lifecycle are obtained by multiplying the values of the Reference product by the following coefficients:

 $^{\star}$  if the coefficient is "1", the impacts of the phase of the life cycle are assimilated to the Reference product, meaning that the impacts are unchanged in comparison to the Reference product

Product name	Manu- facturing	Distri- bution	Installation	Use	End of life	Benefit
2CLA818800A1001	1.00	1.00	1.00	1.00	1.00	1.00
2CLA818850A1001	0.96	0.96	1.00	1.00	0.96	0.96
0						
ATUS	SECURITY LEVEL		REGISTRATION NUME	BER	REV. LANG	S. PAGE
Review	Public		ABBG-00224-V01.01-E	:NI	1 en	9/11

## **Environmental Impact Indicator Glossary**

#### Impact indicators

Indicator	Description	Distri- bution
Global warming potential (GWP) - total	Indicator of potential global warming caused by emissions to air contributing to the greenhouse effect. The total global warming potential (GWP-total) is the sum of three sub-categories of climate change.  GWP-total = GWP-fossil + GWP-biogenic + GWP- land use and land use change	kg CO₂ eq.
Ozone depletion (ODP)	Emissions to air that contribute to the destruction of the stratospheric ozone layer	kg CFC-11 eq.
Acidification of soil and water (A)	Acidification of soils and water caused by the release of certain gases to the atmosphere, such as nitrogen oxides and sulphur oxides	H+ eq.
Eutrophication (E)	Indicator of the contribution to eutrophication of water by the enrichment of the aquatic ecosystem with nutritional elements, e.g. industrial or domestic effluents, agriculture, etc. This indicator is divided to three: freshwater, marine and terrestrial.	kg P eq., kg N eq., mole N eq.
Photochemical ozone creation (POCP)	Indicator of emissions of gases that affect the creation of photochemical ozone in the lower atmosphere (smog) because of the rays of the sun.	kg NMVOC eq.
Depletion of abiotic resources – elements (ADPe)	Indicator of the depletion of natural non-fossil resources	kg Sb eq.
Depletion of abiotic resources – fossil fuels (ADPf)	The use of non-renewable fossil resources in an unsustainable way (e.g. from material to waste)	MJ (lower heating value)
Water Deprivation potential (WDP)	Deprivation-weighted water consumption. Assesses the potential of water deprivation, to either humans or ecosystems, building on the assumption that the less water remaining available per area, the more likely another user will be deprived.	m³ e depr.

#### **Resource use indicators**


Indicator	Description	Distri- bution
Total use of primary energy	Total use of non-renewable primary energy resources (primary energy and primary energy resources used as raw materials) + Total use of renewable primary energy re-sources (primary energy and primary energy resources used as raw materials)	MJ (lower heating value)

STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE		
In Review	Public	ABBG-00224-V01.01-EN	1	en	10/11		
© Copyright 2022 ABB. All rights reserved.							

PCR-ed4-EN-2021 09 06 Registration number: **Drafting Rules:** ABBG-00224-V01.01-EN Supplemented by: PSR-0005-ed2-EN-2016 03 29 Verifier accreditation number: Information and reference documents: VH32 www.pep-ecopassport.org Date of issue: 08/2023 Validity period: 5 years 0 Internal External Independent verification of the declaration and data, in compliance with ISO 14025: 2006

The PCR review was conducted by a panel of experts chaired by Julie ORGELET (DDemain)

PEP are compliant with XP C08-100-1 :2016 or EN 50693:2019
The elements of the present PEP cannot be compared with elements from another program





STATUS	SECURITY LEVEL	REGISTRATION NUMBER	REV.	LANG.	PAGE		
In Review	Public	ABBG-00224-V01.01-EN	1	en	11/11		
© Copyright 2022 ABB. All rights reserved.							